

[manuals.plus](#) /

› [TELESIN](#) /

› [TELESIN Universal Airplane Phone Holder \(Clamp Mount\) Instruction Manual](#)

**TELESIN P1-HSS-01-US**

# **TELESIN Universal Airplane Phone Holder (Clamp Mount) Instruction Manual**

Model: P1-HSS-01-US

## **1. INTRODUCTION**

This manual provides detailed instructions for the setup, operation, and maintenance of your TELESIN Universal Airplane Phone Holder with Clamp Mount. Please read this manual thoroughly before using the product to ensure proper function and longevity.



Image 1.1: The TELESIN Universal Airplane Phone Holder (Clamp Mount) with its detachable Bluetooth remote control.

The TELESIN Phone Holder is designed for versatile use, allowing you to securely mount your smartphone in various environments such as airplanes, desks, or other flat surfaces. It features a 360-degree rotatable design and includes a detachable Bluetooth remote for hands-free control of your device.

## 2. PACKAGE CONTENTS

Please verify that all the following components are included in your package:

- TELESIN Universal Phone Holder (Clamp Mount)
- Bluetooth Remote Control
- Lanyard
- Instruction Manual

## Endorsed By



@Danny Black



@Air Photography



@Ralph Mayhew Photography



@Gemini Connect



@Toaster Ventura Tech



@Niko Bolante



Image 2.1: Illustration of the included components.

## 3. SETUP INSTRUCTIONS

### 3.1 Attaching the Phone Holder

- 1. Identify a Suitable Surface:** The clamp mount is designed for flat objects up to 1.57 inches (4 cm) thick. Ensure the surface is stable and can support the weight of your phone and the holder.
- 2. Open the Clamp:** Gently pull the bottom part of the clamp downwards to open it. The clamp features non-slip silicone pads for secure attachment and to prevent scratches.
- 3. Secure the Holder:** Position the clamp onto the desired surface (e.g., airplane tray table, desk edge) and release it to firmly grip the surface. Ensure the holder is stable before proceeding.

# 4CM clamping range

Fits most table boards



Image 3.1: The clamp mount securely attached to a table, illustrating its 4cm clamping range.

## 3.2 Inserting Your Phone

1. **Expand the Phone Grip:** Gently pull the top section of the phone grip upwards to expand it.
2. **Place Your Phone:** Carefully insert your smartphone into the grip. The holder is compatible with phones ranging from 4.7 to 6.9 inches. Ensure your phone is centered and securely held by the grip.
3. **Adjust Position:** The holder features dual joints with 360-degree rotation, allowing you to adjust your phone to the optimal viewing angle in either portrait or landscape mode.



Image 3.2: The phone holder accommodates smartphones from 4.7 to 6.9 inches.

### 3.3 Pairing the Bluetooth Remote Control

The Bluetooth remote control allows for hands-free operation of your smartphone. Follow these steps to pair it:

- Power On the Remote:** Long press the capture button on the remote control to turn it on. A light indicator will illuminate.
- Enable Bluetooth on Your Phone:** Go to your smartphone's settings and enable Bluetooth.
- Search for Device:** In the Bluetooth settings, search for available devices. Locate and select "TELESIN-BS01" from the list.
- Confirm Pairing:** Once connected, the remote's indicator light will change or stop blinking, confirming successful pairing.

# Remote Control User Instructions



Image 3.3: Visual guide for pairing the Bluetooth remote control with your smartphone.

## 4. OPERATING INSTRUCTIONS

### 4.1 Adjusting the Viewing Angle

The phone holder features two rotary joints that allow for extensive angle adjustments:

- **Rotary Joint 1:** Located at the base of the phone grip, this joint allows for 360-degree rotation of your phone.
- **Rotary Joint 2:** Located near the clamp, this joint provides additional 360-degree rotation for the entire arm.

Utilize both joints to achieve your desired viewing angle, whether for watching videos, video calls, or browsing content.

# Dual 360° adjustment

Unlimited angle adjustment





Image 4.1: The dual 360-degree rotary joints offer unlimited angle adjustment.

## 4.2 Using the Bluetooth Remote Control

The remote control offers various functions for hands-free interaction with your smartphone:

- **Mode Switching:** Double-click the designated button to switch between Photography Mode (Green Light) and Short Video Viewing Mode (Blue Light).
- **Photography Mode (Green Light):**
  - **Capture Button:** Takes photos or records videos.
  - **Up/Down Buttons:** Functions as zoom in/out or volume control depending on the app.
- **Short Video Viewing Mode (Blue Light):**
  - **Capture Button:** Plays or pauses videos.
  - **Up/Down Buttons:** Scrolls up or down the screen, useful for swiping through short videos or pages.

# Short video remote control swipe videos without lifting hand

Browse Without Lifting a Finger



\*Mobile phones are for display only and not included in this product, please purchase separately if needed.

Image 4.2: Remote control functions for short video browsing (Swipe Up, Swipe Down, Play/Pause).

## Remote Control User Instructions

1. Long press the capture button to turn on. Then, search for the Bluetooth name (TELESIN-BS01) on your phone to connect.



2. Double-click to switch between operation modes:




Image 4.3: Comprehensive guide to remote control operations, including mode switching and button actions.

## 4.3 Versatile Usage Scenarios

The holder's flexible design allows for various applications:

- **Travel:** Mount on airplane tray tables or luggage handles for entertainment during flights.
- **Desk/Office:** Use as a desktop stand for video calls, watching content, or hands-free work.
- **Home:** Ideal for cooking (food vlogs), drawing/tracing, or general hands-free viewing.



Image 4.4: Example of the phone holder used as a travel mount on an airplane.

# More Features Await You!

Various angles and scenes for you to unlock



Drawing/Tracing



Food Vlogs



Mobile Tracking



Teapot Shots

Image 4.5: Various applications of the phone holder, including drawing, food vlogging, and mobile tracking.

## 5. MAINTENANCE

To ensure the longevity and optimal performance of your TELESIN Phone Holder, follow these maintenance guidelines:

- **Cleaning:** Wipe the holder and remote with a soft, dry, or slightly damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the materials.
- **Storage:** When not in use, fold the holder into its compact form and store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Over-tightening:** Do not overtighten the clamp or force the rotary joints, as this can cause damage.

## Foldable & Portable

Compact Foldable Design  
Easy to store and  
carry Weighs Only 120g



Convenient strap design  
for easy opening



Image 5.1: The holder's foldable design makes it compact and easy to store or carry.

## 6. TROUBLESHOOTING


If you encounter any issues with your TELESIN Phone Holder, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote control does not pair.	Bluetooth is off on phone; remote battery low; remote not in pairing mode.	Ensure phone Bluetooth is on. Recharge or replace remote battery if applicable. Long press capture button to enter pairing mode. Forget device and re-pair.
Remote functions are not working correctly.	Incorrect mode selected; app incompatibility; remote not connected.	Double-click to switch remote modes (Photography/Video). Ensure the remote is paired. Some apps may have limited remote functionality.
Holder clamp is not stable.	Surface too thick/thin; clamp not fully engaged; surface is uneven.	Ensure the surface thickness is within 1.57 inches (4 cm). Re-position the clamp to ensure a firm grip on a flat, stable part of the surface.
Phone is not held securely.	Phone size outside range; phone not centered.	Verify your phone size is between 4.7 and 6.9 inches. Ensure the phone is placed centrally within the grip.

## 7. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	P1-HSS-01-US
Product Dimensions	1.18 x 1.57 x 5.31 inches (folded)
Item Weight	3.84 ounces (approx. 109g)
Material	ABS, High Carbon Steel

Feature	Detail
Mounting Type	Clamp mount
Clamp Range	0-1.57 inches (0-4 cm)
Compatible Phone Size	4.7-6.9 inches
Rotation	Dual 360-degree joints
Remote Control Range	Up to 10 meters (33 feet)
Expansion Port	1/4 inch screw hole for accessories



# Flexible Expansion

## 1/4 Thread Interface



Aluminum alloy  
waterproof  
selfie stick



Carbon Fiber  
Selfie Stick



Tripod Selfie Stick



1.6m Selfie Stick

\*External products are for display only and not included in this product, please purchase separately if needed.

Image 7.1: The 1/4 inch screw hole allows for connection to various accessories like tripods or selfie sticks.

## 8. WARRANTY INFORMATION

TELESIN products are manufactured with high-quality standards. For specific warranty details, please refer to the warranty card included in your product packaging or visit the official TELESIN website. Keep your purchase receipt as proof of purchase for any warranty claims.

## 9. CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need further support, please contact TELESIN customer service through the following channels:

- **Official Website:** Visit the [TELESIN Brand Store on Amazon](#) for product information and support resources.
- **Email Support:** Refer to your product packaging or the official website for the most current customer service email address.

When contacting support, please have your product model number (P1-HSS-01-US) and purchase details ready.

© 2025 TELESIN. All rights reserved.


### Related Documents - P1-HSS-01-US

 The image shows the front cover of the user manual for the Telesin Versatile Selfie Grip. It features the TELESIN logo at the top, followed by the product name 'Versatile Selfie Grip' and its Chinese equivalent '多功能自拍器'. Below the text is a small image of the selfie grip device. At the bottom, it says 'USER MANUAL / 用户手册'.	<p><a href="#">Telesin Versatile Selfie Grip User Manual</a></p> <p>User manual for the Telesin Versatile Selfie Grip, detailing product introduction, power on/off, sleep mode, specifications, operations for Android and iPhone, and warnings.</p>
	<p><a href="#">TELESIN .</a></p> <p>TELESIN .</p>
 The image shows the front cover of the user manual for the TE-RCSS-003 Selfie bot. It features the TELESIN logo at the top, followed by the product name 'Selfie-zsík állvánnyal 1,3m-es távirányítóval Telesin TE-RCSS-003' and 'Használati útmutató' at the bottom.	<p><a href="#">TELESIN TE-RCSS-003 Selfie bot állvánnyal és távirányítóval - Használati utasítás</a></p> <p>Részletes használati útmutató a Telesin TE-RCSS-003 selfie bothoz, amely állvánnyal és távirányítóval rendelkezik. Tartalmazza a termékleírást, párosítási és használati utasításokat, töltési információkat és jótállási feltételeket.</p>



### [Telesin Universal Handle for MasterGrip User Manual](#)

User manual for the Telesin Universal Handle for MasterGrip, detailing product features, installation, operation, specifications, and safety information.



### [TELESIN Magnetic Cell Phone Stand - User Guide & Assembly Instructions](#)

Comprehensive user guide for the TELESIN Magnetic Cell Phone Video/Live Streaming Stand. Learn about product parameters, packing list, assembly, operation, and accessories.



### [Telesin Fun Shot Magnetic Grip User Guide](#)

Comprehensive user guide for the Telesin Fun Shot Magnetic Grip, detailing its features, operation, setup, and safety precautions.