Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- HAUSHOF /
- > HAUSHOF Mattress Vacuum Cleaner HH24140A User Manual

HAUSHOF HH24140A

HAUSHOF Mattress Vacuum Cleaner HH24140A User Manual

Model: HH24140A

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this appliance and retain for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- This appliance is for household use only. Do not use outdoors or on wet surfaces.
- Always unplug the vacuum cleaner from the electrical outlet before cleaning or performing maintenance.
- Do not handle the plug or appliance with wet hands.
- · Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not pick up flammable or combustible materials, such as lighter fluid, gasoline, or kerosene, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- The UV-C light automatically turns off when the unit is lifted from the surface to prevent direct exposure. Do not attempt to bypass this safety feature.
- Do not look directly at the UV-C light when it is active.
- Ensure the HEPA filter and dust cups are correctly installed before operation.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly
 qualified persons in order to avoid a hazard.

PRODUCT OVERVIEW

Components

Familiarize yourself with the parts of your HAUSHOF Mattress Vacuum Cleaner:



Diagram showing the components of the HAUSHOF Mattress Vacuum Cleaner, including handle, dust cup, power cord, display screen, rolling brush, UV-C lamp, and air outlet.

- Switch Button: Powers the unit on and off.
- Dust Cup Release Button: For detaching the dust cup.
- Handle: Ergonomic grip for operation.
- Power Cord: Provides continuous power.
- Dust Cup: Collects debris and houses the filtration system.
- **Display Screen:** Shows operational status and indicators.
- Rolling Brush: High-speed brush for dislodging particles.
- UV-C Lamp: Emits UV-C light for enhanced cleaning.
- Air Outlet: Exhausts filtered air.
- Fragrance Compartment: For aromatherapy pads.

Key Features

- Powerful 15KPa Suction: Effectively captures dust, hair, and embedded particles.
- 140°F Hot Air System: Penetrates fabrics to reduce moisture and create a fresher environment.

- 275nm UV-C Light: Helps disrupt particles on fabric surfaces. Features an automatic safety shut-off when lifted.
- High-Speed Roller Brush: Assists in dislodging stubborn debris.
- **Dual Dust Cups with H12-grade HEPA Filter:** Separates storage and filtration, preventing clogging and ensuring high filtration efficiency.
- **Aromatherapy Function:** Includes a sponge slot for essential oils or fragrance pads to provide a light scent during cleaning.
- Extended 16.4-foot Cord: Offers broad reach for various cleaning tasks.
- 8.5-inch Suction Port: Designed for efficient cleaning of larger areas.



Illustration demonstrating the 15KPa suction power, UV-C light, hot air drying, and dual dust cup system of the HAUSHOF Mattress Vacuum Cleaner.



Close-up of the electronic display panel showing the Dust Mite Index, Mite Status Indicator Light (High, Medium, Low), UV-C Lamp indicator, Heating Drying Lamp indicator, and Rolling Brush Tapping Lamp indicator.

SETUP

Unpacking

- 1. Carefully remove all components from the packaging.
- 2. Check for any damage during transit. If any damage is found, do not use the appliance and contact customer support.
- 3. Ensure all listed components are present: Main Vacuum Unit, Dust Cup Assembly, Fragrance Pads (2), User Manual.

Initial Use

- 1. Ensure the dust cup assembly is securely attached to the main unit.
- 2. Unwind the power cord completely.
- 3. Plug the power cord into a suitable electrical outlet (120V AC).

OPERATION

Powering On/Off

Press the **Switch Button** located on the handle to turn the vacuum cleaner on. Press it again to turn the appliance off.

Cleaning Functions

- **UV-C Light:** The 275nm UV-C light activates automatically when the vacuum head is in contact with a surface. For safety, it will turn off if the unit is lifted.
- 140°F Hot Air: The built-in hot air system operates concurrently with the vacuum, providing heat to assist in drying and particle disruption.
- Roller Brush: The high-speed roller brush rotates during operation to agitate fabric surfaces, helping to

dislodge embedded dust and debris.

Aromatherapy Function

To use the aromatherapy feature:

- 1. Locate the fragrance compartment on the side of the vacuum head.
- 2. Open the compartment cover.
- 3. Insert one of the provided fragrance pads into the slot. You may also add a few drops of your preferred essential oil to the sponge pad.
- 4. Close the compartment cover securely.
- 5. The scent will be dispersed during vacuum operation.



Image showing the aromatherapy compartment on the HAUSHOF Mattress Vacuum Cleaner and the included fragrance pads.

Usage Tips

- Move the vacuum cleaner slowly and steadily across the surface to allow the suction, UV-C light, and hot air to work effectively.
- For best results on mattresses, clean in overlapping passes.
- The vacuum is suitable for mattresses, sofas, couches, cribs, and other fabric surfaces.



MEET YOUR VARIABLE NEEDS



Collage of images showing the HAUSHOF Mattress Vacuum Cleaner being used on a bed, carpet, pet bed, and sofa.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your appliance. Always unplug the vacuum before cleaning.

Emptying and Cleaning Dust Cups

The dual dust cup design separates larger debris from fine dust, improving filtration efficiency.



Diagram illustrating the dual dust cup design for separate filtration and dust storage, highlighting high filtration efficiency and strong suction.

- 1. Press the Dust Cup Release Button to detach the dust cup assembly from the main unit.
- 2. Carefully empty the contents of both dust cups into a trash receptacle.
- 3. Rinse the dust cups with water if necessary. Ensure they are completely dry before reattaching.

Cleaning the HEPA Filter

The H12-grade HEPA filter is crucial for trapping fine particles. It is located within the dust cup assembly.

- 1. Remove the HEPA filter from the dust cup assembly.
- 2. Tap the filter gently over a trash can to dislodge accumulated dust.
- 3. If heavily soiled, rinse the HEPA filter under running water. Do not use detergents.
- 4. Allow the filter to air dry completely for at least 24 hours before reinserting. Do not use the vacuum with a wet filter.

Cleaning the Roller Brush

1. Locate the cover lock for the rolling brush on the underside of the vacuum head.

- 2. Unlock and remove the rolling brush cover plate.
- 3. Carefully remove the rolling brush.
- 4. Remove any tangled hair or debris from the brush using scissors or a brush cleaning tool.
- 5. Reinsert the rolling brush and secure the cover plate.



Step-by-step visual guide on how to disassemble and clean the dust cup and roller brush of the HAUSHOF Mattress Vacuum Cleaner.

Storage

Store the vacuum cleaner in a cool, dry place, away from direct sunlight and out of reach of children.

TROUBLESHOOTING

If you encounter any issues with your HAUSHOF Mattress Vacuum Cleaner, please refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on.	 Power cord not securely plugged in. No power from the electrical outlet. Switch button not pressed correctly. 	 Ensure the power cord is firmly plugged into a working outlet. Check the circuit breaker or try a different outlet. Press the switch button firmly.
Reduced suction power.	 Dust cups are full. HEPA filter is clogged. Roller brush is tangled with debris. Suction port is blocked. 	 Empty the dust cups. Clean or replace the HEPA filter. Clean the roller brush. Check the suction port for any obstructions and remove them.

Problem	Possible Cause	Solution
UV-C light not working.	 Vacuum is not in contact with the surface. UV-C lamp is damaged. 	 Ensure the vacuum head is pressed firmly against the cleaning surface. The UV-C light has a safety sensor. Contact customer support if the lamp is damaged.
Unusual noise during operation.	 Obstruction in the roller brush or suction path. Dust cups or filter not properly installed. 	 Turn off and unplug the vacuum. Check and clear any obstructions from the roller brush and suction port. Ensure all dust cup components and filters are correctly assembled and secured.

SPECIFICATIONS

Feature	Detail
Brand	HAUSHOF
Model Name	HAUSHOF Mattress Vacuum Cleaner
Model Number	HH24140A
Suction Power	15 KPa
UV-C Wavelength	275 nm
Hot Air Temperature	140°F
Dust Cup Capacity	0.5 Liters (500 mL)
Filter Type	H12-grade HEPA Filter
Cord Length	16.4 feet
Product Dimensions	11"L x 11.8"W x 7.8"H
Item Weight	4.7 pounds
Power Source	Corded Electric

Your HAUSHOF Mattress Vacuum Cleaner is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.

For technical support, replacement parts, or any questions regarding your product, please contact HAUSHOF customer service through the contact information provided on your warranty card or the official HAUSHOF website.

Related Documents - HH24140A



HAUSHOF High Pressure Cleaner Operator's Manual HH20007AU

The HAUSHOF High Pressure Cleaner Operator's Manual provides comprehensive instructions for the safe and efficient operation, maintenance, and troubleshooting of the HH20007AU and ABW-VCL-90P(C) models. Learn about proper use, safety precautions, technical specifications, installation, and storage to ensure years of rugged, trouble-free performance from your HAUSHOF pressure washer.



HausHof Carpet Spot Cleaner Operation Manual

This operation manual provides detailed instructions for the HausHof Carpet Spot Cleaner, including safety precautions, parts identification, preparation, operating instructions, cleaning and maintenance, troubleshooting, and disposal information.



HAUSHOF Carpet Spot Cleaner HH22050A Operation Manual

This manual provides instructions for the HAUSHOF Carpet Spot Cleaner HH22050A, covering safety precautions, parts identification, preparation, operation, cleaning, maintenance, troubleshooting, and disposal.



HAUSHOF Carpet Spot Cleaner Original Operation Manual

This operation manual provides detailed instructions for the HAUSHOF Carpet Spot Cleaner, Model YLW6336. It covers important safety precautions, parts identification, preparation, operating instructions, handling stubborn dirt, cleaning and maintenance, consumables, fault diagnosis, and environmentally friendly disposal.



HAUSHOF Steam Cleaner JX-078: Original Operating Instructions and Safety Guide

Detailed operating instructions, safety precautions, and maintenance guide for the HAUSHOF Steam Cleaner Model JX-078. Learn how to use this household steam cleaner effectively and safely for various cleaning tasks.



HAUSHOF HH25001A Portable Dehumidifier User Manual

Official user manual for the HAUSHOF HH25001A portable dehumidifier. Includes safety instructions, technical specifications, operation guide, cleaning, maintenance, and troubleshooting tips.