

[Manuals.plus](#) /

› [ABBIDOT](#) /

› ABBIDOT Smaller No Shock Bark Collar User Manual

ABBIDOT PB20

ABBIDOT Smaller No Shock Bark Collar User Manual

Model: PB20

INTRODUCTION

The ABBIDOT Smaller No Shock Bark Collar is designed to help manage and reduce excessive barking in dogs and meowing in cats, weighing between 5-100 lbs. This device utilizes humane training modes including beep, vibration, and a combination of both, without the use of static shock. It features automatic bark detection, adjustable sensitivity levels, and a durable, waterproof design for versatile use.



Image: The ABBIDOT Smaller No Shock Bark Collar, showcasing its compact design and digital display.

Safety Information

- This collar is intended for dogs 6 months and older.
- Do not use this collar on aggressive dogs or dogs with health issues. Consult a veterinarian if unsure.
- The collar should not be worn for more than 8-12 hours per day to prevent pressure necrosis (bed sores).
- Regularly check your pet's neck for any signs of irritation or sores. If irritation occurs, discontinue use until the skin heals.
- Ensure the collar is fitted correctly, not too tight or too loose. Two fingers should comfortably fit between the collar and your pet's neck.
- This device is not a toy. Keep out of reach of children.

Product Overview and Components

The ABBIDOT bark collar system includes the main collar unit and an adjustable nylon strap. The main unit features a digital display, control buttons, and charging port.

Key Features:

- No Shock Training Modes: Beep, Vibration, Beep + Vibration.
- Automatic Bark Detection with adjustable sensitivity (Levels 1-5).
- IP67 Dustproof and Waterproof design.
- Rechargeable battery with long life (up to 10-20 days on 1-2 hours charge).
- Suitable for pets 5-100 lbs with neck sizes 6-27 inches.

Smart Anti-bark Collar

Easy to Use



Beep



Vibration



Sensitivity

Image: Diagram illustrating the collar's controls, including the power button, mode switch, sensitivity display, and power indicator.

SETUP

1. Charging the Collar

Before first use, fully charge the collar. Connect the USB charging cable to the collar's charging port and a USB power source (e.g., USB adapter, car charger, power bank, laptop/PC). A full charge typically takes 1-2 hours and provides 10-20 days of use.

HOW TO ADJUST THE COLLAR STRAP?



STEP 1

Pass the nylon belt through the collar



STEP 2

Pass the nylon belt through the tri-glides buckle



STEP 3

Pass the nylon belt through the side release buckle

Image: Illustration of the collar being charged via USB, highlighting the 2-hour charge time for 10 days of use.

2. Attaching and Adjusting the Collar Strap

The collar comes with an adjustable nylon strap. Thread the strap through the collar unit's loops and adjust the length to fit your pet's neck comfortably. Ensure the strap is securely fastened with the buckle.




Image: Visual guide on how to adjust the collar strap, showing minimum and maximum lengths (15 cm to 70 cm) and suitability for pets from 5-100 lbs.

3. Fitting the Collar on Your Pet

Place the collar around your pet's neck so that the main unit rests comfortably on their throat, near the vocal cords. The fit should be snug but not tight; you should be able to fit two fingers between the collar strap and your pet's neck. This ensures proper contact for bark detection and comfort.

OPERATING INSTRUCTIONS

1. Power On/Off

Press and hold the power button (usually marked with a circle and vertical line) on the collar unit to turn it on or off. The display will light up when powered on.

2. Switching Modes

The collar offers three training modes: Beep, Vibration, and Beep + Vibration. Press the 'M' button to cycle through these modes. The current mode will be indicated on the display.

1. **Beep Mode:** Emits an audible tone when barking is detected.
2. **Vibration Mode:** Delivers a gentle vibration when barking is detected.
3. **Beep + Vibration Mode:** Combines both a beep and vibration for correction.

3 Working Modes

Auto and Effective



Switch Modes

1  Beep

2  Vibration

3  Beep+Vibration

Image: Visual representation of the three working modes (Beep, Vibration, Beep+Vibration) and how to switch between them using the 'M' button.

3. Adjusting Sensitivity Levels

The collar has 5 adjustable sensitivity levels (1-5) to detect barking. Level 'H' is a test mode. Higher sensitivity levels mean the

collar will detect barking more easily, while lower levels require more pronounced barking. Adjust the sensitivity based on your pet's barking habits and the surrounding environment.

- **Levels 1-2:** Suitable for noisy environments (e.g., busy streets, downtown, dog parks).
- **Levels 3-4:** Ideal for normal environments (e.g., suburbs, home, work area).
- **Level 5:** Best for quiet environments (e.g., sleep or late night).

5 Adjustable Sensitivity

Smart and Professional



Image: Illustration demonstrating the 5 adjustable sensitivity levels, from low to high, with 'H' indicating test mode.



Image: Examples of suitable sensitivity levels for various environments: noisy, normal, and quiet.

4. Automatic Detection and Trigger Record

The collar automatically detects your pet's barking or meowing. It uses advanced bark recognition technology to prevent false triggering from other sounds (e.g., car horns, other dogs barking). If the collar is not triggered for 35 seconds, the internal trigger record will reset and recalculate.



Image: Depiction of the collar's humane, no-shock vibration feature, emphasizing safety.

MAINTENANCE

- **Cleaning:** Wipe the collar unit and strap with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Waterproof:** The collar is IP67 dustproof and waterproof, allowing your pet to play freely in water, rain, or snow. However, ensure the charging port cover is securely closed when exposed to water.
- **Battery Care:** Recharge the collar when the battery indicator is low. Avoid completely draining the battery for extended periods to prolong its lifespan.
- **Storage:** When not in use for a long time, store the collar in a cool, dry place.

Dustproof & Waterproof

Play Freely in the Water



Image: A dog swimming while wearing the ABBIDOT bark collar, demonstrating its waterproof capability.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Collar not activating when pet barks.	Battery is low or dead. Sensitivity level is too low. Collar is not positioned correctly. Collar is off.	Charge the collar fully. Increase the sensitivity level. Adjust the collar position on your pet's throat. Ensure the collar is powered on.
Collar activating without pet barking (false triggers).	Sensitivity level is too high. Loud ambient noises.	Decrease the sensitivity level. Move to a quieter environment or adjust sensitivity accordingly.
Collar not holding a charge.	Charging cable or adapter issue. Battery degradation.	Try a different USB charging cable and adapter. Contact customer support if the issue persists.

SPECIFICATIONS

Model Number	PB20
Brand	ABBIDOT
Training Modes	Beep, Vibration, Beep + Vibration
Sensitivity Levels	5 (plus Test Mode 'H')
Waterproof Rating	IP67 Dustproof and Waterproof
Battery Life	10-20 days (after 1-2 hours charge)
Recommended Pet Weight	5-100 lbs (2.3-45 kg)
Neck Size Compatibility	6-27 inches (15-70 cm)
Material	Plastic, Rubber
Color	Pure Black

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your product packaging or visit the official ABBIDOT website. Keep your purchase receipt for warranty claims.
Visit the [ABBIDOT Store](#) for more products and information.

