Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY BSL-2212V-32T2

ALLIMITY Remote Control Instruction Manual

For BSL Smart LED TV Models: SF-01, BSL-2212V, BSL-24T2SATV, BSL-32T2S, BSL-24T2S, BSL-32T2, BSL-32T2SATV

Introduction Compatibility Features Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides comprehensive instructions for the ALLIMITY replacement remote control, designed for use with various BSL Smart LED TV models. This remote offers full functionality without requiring any programming or setup, ensuring a seamless user experience. Please read this manual carefully to understand the features and proper operation of your new remote control.



Image 1: Angled front view of the ALLIMITY remote control, showcasing its button layout.

2. Compatibility

This ALLIMITY remote control is compatible with the following BSL Smart LED TV models:

- SF-01
- BSL-2212V
- BSL-24T2SATV
- BSL-32T2S
- BSL-24T2S
- BSL-32T2
- BSL-32T2SATV

To confirm compatibility, compare your original remote control or your TV's model number (usually found on a label on the back of the

TV) with the list provided. The remote is designed to function identically to the original remote for these models.

3. Key Features

- **No Programming Required:** Ready to use directly out of the package.
- **Full Functionality:** Designed to replicate all functions of the original remote control.
- **Ergonomic Design:** Lightweight and comfortable to hold, providing a secure grip.
- **Stable Performance:** Offers a consistent and reliable signal transmission.
- **Infrared Technology:** Utilizes standard infrared (IR) communication for TV control.

4. Setup: Battery Installation

The ALLIMITY remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: Always replace both batteries at the same time. Do not mix old and new batteries, or different types of batteries.





Image 2: Rear view of the remote control, showing the battery compartment cover.

5. Basic Operation

This section outlines the primary functions of the buttons on your ALLIMITY remote control. Refer to your BSL TV's user manual for specific advanced functions.

Button	Function
POWER	Turns the TV on or off.
MUTE	Mutes or unmutes the TV sound.
0-9 (Number Buttons)	Directly select TV channels.
VOL +/-	Adjusts the volume level.
CH +/-	Changes the TV channel up or down.
SOURCE	Selects input sources (e.g., HDMI, AV).
MENU	Accesses the TV's main menu.
OK / Navigation Arrows	Navigates through menus and confirms selections.
EXIT	Exits the current menu or function.
HOME	Returns to the TV's home screen or smart TV interface.
INFO	Displays program information.
FAV	Accesses favorite channels list.
P.MODE	Changes picture modes.
S.MODE	Changes sound modes.

Button	Function
AUDIO	Selects audio tracks or languages.
EPG	Opens the Electronic Program Guide.
REC	Initiates recording (if supported by TV and external storage).
TV/RADIO	Switches between TV and Radio modes.
ASPECT	Adjusts the screen aspect ratio.
SLEEP	Sets the sleep timer.
FREEZE	Freezes the current image on screen.
SUB-T	Activates or deactivates subtitles.
PVR.LIST	Accesses the PVR recording list.
TTX	Opens Teletext.
INDEX	Accesses index functions (e.g., Teletext index).
ZOOM	Zooms in or out on the screen.
TSR	Time Shift Recording function.
HOLD	Holds Teletext page.
REVEAL	Reveals hidden Teletext information.
SUB-P	Sub-page selection for Teletext.
Colored Buttons (Red, Green, Yellow, Blue)	Context-sensitive functions, often used in Smart TV apps or Teletext.
Playback Controls (Rewind, Play/Pause, Fast Forward, Previous, Stop, Next)	Controls media playback for connected devices or recorded content.





Image 3: Front and side view of the remote control, illustrating its full button layout and physical dimensions (21 cm / 8.27 in length, 5 cm / 1.97 in width).

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Care:** Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

7. Troubleshooting

Problem	Solution

Problem	Solution
Remote control is not responding.	◦ Ensure batteries are inserted correctly with the correct polarity (+/-). ◦ Replace old batteries with new ones. ◦ Check for any obstructions between the remote and the TV's IR sensor. ◦ Ensure you are within the effective operating range (up to 10 meters).
Some buttons are not working.	◦ Verify that the remote is compatible with your specific BSL TV model. ◦ Clean the remote control surface, especially around the non-working buttons, to remove any debris. ◦ If only specific advanced functions are not working, consult your TV's original user manual to confirm if the TV model supports those functions.
Remote control range is reduced.	◦ Replace batteries with fresh ones. ◦ Ensure there are no strong light sources (e.g., direct sunlight, fluorescent lights) interfering with the IR signal.

8. Specifications

Feature	Detail
Brand	ALLIMITY
Model Number	BSL-2212V-32T2
Compatible Devices	SF-01, BSL-2212V, BSL-24T2SATV, BSL-32T2S, BSL-24T2S, BSL-32T2, BSL-32T2SATV
Connectivity Technology	Infrared (IR)
Maximum Range	10 Meters
Power Source	2 x AAA Batteries (not included)
Product Dimensions	17 x 5 x 1 cm (approximately 6.7 x 2 x 0.4 inches)
Item Weight	59 Grams (approximately 2.08 ounces)
Special Features	Ergonomic design

9. Warranty and Support

Specific warranty information for this ALLIMITY remote control is not provided in the product details. For any support inquiries, troubleshooting assistance beyond this manual, or warranty claims, please contact the seller or manufacturer directly through your purchase platform.
Please retain your proof of purchase for any potential warranty or support claims.

© 2025 ALLIMITY. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DSL5GJ18

More documents and user manuals: **https://manuals.plus/**