Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY V9-SUPER

ALLIMITY Remote Control User Manual

Brand: ALLIMITY | Model: V9-SUPER

1. Introduction

This manual provides comprehensive instructions for the ALLIMITY remote control, designed for use with various GTMEDIA SAT DTT models. It covers essential information regarding its features, setup, operation, maintenance, and troubleshooting to ensure optimal performance.





Image 1.1: Front view of the ALLIMITY remote control, showcasing its button layout and ergonomic design.

2. Compatibility

The ALLIMITY remote control is compatible with the following GTMEDIA SAT DTT receiver models:

- GTMEDIA V8 HONOR
- GTMEDIA V8 PRO
- GTMEDIA V8 NQVA
- GTMEDIA V9 SUPER
- GTMEDIA N30MTBX01

To ensure compatibility, verify that your device's model number matches one of the listed models.

3. Key Features

- **Easy to Use:** No programming or setup is required. The remote is ready for use directly out of the packaging.
- **Fully Functional:** Designed to replicate all functions of your original remote control for the compatible GTMEDIA devices.
- **Ergonomic Design:** Lightweight and comfortable to hold, facilitating extended use without discomfort.
- **Stable Performance:** Offers a reliable and stable transmission performance with an extended range.

4. Setup

4.1 Battery Installation

The remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.





Image 4.1: Back view of the ALLIMITY remote control, highlighting the battery compartment for installation.

4.2 Initial Use

Once batteries are installed, the remote control is ready for immediate use with your compatible GTMEDIA device. No additional programming or pairing steps are necessary.

5. Operating Instructions

The ALLIMITY remote control features a standard layout for intuitive operation. Refer to the image below for a visual guide to the buttons and their general functions.



Image 5.1: Angled view of the ALLIMITY remote control, illustrating the full array of buttons and their positions.

5.1 Button Functions Overview

- **Power Button (U):** Turns the device on or off.
- **TV MODE:** Switches the input mode to TV.
- **Mute Button:** Mutes or unmutes the audio.
- **Numeric Keypad (0-9):** Used for direct channel input or data entry.
- **MENU:** Accesses the main menu of the device.
- **EXIT:** Exits the current menu or function.
- **Navigation Buttons (Up, Down, Left, Right):** Navigates through menus and options.
- **OK Button:** Confirms selections or displays channel information.
- **VOL+/-:** Adjusts the volume level.
- **CH+/-:** Changes channels.
- **SAT:** Selects satellite input.

- **FAV:** Accesses favorite channels list.
- **Playback Controls (Play/Pause, Stop, Prev, Next, FF, FB):** Controls media playback.
- **EPG:** Displays the Electronic Program Guide.
- **REC:** Initiates recording.
- **SLEEP:** Sets a sleep timer.
- **TEXT:** Accesses teletext.
- **SUB-T:** Selects subtitle options.

6. Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control regularly with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution, then wipe dry immediately. Avoid using harsh chemicals or abrasive cleaners.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, remove the batteries to prevent leakage.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

7. Troubleshooting

If you encounter issues with your ALLIMITY remote control, refer to the following troubleshooting tips:

- **Remote Not Responding:**
  - Check if the batteries are correctly inserted with the correct polarity.
  - Replace the batteries with new ones.
  - Ensure there are no obstructions between the remote control and the device's infrared sensor.
  - Point the remote directly at the device.
- **Short Operating Range:**
  - Replace the batteries, as low battery power can reduce the effective range.
  - Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the IR signal.
- **Specific Buttons Not Working:**
  - Clean the remote control, especially around the non-functioning buttons, to remove any dirt or debris that might be preventing contact.
  - If only specific buttons fail, and other troubleshooting steps do not resolve the issue, the remote control may require replacement.

8. Specifications

Below are the technical specifications for the ALLIMITY remote control:



18 cm / 7.09 in


TV MODE
PLAY/PAUSE
FB
FF
STOP
PREV
NEXT
1 مه
2 ABC
3 DEF
4 GHI
5 JKL
6 MNO
7 PQRS
8 TUV
9 WXYZ
RECALL
0
AUDIO
MENU
EXIT
CH+
VOL-
OK
VOL+
CH-
SAT
FAV
PG+
PG-
You Tube
EPG
REC
SLEEP
TV/RAD
FIND
TEXT
SUB-T
M/P
VIDEO
PVR
TIMER





Image 8.1: Front view of the ALLIMITY remote control, illustrating its physical dimensions.

Feature	Detail
Brand	ALLIMITY
Item Model Number	V9-SUPER
Connectivity Technology	Infrared (IR)
Special Features	Ergonomic Design
Compatible Devices	V8 HONOR, V8 PRO, V8 NQVA, V9 SUPER, N30MTBX01
Maximum Range	10 Meters
Item Weight	59 Grams
Power Source	2 x AAA Batteries (not included)
Country of Origin	China

9. Warranty and Support

Specific warranty information for this ALLIMITY remote control is not provided in the product details. For any support inquiries, warranty claims, or further assistance, please refer to the retailer or the manufacturer's official support channels where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DSL64ZYD

More documents and user manuals: **https://manuals.plus/**