

Eonon L0328J

Eonon 11.6-inch Headrest DVD Player Monitor (Model L0328J) User Manual

Model: L0328J | Brand: Eonon

1. INTRODUCTION

Thank you for purchasing the Eonon 11.6-inch Headrest DVD Player Monitor. This manual provides detailed instructions for installation, operation, and maintenance to ensure optimal performance and longevity of your device. Please read this manual thoroughly before use and keep it for future reference.

2. PRODUCT OVERVIEW

Key Features

- **11.6-inch IPS Display:** Enjoy vibrant and clear visuals from any viewing angle with a 1366x768 high-resolution screen.
- **Built-in DVD Player:** Convenient slot-in DVD player supports various disc formats including DVD, DVD+R/-R, DVD+RW/-RW, MP3, CD, CD+R/-R, CD+RW/-RW.
- **CPRM Playback & Region-Free:** Supports CPRM discs and is region-free, allowing playback of DVDs from various regions.
- **HDMI Input:** Connect smartphones, Amazon Fire TV Stick, and other HDMI-compatible devices for high-quality audio and video. (Note: HDMI output devices only. HDMI conversion cable not included.)
- **USB/SD Card Support:** Play movies, music, and photos from USB drives and SD cards up to 32GB. Supports various formats including MPEG, RMVB, MKV, MPG, MP4, ASF, VOB, AV, WMV, FLV, MOV.
- **Resume Playback Function:** The device can resume playback from where it was stopped for DVD, USB, and SD card content. (Note: CPRM discs do not support resume function. Dubbed DVDs may not support resume function.)
- **Front Speakers:** Speakers are positioned at the front to minimize interference with the driver, promoting

safer driving.


- **Wired/IR Headphone Support:** Connect wired or IR headphones for private listening without disturbing others. (Headphones not included.)
- **Home Use Capability:** Can be used at home with the separately sold EONON POA025 power cable.
- **Mood Lighting:** Integrated lights at the bottom of the monitor add ambiance to your car interior.
- **12V/24V Compatible:** Suitable for use in both cars and trucks.

Package Contents

Please check that all items are included in your package:

- Monitor Unit (x1)
- Instruction Manual (x1)
- Remote Control (x1)
- Cigarette Lighter Power Cable (2.4m) (x1)
- Rear Mount Bracket (x1)
- Center Mount Bracket (x1)
- Screwdriver (x1)
- Spare Fuse (x1)
- Shaft Adapters (x12)
- Monitor Cleaning Cloth (x1)

サイズ



※一体型シートは全ブラケット非対応、
肩に突起のあるシートはリアブラケットのみ対応です。



※調整パーツ6種類各2個付属
10.2/11.2/12.2/13.2/14.2/16.2MM

付属品

1  モニター本体 1台	2  説明書x1	3  リモコンx1	4  シガー電源 ケーブル(長さ2.4m)x1	5  リア取付用ブラケットx1
6  センター取付用 ブラケットx1	7  ドライバーx1	8  予備ヒューズx1	9  シャフトアダプターx12	10  モニタークリーニ ングクロスx1

Image: All included accessories for the Eonon L0328J monitor.

3. INSTALLATION

The Eonon L0328J monitor offers two primary installation methods: Center Bracket and Rear Bracket. Please choose the method that best suits your vehicle and preferences.

3.1 Center Bracket Installation

This method allows a single monitor to be centrally positioned in the rear, enabling passengers on both sides to comfortably view the screen simultaneously.

1. Turn the switch to ON to extend the arm.
2. Rotate the lock lever to adjust the direction of the arm.
3. Loosen the 4 screws on the bracket.
4. Remove the headrest. Position the center bracket and secure it under the original bracket using the two slots.
5. Insert the two main poles into the car seat and tighten the screws.
6. Slide the monitor onto the guide rail while holding the switch, then attach the center bracket.
7. Adjust the tightness of the monitor and bracket connection, then lock it clockwise.
8. After adjusting the extension rod, turn the switch to OFF to secure it.



Image: Diagram illustrating the steps for installing the monitor using the center bracket.

Video: This video demonstrates the installation process for the Eonon 11.6-inch Headrest DVD Player L0328J using both center and rear bracket methods.

3.2 Rear Bracket Installation

This method allows the monitor to be attached directly behind a single headrest.

1. Turn the 'Connection' switch to ON and the 'Fixed Clip' switch to OFF.
2. Pull down to remove the connection bracket.
3. Unfold the connection bracket and remove the fixed clip (screw side up).
4. This is the state after removal.
5. Lift the headrest. Point the headrest opening towards yourself.
6. Push the left and right connection brackets into the car seat and lock them.
7. When attaching the monitor and connection bracket, insert the fixed clip (bracket side up).
8. Adjust the tightness of the nut and connection bracket.
9. Attach the bracket and tighten the screws.
10. Push the inserted part all the way in.

2年
保証も!

購入後1年を過ぎても、
もう1年。
合計2年間の安心を
ご提供します。

大切なお知らせ

■ **保証期間の拡大と、お客様へのご案内**
平素より格別のご愛顧を賜り、誠にありがとうございます。このたび、2026年1月9日以降L0328Jご購入のお客様を対象に、保証期間を2年間に拡大させていただくこととなりました。

■ **2026年1月9日より前にご購入のお客様へ**
誠にありがとうございます。製品L0328Jへの一層の信頼をお届けするため、2025年10月1日～2026年1月8日の期間にご購入いただいたお客様についても、特例として保証期間を2年間に延長させていただきます。詳細は、当社カスタマーサポートまでお問い合わせください。

Image: Diagram illustrating the steps for installing the monitor using the rear bracket.

3.3 Power Connection

Connect the cigarette lighter power cable (2.4m length) to the monitor's DC 12V input port and then to your vehicle's cigarette lighter socket. Ensure a secure connection.

有線/IRヘッドフォン対応



ご家庭でも使用可能

(EONON POA025 別売り)



モニター底部に搭載されたライトで、
ドライブ中の車内をムード
満点に彩ります。



12V/24V 兼用

トラック内での使用も可能



Image: Close-up of the monitor's side ports, including DC 12V input, USB, SD, HDMI, and headphone jack.

4. OPERATION

4.1 DVD Playback

The monitor features a convenient slot-in DVD player. Simply insert a compatible DVD disc into the slot. The monitor will automatically detect and begin playback. Supported formats include DVD, DVD+R/-R, DVD+RW/-RW, MP3, CD, CD+R/-R, CD+RW/-RW. The device is region-free and supports CPRM discs.

ディスク交換に便利な
スロットイン式



CPRM再生可能
リージョンフリー

※blu-rayディスクおよび暗号化されたディスクには対応していません。

Image: Demonstrates the slot-in DVD feature and highlights CPRM compatibility.

4.2 USB/SD Card Playback

Insert a USB drive or SD card (up to 32GB) into the designated ports on the monitor. Use the remote control or on-screen menu to navigate and select media files (movies, music, photos) for playback. Supported video formats include MPEG, RMVB, MKV, MPG, MP4, ASF, VOB, AV, WMV, FLV, MOV.

4.3 HDMI Input

Connect an HDMI-compatible device (e.g., smartphone, Amazon Fire TV Stick) to the HDMI input port on the monitor. Switch the input source on the monitor to HDMI to display content from the connected device. Ensure your device has HDMI output capability. An HDMI conversion cable is not included.

フロントスピーカーは
運転を
より安全にします。

HDMI入力対応

スマートフォンやAmazon Fire TV StickなどのHDMI対応機器を接続して、高画質な映像や音声を楽しめます。

You Tube

prime video

NETFLIX

※HDMI出力機能付きのデバイスにのみ対応しています。また、HDMI変換ケーブルは付属しておりません。

Image: Shows the monitor connected via HDMI to a smartphone, displaying content.

4.4 Resume Playback

The monitor supports a resume playback function for DVD, USB, and SD card content. If playback is stopped, the device will resume from the last stopped position when restarted. Please note that CPRM discs and some dubbed DVDs may not support this feature.

4.5 Audio Options

- **Front Speakers:** The monitor has built-in front-facing speakers for audio output.
- **Wired/IR Headphones:** For private listening, connect wired headphones to the 3.5mm audio jack or use IR wireless headphones (not included).



Image: Icons indicating support for both wired and infrared (IR) headphones.

5. MAINTENANCE

5.1 Cleaning the Monitor

Use the provided monitor cleaning cloth to gently wipe the screen and exterior of the device. Do not use abrasive cleaners or solvents, as they may damage the surface.

5.2 Disc Care

Handle discs by their edges to avoid fingerprints and scratches. Store discs in their cases when not in use. Clean dirty discs with a soft, lint-free cloth, wiping from the center outwards.

5.3 Storage

When not in use for extended periods, disconnect the monitor from the power source and store it in a cool, dry place away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected properly; Blown fuse in cigarette lighter plug.	Check power cable connection; Replace fuse in cigarette lighter plug.
No image/sound from DVD	Disc inserted incorrectly; Disc is dirty or scratched; Incompatible disc format.	Reinsert disc correctly; Clean or replace disc; Ensure disc format is supported.
No image/sound from HDMI	HDMI cable not connected properly; Incorrect input source selected; External device not outputting signal.	Check HDMI cable connection; Select correct input source; Verify external device's HDMI output.
No sound from speakers/headphones	Volume too low or muted; Headphones not connected properly.	Increase volume or unmute; Check headphone connection.
Remote control not working	Batteries depleted; Obstruction between remote and monitor's IR receiver.	Replace batteries; Remove any obstructions.

7. SPECIFICATIONS

- **Screen Size:** 11.6 inches
- **Display Type:** IPS LCD
- **Native Resolution:** 1366x768 pixels
- **Color:** Black
- **Media Type Support:** CD-R, DVD RW, SD, USB
- **Connectivity:** HDMI, USB
- **Power Compatibility:** 12V/24V (DC 9V-40V)
- **Dimensions (L x W x H):** 29 cm x 5.2 cm x 18.7 cm (approx.)
- **Origin:** China

センターブラケット付き

モニターを1台のみ後席の中央に設置し、後席左右両側の乗客が同時に快適に画面を視聴できるようになっています。

30-50cm

センターブラケット

リアブラケット

Image: Diagram showing the dimensions of the Eonon L0328J monitor and its brackets.

8. WARRANTY AND SUPPORT

8.1 Warranty Information

Effective January 9, 2026, the warranty period for the Eonon L0328J product has been extended to **two years** for customers who purchase on or after this date.

For customers who purchased between October 1, 2025, and January 8, 2026, your warranty period will also be extended to two years as a special exception, demonstrating our commitment to product reliability.

For detailed information regarding your warranty, please contact our customer support.

8.2 Customer Support

For any inquiries, technical assistance, or warranty claims, please contact Eonon customer support through the official channels provided at the time of purchase or on the Eonon brand website. Please have your model number (L0328J) and purchase details ready when contacting support.