

Philips TAS1509

Philips S1509 Portable Bluetooth Speaker User Manual

Model: TAS1509

1. PRODUCT OVERVIEW

The Philips S1509 is a compact and portable Bluetooth speaker designed for both indoor and outdoor use. It features robust sound with extra bass, a long-lasting battery, and a durable, waterproof design.



Image: The Philips S1509 Portable Bluetooth Speaker, a compact black device with a textured grille and a red and black

Key Features:

- **Superior Sound:** Delivers rich and punchy bass with 10W maximum power and a 40mm full-range driver.
- **TWS Pairing:** Connect two identical S1509 speakers for 360° stereo sound.
- **Extended Playtime:** Up to 12 hours of continuous music playback on a single charge.
- **Hands-Free Calls:** Integrated microphone allows for clear hands-free communication.
- **IPX7 Waterproof:** Designed to withstand submersion in water up to 1 meter for 30 minutes, making it suitable for various environments.
- **Bluetooth 5.3:** Ensures fast pairing and a stable wireless connection.
- **Portable Design:** Small size and convenient carry strap for effortless portability.

2. WHAT'S IN THE BOX

Upon unpacking, ensure all items are present:

- Philips S1509 Portable Bluetooth Speaker
- Quick Install Guide
- Safety Warranty Sheet
- Carrying Strap
- USB Charging Cable (Type-C)

3. SETUP

3.1 Charging the Speaker

1. Locate the USB-C charging port on the speaker.
2. Connect the provided USB charging cable to the speaker and a compatible USB power source (e.g., wall adapter, computer USB port).
3. The charging indicator light will illuminate. A full charge takes approximately 2.5 hours.
4. Once fully charged, the indicator light will change or turn off, depending on the model.

A full charge provides up to 12 hours of playtime.




Image: The Philips S1509 speaker illustrating its 12-hour playtime and 2.5-hour charging time.

3.2 Powering On/Off

- To power on, press and hold the Power button until you hear an audible cue and the indicator light

illuminates.

- To power off, press and hold the Power button again until you hear an audible cue and the indicator light turns off.

3.3 Bluetooth Pairing

The Philips S1509 uses Bluetooth 5.3 for a stable and fast connection.

1. Ensure the speaker is powered on and in pairing mode (the Bluetooth indicator light will typically flash).
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "PHILIPS S1509" from the list of devices.
4. Once connected, you will hear an audible confirmation, and the Bluetooth indicator light will become solid.



Image: A person using a laptop outdoors with the Philips S1509 speaker, demonstrating Bluetooth 5.3 connectivity.

3.4 TWS (True Wireless Stereo) Pairing

For an enhanced audio experience, you can pair two identical Philips S1509 speakers together for stereo sound.

1. Ensure both S1509 speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be your primary speaker), press and hold the TWS pairing button (refer to the quick install guide for button location).
3. The primary speaker will search for the secondary speaker. Once connected, you will hear an audible confirmation.
4. Now, connect your device to the primary speaker via Bluetooth as described in section 3.3. Audio will play in stereo through both speakers.




Image: Two Philips S1509 speakers shown together, illustrating their ability to pair for stereo sound.

4. OPERATING THE SPEAKER

4.1 Basic Controls

- **Volume Up/Down:** Press the '+' or '-' buttons to adjust the volume.
- **Play/Pause:** Press the Play/Pause button to start or pause music playback.
- **Next/Previous Track:** Double-press the '+' button for the next track, and double-press the '-' button for the previous track.

4.2 Hands-Free Calling

The speaker features a built-in microphone for hands-free calls.

- **Answer Call:** Press the Play/Pause button once to answer an incoming call.
- **End Call:** Press the Play/Pause button once during a call to end it.
- **Reject Call:** Press and hold the Play/Pause button to reject an incoming call.




Image: The Philips S1509 speaker positioned beside a smartphone, indicating its hands-free calling capability.

4.3 Waterproof Functionality (IPX7)

The Philips S1509 is IPX7 rated, meaning it is protected against the effects of temporary immersion in water. It can be submerged in water up to 1 meter for 30 minutes.

- Ensure the charging port cover is securely closed before exposing the speaker to water.
- After exposure to water, wipe the speaker dry with a soft cloth before charging or opening the port cover.




Image: The Philips S1509 speaker partially submerged in water, highlighting its IPX7 waterproof feature.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Philips S1509 speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, damp cloth to clean the exterior of the speaker. Avoid using abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Exposure:** Always ensure the charging port cover is sealed when near water. After water exposure, dry the speaker thoroughly before charging.

- **Charging:** Use only the provided USB-C cable for charging. Avoid overcharging the battery.

6. TROUBLESHOOTING

If you encounter any issues with your Philips S1509 speaker, refer to the following common solutions:

- **No Power:** Ensure the speaker is fully charged. Connect it to a power source and check the charging indicator.
- **Cannot Pair Bluetooth:**
 - Ensure the speaker is in pairing mode (flashing Bluetooth indicator).
 - Check that Bluetooth is enabled on your device.
 - Move the speaker closer to your device.
 - Forget the speaker from your device's Bluetooth list and attempt to re-pair.
- **No Sound:**
 - Increase the volume on both the speaker and your connected device.
 - Ensure the speaker is properly paired via Bluetooth.
 - Check if the music is paused on your device.
- **Poor Sound Quality:**
 - Move the speaker closer to your device to avoid interference.
 - Ensure there are no obstructions between the speaker and your device.
 - Check the audio source quality.
- **TWS Pairing Failure:**
 - Ensure both speakers are S1509 models and are not connected to any other Bluetooth device.
 - Place the speakers close to each other during pairing.
 - Restart both speakers and try TWS pairing again.

7. SPECIFICATIONS

Feature	Specification
Model Name	TAS1509BK/37
Output Power	10 Watts (Max)
Speaker Size	40 Millimeters
Audio Driver Type	Dynamic Driver
Frequency Response	18 KHz
Connectivity Technology	Bluetooth 5.3
Battery Life	Up to 12 Hours
Battery Capacity	1500 Milliamp Hours

Feature	Specification
Charging Time	2.5 Hours
Water Resistance Rating	IPX7
Control Method	Touch Buttons
Product Dimensions	1.81"D x 4.09"W x 3.11"H
Item Weight	0.25 Kilograms (8.8 ounces)
UPC	840063205420

8. OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video from PHILIPS Sound showcasing the features and design of the S1509 Portable Bluetooth Speaker.

9. WARRANTY AND SUPPORT

The Philips S1509 Portable Bluetooth Speaker comes with a limited warranty. Please refer to the included Safety Warranty Sheet for detailed information regarding warranty terms, conditions, and registration procedures.

For technical support, product inquiries, or warranty claims, please visit the official Philips support website or contact their customer service. Contact information can typically be found in the Quick Install Guide or on the Philips brand website.