

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Relaxdays](#) /

› [Relaxdays Shoe Bench with Cushion and Storage, Model 10050464 - Instruction Manual](#)

Relaxdays 10050464

Relaxdays Shoe Bench with Cushion and Storage

Model: 10050464

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your new Relaxdays Shoe Bench with Cushion and Storage. Designed with an industrial style, this versatile bench offers comfortable seating and practical storage for your footwear and other items. Please read this manual thoroughly before assembly and use to ensure safe and correct operation.

SAFETY INSTRUCTIONS

- Always assemble the bench according to the provided instructions.
- Do not exceed the maximum load capacity of **155 kg (341 lbs)**.
- Ensure the bench is placed on a stable, level surface to prevent tipping.
- Keep the bench away from heat sources and avoid prolonged exposure to direct sunlight to maintain its longevity and material integrity.
- Do not allow children to climb on or play unsupervised with the bench, especially when the lid is open.

PACKAGE CONTENTS

Before beginning assembly, please verify that all components are present and undamaged. The package should contain:

- 1 x Shoe Bench (disassembled parts)
- Assembly hardware (screws, dowels, etc.)
- Assembly tools (if included, otherwise standard household tools may be required)

Decorative items shown in product images are not included.

SETUP AND ASSEMBLY

Assembly of the Relaxdays Shoe Bench requires careful attention to detail. Follow the step-by-step instructions provided in the separate assembly guide included with your product. Ensure all connections are secure before use.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify each part using the diagrams in the assembly guide.
3. Attach the side panels to the base and top sections using the provided hardware.
4. Insert the internal shelves into the designated slots.
5. Secure the back panel.
6. Attach the cushioned lid using the hinges, ensuring it opens and closes smoothly.
7. Place the bench in its desired location, ensuring it is stable and level.



Image: Detailed view of the bench's handle, hinges, and protective footpad. These components are crucial for assembly and long-term stability.

OPERATING INSTRUCTIONS

The Relaxdays Shoe Bench is designed for dual functionality: comfortable seating and organized storage.

Using the Seating Area

The padded top provides a comfortable surface for sitting while putting on or taking off shoes. Ensure the lid is fully closed and securely seated before using it as a bench.

Utilizing Storage Compartments

- **Open Shelves:** The three open compartments are ideal for storing 5 to 7 pairs of shoes or boots, keeping them organized and easily accessible. These can also be used for books, magazines, or decorative items.
- **Hidden Storage:** Lift the cushioned lid to access a spacious hidden compartment. This area is perfect for storing items like blankets, scarves, gloves, or other accessories, keeping your entryway tidy.



Image: The shoe bench with its cushioned lid open, showcasing the internal storage space. The open shelves below are filled with various pairs of shoes and books.



Image: An example of the shoe bench's storage capabilities, with clothing and a book in the hidden compartment, and shoes neatly arranged on the open shelves.

MAINTENANCE

Proper care will extend the life and appearance of your shoe bench.

- **Cleaning the Wood/MDF Surfaces:** Wipe with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish. Dry immediately with a clean cloth.
- **Cleaning the Cushion:** The polyurethane cushion can be wiped clean with a damp cloth and mild soap solution. Do not saturate the fabric. Allow to air dry completely.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary to maintain stability.
- **Environmental Conditions:** Avoid placing the bench in areas with extreme temperature fluctuations or high humidity, as this can affect the wood material.



Image: A hand demonstrating how to clean the black cushioned surface of the bench with a cloth, highlighting its easy-to-clean material.

TROUBLESHOOTING

If you encounter any issues with your shoe bench, refer to the following common solutions:

- **Bench feels wobbly:** Ensure all assembly screws are fully tightened. Check that the bench is on a flat, even surface. If the floor is uneven, consider using furniture pads to level it.
- **Lid does not close properly:** Verify that the hinges are correctly installed and aligned. Check for any obstructions in the storage compartment.
- **Scratches or minor damage:** For minor scratches on the wood finish, a furniture repair marker or wood stain pen matching the 'Burnt Wood' finish can be used.

SPECIFICATIONS

Model Number	10050464
Brand	Relaxdays
Overall Dimensions (H x W x D)	46 x 80 x 30 cm (18.1 x 31.5 x 11.8 inches)

Weight	11.26 kg (24.8 lbs)
Maximum Load Capacity	155 kg (341 lbs)
Material	MDF, Fiberboard, Polyurethane (cushion)
Frame Material	Metal
Color	Brown/Black
Style	Industrial
Number of Seating Places	1
Internal Storage (H x W x D)	Approx. 9 x 77.5 x 27 cm
Left Compartments (H x W x D)	Approx. 13.5 x 51 x 29 cm (each)
Right Compartment (H x W x D)	Approx. 28.5 x 25.5 x 29 cm



Image: Dimensional drawing of the shoe bench, illustrating its overall height, width, and depth, as well as the specific measurements of its internal and external storage compartments.

Relaxdays products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Relaxdays website. If you require assistance with assembly, missing parts, or have any questions about your product, please contact Relaxdays customer support through their official channels.