

## Country Living CL-FS-696-5

# Country Living Infrared Freestanding Electric Fireplace Stove Heater

Model: CL-FS-696-5

## INTRODUCTION

---

This manual provides essential information for the safe and efficient operation of your Country Living Infrared Freestanding Electric Fireplace Stove Heater. Please read all instructions carefully before assembly, operation, or maintenance. Retain this manual for future reference.

The Country Living Electric Fireplace Stove Heater offers a realistic 3D flame effect with multiple flame colors and brightness levels, providing ambiance with or without heat. It features an infrared heating element capable of heating up to 1000 sq ft, and can be controlled via a multi-functional remote, Wi-Fi app, or voice commands through Alexa.

## SETUP

---

Your electric fireplace is designed for easy assembly. Follow these steps to set up your unit:

1. Carefully unpack all components from the packaging. Ensure all parts are present: main fireplace unit, 4 legs, and door handle.
2. Attach the 4 legs to the bottom of the main fireplace unit. Ensure they are securely fastened.
3. Attach the door handle to the fireplace door.
4. Place the assembled fireplace on a stable, level surface. Ensure there is adequate clearance from combustible materials as per safety guidelines.
5. Plug the power cord into a grounded 120V AC outlet.



Figure 1: The fireplace with its door open, showing the internal controls and faux logs. Assembly involves attaching the legs and door handle.

## OPERATING INSTRUCTIONS

Your Country Living Electric Fireplace offers multiple ways to control its functions:

### 1. Remote Control Operation

The included multi-functional remote control allows for convenient adjustment of settings from a distance.

- **Power On/Off:** Press the power button to turn the unit on or off.
- **Temperature Control:** Use the temperature buttons to adjust the desired heat output (68°F - 88°F).
- **Flame Colors:** Cycle through 3 flame colors (yellow, blue, orange-blue).
- **Flame Brightness:** Adjust the flame brightness with 5 available levels.
- **Timer:** Set a timer for automatic shut-off.



Figure 2: The remote control and smartphone app interface for controlling the fireplace.

## 2. Wi-Fi App & Voice Control

For enhanced convenience, connect your fireplace to the dedicated Wi-Fi app and integrate with voice assistants like Alexa.

- Download the Country Living Fireplace App from your device's app store.
- Follow the in-app instructions to connect your fireplace to your home Wi-Fi network.
- Once connected, you can control all functions (temperature, flame settings, timer, power) directly from your smartphone.
- Enable the Country Living skill in your Alexa app to use voice commands (e.g., "Alexa, turn on the fireplace").

## 3. Heat Functionality

The infrared heater provides supplemental heat for areas up to 1000 sq ft.

- The heater can be used independently of the flame effect.
- Adjust the thermostat to maintain your desired room temperature.
- For ambiance without heat, select the flame-only mode.



Figure 3: The fireplace's heating capability, providing warmth for up to 1000 sq ft.

## MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your electric fireplace.

- **Cleaning:** Ensure the unit is unplugged and cool before cleaning. Use a soft, damp cloth to wipe down the exterior surfaces. Do not use abrasive cleaners or sprays.
- **Air Intake/Outlet:** Periodically check and clean the air intake and outlet vents to prevent dust buildup, which can affect heating efficiency. Use a vacuum cleaner with a brush attachment if necessary.
- **Storage:** If storing the unit for an extended period, unplug it and store it in a dry, cool location, preferably in its original packaging.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not turn on.	No power, tripped circuit breaker, loose connection.	Check power outlet, reset circuit breaker, ensure power cord is securely plugged in.
No heat output.	Heat function not activated, thermostat set too low, air vents blocked.	Activate heat function via remote/app, increase thermostat setting, clear any obstructions from vents.
Flame effect not working.	Flame effect not activated, internal light issue.	Ensure flame effect is turned on. If issue persists, contact customer support.
Remote control not responding.	Dead batteries, obstruction, remote out of range.	Replace batteries (2 AAA included), remove obstructions, ensure remote is within operating range.

## SPECIFICATIONS

Feature	Detail
Brand	Country Living
Model Name	CL-FS-696-5
Product Dimensions	13"D x 24"W x 23.5"H
Item Weight	31.8 Pounds
Material	Metal
Finish Type	Painted
Installation Type	Freestanding
Power Source	AC
Special Features	Digital Thermostat, WiFi App, Alexa, Flame Customization Technology, Corded, Multi-Function Remote
Heating Coverage	1000 sq ft
Included Components	Legs, Door Handle, Remote Control
Batteries Required	2 AAA (included)

Feature	Detail
UPC	810175870007



Figure 4: Product dimensions for the Country Living Electric Fireplace.

## WARRANTY INFORMATION

This product comes with a Limited Warranty. For specific terms and conditions, please refer to the warranty card included with your purchase or contact Country Living customer support.

## CUSTOMER SUPPORT

For any questions, technical assistance, or warranty claims, please contact Country Living customer support. You can find more information and contact details on the official Country Living website or through the retailer where you purchased the product.

Visit the official [Country Living Store on Amazon](#) for additional product information and support resources.