



[Manuals.plus](#) /

› [Riflevault](#) /

› Riflevault 15-20 Fingerprint Gun Safe User Manual (Model AKG5-132W)

## Riflevault AKG5-132W

# Riflevault 15-20 Fingerprint Gun Safe User Manual

Model: AKG5-132W

## 1. INTRODUCTION

---

This manual provides detailed instructions for the assembly, operation, and maintenance of your Riflevault 15-20 Fingerprint Gun Safe. Please read this manual thoroughly before assembly and use to ensure proper function and safety. Keep this manual for future reference.



Image: The Riflevault 15-20 Fingerprint Gun Safe, displaying its exterior with the biometric lock and its interior with organized firearm and accessory storage.

## 2. IMPORTANT SAFETY INFORMATION

---

- Always store firearms unloaded and locked.
- Keep keys and access codes in a secure location, away from the safe and out of reach of unauthorized individuals, especially children.
- Do not store the emergency keys inside the safe.
- Ensure the safe is securely mounted to a wall or floor to prevent tipping or unauthorized removal.
- Regularly check the battery level and replace batteries as needed to ensure continuous operation of the electronic lock.

## 3. PACKAGE CONTENTS

---

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, contact customer service immediately.

- 1 x Large Unassembled Gun Safe (various panels)
- 1 x User Manual
- 2 x Emergency Keys
- 3 x Gun Racks
- 1 x Magnetic Light
- 4 x Expansion Screws
- 1 x USB Type-C Cable
- Assembly Screws (B Screw, C Screw)
- 1 x Screwdriver



Image: Visual representation of the accessories included with the Riflevault gun safe, such as keys, gun racks, magnetic light, and various screws.

## 4. ASSEMBLY INSTRUCTIONS

---

The Riflevault gun safe is shipped unassembled. Follow these steps carefully for proper assembly. An electric drill may expedite the process.

1. **Left Plate Installation:** Attach the left side panel.
2. **Right Plate Installation:** Attach the right side panel.
3. **Door Installation:** Secure the door to the main frame.
4. **Top Plate Installation:** Install the top panel.
5. **Fix the Bottom Plate:** Secure the bottom panel.
6. **Middle Vertical Plate Installation:** Insert the central vertical divider.
7. **Small Dividers Installation:** Place the smaller internal dividers.
8. **Compartment Dividers Installation:** Install the remaining compartment dividers and shelves.



Image: Visual guide detailing the 8 steps for assembling the Riflevault gun safe, showing how each panel and divider fits together.

## 5. INSTALLATION AND MOUNTING

---

For enhanced security, it is recommended to mount the safe to a wall or floor using the provided expansion screws.

1. **Step 1:** Choose a suitable location for mounting.
2. **Step 2:** Mark the drilling points on the wall or floor through the pre-drilled holes in the safe.
3. **Step 3:** Drill pilot holes and insert the expansion screws, securing the safe firmly in place.



Image: A three-step diagram illustrating the process of wall mounting the gun safe for added security.

## 6. OPERATING INSTRUCTIONS

---

### 6.1 Unlocking Methods

The Riflevault gun safe offers four methods for access:

1. **Fingerprint + Knob:** For daily use, quick biometric access.
2. **Password + Knob:** For daily use, electronic keypad access.
3. **Key + Knob:** Emergency access if password is forgotten or batteries are depleted.
4. **USB Type-C Cable + Password/Fingerprint + Knob:** Emergency power supply if batteries are depleted, allowing

electronic access.




Image: A visual guide illustrating the four distinct methods to unlock the Riflevault gun safe, including biometric, keypad, key, and emergency power options.

## 6.2 Setting Up Fingerprints and Passwords

Refer to the specific instructions provided on the keypad unit for programming fingerprints (up to 20) and a 3-12 digit password. Typically, this involves pressing a program button, entering the desired code/scanning the fingerprint, and confirming.



Image: Detailed view of the biometric keypad, highlighting its components such as the LCD screen, fingerprint collector, and emergency power port.

## 6.3 Mute Function

The safe features a mute function to silence operational sounds. Activate this function if silent access is preferred.

## 6.4 Dual Alarm System

The safe is equipped with a dual alarm system that activates under specific conditions:

- After 3 consecutive incorrect fingerprint entries.
- After 5 consecutive incorrect password entries.
- Upon detection of violent vibrations or tampering.

The alarm emits a 70-decibel sound for 30 seconds and can be deactivated by entering the correct password.



Image: Illustration of the dual alarm system, showing an alarm activating during an attempted break-in and the silent mode for discreet operation.

## 6.5 LED Light

The safe includes a backlit keypad for visibility in low light and an automatic internal LED light that illuminates upon opening. A magnetic LED light is also provided for additional convenience.

## 7. STORAGE CONFIGURATION

The safe features a detailed compartment layout designed for efficient organization of firearms and accessories. It includes three adjustable gun racks and three removable and adjustable shelves on the left side, allowing customization of storage space.

- The top shelf has special slots for long guns, eliminating the need to remove the shelf for storage.
- The external hinge design allows the door to open 180 degrees for full access.




Image: The interior of the safe demonstrating the removable and adjustable features, including shelves and gun racks, for flexible storage.




Image: Close-up details of the safe's interior, highlighting features like removable shelves, gun racks, magnetic lamp, pistol pouches, and magazine storage.

## 8. MAINTENANCE

- **Battery Replacement:** The electronic lock requires batteries for operation. Replace batteries when the low battery alert is indicated. Use the USB Type-C cable for emergency power if batteries are fully depleted before replacement.
- **Cleaning:** Clean the exterior and interior of the safe with a soft, dry cloth. Avoid abrasive cleaners or solvents that could damage the finish or electronic components.
- **Lock Mechanism:** Periodically check the lock mechanism for any obstructions or signs of wear. Do not lubricate the lock mechanism unless specifically instructed by the manufacturer.

## 9. TROUBLESHOOTING


Problem	Possible Cause	Solution
Safe does not open with fingerprint/password.	Low battery, incorrect entry, fingerprint not registered.	Replace batteries, re-enter code/fingerprint, use emergency key or USB-C power. Re-register fingerprint if needed.
Alarm activates unexpectedly.	Incorrect entries, violent vibration.	Enter correct password to disarm. Avoid moving the safe violently.
Keypad not responding.	Dead batteries.	Use emergency key or connect USB Type-C cable for external power. Replace batteries.
Assembly difficulties (parts not aligning).	Incorrect orientation of panels, manufacturing tolerance.	Review assembly diagrams carefully. Ensure panels are oriented correctly. Apply gentle force or contact customer service if parts are bent.

## 10. SPECIFICATIONS

- **Brand:** Riflevault
- **Model:** AKG5-132W
- **External Dimensions:** 17.72"D x 22.83"W x 51.96"H

- **Lock Type:** Biometric, Electronic, Key
- **Color:** Black
- **Material:** Alloy Steel
- **Special Features:** Adjustable Gun Rack, Adjustable Shelf, Heavy Duty Construction, Lockable
- **Mounting Type:** Floor Mount (Wall mounting also supported)
- **Item Weight:** Approximately 86 pounds
- **Capacity:** Designed to fit 10-20 rifles up to 50 inches tall.

## SUITABLE FOR VARIOUS SCENARIOS



Bedroom



Living room



Office



Garage

Image: A diagram illustrating the external dimensions (depth, width, height) of the Riflevault gun safe.

## 11. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Riflevault customer service. The manufacturer provides 24/7 customer service to assist with assembly or operational questions.

**Contact Information:** Refer to your purchase receipt or the Riflevault official website for the most current customer service contact details.

