Manuals+

Q & A | Deep Search | Upload

GNMN G17

GNMN G17 Wireless Earbuds User Manual

Model: G17 | Brand: GNMN

INTRODUCTION

Thank you for choosing the GNMN G17 Wireless Earbuds. These Bluetooth headphones are designed for an immersive audio experience with exceptional comfort and durability, perfect for sports, travel, and daily entertainment. Featuring a long-lasting battery, crystal-clear calls, and IPX7 waterproofing, the G17 earbuds are built to enhance your active lifestyle. This manual provides detailed instructions to help you get the most out of your new earbuds.



Image: GNMN G17 Wireless Earbuds in their charging case, showcasing the sleek black design and compact form factor.

WHAT'S IN THE BOX

Your GNMN G17 package includes the following items:

- Wireless Earbuds (Left and Right)
- Wireless Charging Case
- USB-C Charging Cable

- S/M/L Eartips (Small, Medium, Large sizes for customizable fit)
- User Manual



Image: A visual representation of the GNMN G17 package contents, including the earbuds, charging case, USB-C cable, and various eartips.

SETUP

Charging the Earbuds and Case

Before first use, fully charge your earbuds and charging case. The case supports both USB-C wired charging and wireless charging. The dual LED digital display on the case shows the remaining battery percentage of the case and the charging status of each earbud (L for Left, R for Right).

- Wired Charging: Connect the provided USB-C cable to the charging port on the case and plug the other end into a compatible USB power source.
- Wireless Charging: Place the charging case on a compatible wireless charging pad (not included).

A full charge provides up to 8 hours of playtime for the earbuds, and the charging case extends total playback to an impressive 90 hours.



Image: The GNMN G17 charging case being charged via USB-C cable and wirelessly on a charging pad, illustrating both charging methods.



Image: Close-up of the GNMN G17 charging case displaying the battery percentage and individual earbud charge levels on its dual LED screen.

Pairing with Your Device

The GNMN G17 earbuds utilize advanced Bluetooth 5.3 technology for fast and stable connections.

- 1. Initial Pairing: Open the charging case. The earbuds will automatically power on and enter pairing mode.
- 2. **Connect:** On your device (smartphone, tablet, laptop, etc.), go to Bluetooth settings and select "G17" from the list of available devices.
- 3. **Automatic Reconnection:** After the first successful connection, the earbuds will automatically connect to your device when removed from the charging case.



Image: A smartphone screen showing "G17" as a discoverable Bluetooth device, illustrating the simple one-step pairing process.

Your browser does not support the video tag.

Video: An official product video demonstrating the features of the GNMN Bluetooth Headphones, including their quick pairing and connectivity.

OPERATING THE EARBUDS

Wearing Your Earbuds

The G17 earbuds are designed with flexible ear hooks and come with S/M/L silicone ear tips to ensure a secure and comfortable fit for various ear shapes, especially during active use.

- 1. Choose Eartips: Select the ear tips that best fit your ear canal for optimal sound and comfort.
- 2. **Position Earhook:** Place the earbud into your ear and gently loop the flexible ear hook over the top of your ear.
- 3. Adjust: Rotate and adjust the earbud and ear hook until you achieve a comfortable and secure fit.




Image: A person wearing the GNMN G17 earbuds, highlighting the flexible earhooks and the different sizes of silicone eartips for a secure and comfortable fit.



Image: A close-up of a person wearing one of the GNMN G17 earbuds, demonstrating how the earhook secures the earbud during movement.

Button Controls

The G17 earbuds feature intuitive button controls for easy management of audio playback and calls, providing more precise control than sensitive touch designs.

- Play/Pause: Single press the button on either earbud.
- Volume Up/Down: Specific button presses (refer to detailed manual for exact sequence).
- Next/Previous Track: Specific button presses (refer to detailed manual for exact sequence).
- Answer/End Call: Single press the button during an incoming call.
- Reject Call: Press and hold the button during an incoming call.
- Activate Voice Assistant: Specific button presses (refer to detailed manual for exact sequence).



Image: A detailed view of the GNMN G17 earbud, highlighting the physical button control for easy operation and its internal components for Hi-Fi sound.

MAINTENANCE

To ensure the longevity and optimal performance of your GNMN G17 Wireless Earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging points with a soft, dry cloth. If necessary, use a slightly damp cloth for the exterior, but ensure no moisture enters the charging ports or speaker grilles.
- **Drying:** After using the earbuds during exercise or in wet conditions, ensure they are completely dry before placing them back into the charging case. This prevents corrosion and damage to the charging contacts.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust, dirt, and physical damage. Store the case in a cool, dry place away from extreme temperatures.
- Avoid Overcharging: While the earbuds have built-in protection, it's good practice to disconnect them from the charger once fully charged to prolong battery life.

The IPX7 waterproof rating means the earbuds can withstand submersion in up to 1 meter of water for 30 minutes, making them

resistant to sweat and rain. However, the charging case is not waterproof.



Image: A close-up of the GNMN G17 earbud with water droplets, illustrating its IPX7 water resistance for active use.

TROUBLESHOOTING

If you encounter any issues with your GNMN G17 Wireless Earbuds, please refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Earbuds not pairing/connecting	Bluetooth off, out of range, earbuds not in pairing mode, previous connection issue.	Ensure Bluetooth is on. Place earbuds closer to device. Open case to activate pairing. Forget device in Bluetooth settings and re-pair.
Only one earbud working	Low battery, pairing issue, earbud not properly seated in case.	Charge both earbuds fully. Place both earbuds in case, close, then open to reset. Re-pair if necessary.
No sound or low volume	Volume too low on device/earbuds, improper fit, dirty speaker grilles.	Increase volume on both device and earbuds. Adjust fit or try different eartips. Gently clean speaker grilles.
Charging case not charging	Faulty cable/adapter, improper connection, wireless charging misalignment.	Try a different USB-C cable and power adapter. Ensure cable is firmly connected. Adjust case position on wireless charger.
Sound quality is poor (e.g., tinny, no bass)	Improper fit, low quality audio source, earbud placement.	Ensure a snug fit with appropriate eartips. Try a different audio source. Adjust earbud position in ear.

SPECIFICATIONS

Detailed technical specifications for the GNMN G17 Wireless Earbuds:

Feature	Specification
Model Name	G17
Connectivity Technology	Wireless (Bluetooth)

Feature	Specification
Wireless Communication Technology	Bluetooth 5.3
Bluetooth Range	33 Feet
Ear Placement	Over Ear
Form Factor	Over Ear
Battery Life (Earbuds)	8 Hours (per charge)
Total Playback (with Case)	Up to 90 Hours
Charging Time	1.5 Hours
Water Resistance Level	IPX7 Water Resistant
Control Type	Button Control
Audio Driver Type	Dynamic Driver (13mm dual-chamber)
Noise Control	Sound Isolation
Material	Plastic
Item Weight	4.6 Grams (each earbud)
Product Dimensions	2.05 x 1.22 x 2.28 inches (case)

WARRANTY & SUPPORT

GNMN is committed to providing high-quality products and excellent customer service. Your GNMN G17 Wireless Earbuds may come with a lifetime warranty, offering permanent replacement for damaged, defective, upgraded, or lost products. You typically do not need to return the original item for warranty claims.

To activate your warranty and for any support inquiries, please refer to the information provided in your product packaging or visit the official GNMN website. It is recommended to activate your warranty within 14 days of purchase.

Your browser does not support the video tag.

Video: An official GNMN Direct video showcasing the G17 Bluetooth 5.3 Headphones with Wireless Charging Case, highlighting key features and product quality.


© 2025 GNMN. All rights reserved.

Related Documents



GNMN V7 Sports Wireless Headphones User Manual and Specifications

Official user manual for GNMN V7 Sports Wireless Headphones. Includes setup, charging, pairing, operations, troubleshooting, and Android volume sync guide. Features Bluetooth V5.3, 8-hour music time, and 50mAh battery.



Documents - GNMN - G17



GNM G17 Wireless Earbuds User Manual

Comprehensive user manual for GNM G17 wireless earbuds, covering product overview, charging, Bluetooth pairing, multi-function operations, and troubleshooting tips.

lang: score:26 filesize: 4.36 M page_count: 6 document date: 2023-06-15



GNMN G17 True Wireless Earbuds User Manual and Specifications

Discover the GNMN G17 True Wireless Earbuds with this comprehensive user manual. Learn about features, specifications, charging, pairing, multi-function controls, and troubleshooting for optimal audio experience.

lang: score:24 filesize: 4.39 M page_count: 6 document date: 2023-11-16