

[Manuals.plus](#) /

› [KALPADIVES](#) /

› KALPADIVES Pagani Design PD1654 Quartz Watch User Manual

KALPADIVES PD-1654

KALPADIVES Pagani Design PD1654 Quartz Watch User Manual

INTRODUCTION

This manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your Pagani Design PD1654 Quartz Watch. Please read this manual thoroughly to ensure proper use and care of your timepiece.



Image: The Pagani Design PD1654 watch worn on a wrist, highlighting its elegant design.

SETUP AND INITIAL USE

Unpacking

Carefully remove the watch from its packaging. Inspect the watch for any visible damage. The watch should arrive with the crown in the pulled-out position to conserve battery life during shipping.

Setting the Time

1. Pull the crown (A) out to position 2.
2. Turn the crown (A) clockwise or counter-clockwise to set the hour and minute hands to the desired time.
3. Push the crown (A) back into position 0 to start the watch.

Setting the Date

1. Pull the crown (A) out to position 1.

2. Turn the crown (A) clockwise or counter-clockwise to set the date.
3. Once the correct date is displayed, push the crown (A) back into position 0.



Image: Side view of the watch, illustrating the crown for time and date adjustments.

Adjusting the Strap

The watch features a leather strap with a buckle closure. Adjust the buckle to a comfortable fit on your wrist. Ensure the watch is snug but not overly tight to allow for proper circulation.



Image: The watch with its leather strap unbuckled, ready for adjustment.

OPERATION

Timekeeping

Your Pagani Design PD1654 watch is equipped with a reliable Japan VH65 quartz movement, providing accurate timekeeping. Once the time is set, the watch will operate continuously until the battery requires replacement.

Date Display

The watch features a date display function. The date will advance automatically every 24 hours. If the date changes during the day, you may need to adjust the time by 12 hours (see "Setting the Time" section).



Image: Detailed view of the watch dial, highlighting the date display.

Water Resistance

This watch is rated as "Waterproof" (Water Resistance Level: Waterproof). While it is designed to withstand splashes and brief immersion, it is not suitable for diving or prolonged water activities. Avoid operating the crown while the watch is wet to prevent water ingress.

CARE AND MAINTENANCE

Cleaning

Wipe the watch case and crystal regularly with a soft, dry cloth. For the leather strap, use a slightly damp cloth and allow it to air dry. Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish or strap.

Battery Replacement

The quartz movement is powered by a battery. When the watch stops or the second hand begins to skip, the

battery likely needs replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance seal is maintained.

Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight and extreme temperatures. Keeping it in its original box or a watch case can help protect it from dust and scratches.

Water Resistance Care

To maintain the water resistance of your watch, ensure the crown is always fully pushed in. Avoid exposing the watch to hot water, steam, or sudden temperature changes, as these can compromise the seals. Have the water resistance seals checked periodically by a professional, especially after battery replacement.

TROUBLESHOOTING

Watch Not Running

- Check if the crown is fully pushed into position 0.
- If the crown is correctly positioned and the watch is still not running, the battery may need replacement.

Date Not Changing Correctly

- Ensure the time is set correctly, especially the AM/PM cycle. If the date changes at noon instead of midnight, advance the time by 12 hours.
- Manually adjust the date using the crown (see "Setting the Date" section).

Condensation Inside Crystal

If you notice condensation inside the watch crystal, this indicates that moisture has entered the watch. Immediately take the watch to a qualified technician for inspection and repair to prevent further damage to the movement.

PRODUCT SPECIFICATIONS

Feature	Specification
Model Number	PD-1654
Movement Type	Japan VH65 Quartz
Case Material	Stainless Steel
Case Diameter	40 mm
Case Thickness	11 mm
Strap Material	Leather
Band Width	20 mm

Feature	Specification
Band Length	240 mm
Dial Window Material	Hard Coated Glass
Display Type	Analog
Water Resistance	Waterproof (10 BAR / 100 M)

Model: PD-1654

Style: Male

-  Case Thickness: 11MM
-  Dial Diameter: 40MM
-  Weight.: 49G
-  Band Length: 240MM
-  Movement: Japan Seiko VH65
-  Band Width: 20MM
-  Band Material :Genuine leather
-  Dial Window Material Type: Hard coated glass
-  Original gift box, User manual warranty card and original watch

Note: This data is only store measurement data, There is an error (size ± 1 MM, weight ± 2 G)



Ca: 40MM

Strap width: 20MM

Image: Visual representation of the watch with key specifications.

WARRANTY INFORMATION

Your Pagani Design PD1654 watch comes with a 12-month after-sale service warranty. Additionally, a 30-day refund policy is available for returns without reason. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For further assistance, inquiries, or to learn more about Pagani Design watches, please contact us through the Amazon platform where you made your purchase. Our customer service team is available to help.