

- Manuals.plus /
- › AMICLIBER /
- › AMICLIBER Rectangular Dining Table Set with 4 Chairs (Model DT-0001-GY) - Instruction Manual

AMICLIBER DT-0001-GY

AMICLIBER Rectangular Dining Table Set with 4 Chairs

Model: DT-0001-GY | Color: Retro Grey

INTRODUCTION

Thank you for choosing the AMICLIBER Rectangular Dining Table Set. This manual provides essential information for the safe assembly, proper use, and maintenance of your new dining set. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: The AMICLIBER dining table set, featuring a retro grey tabletop and black metal frames, comfortably seating four.

SAFETY INFORMATION

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all screws and bolts are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand on the table or chairs.
- Keep small parts away from children during assembly to avoid choking hazards.
- Distribute weight evenly on the table surface.
- Avoid placing hot items directly on the tabletop without protection.
- The table has a maximum load capacity of 220 pounds. Each chair can support up to 330 pounds. Do not exceed these limits.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- 1 x Rectangular Tabletop
- 4 x Table Legs
- 2 x Table Support Frames
- 4 x Chair Backrests
- 4 x Chair Seats
- 4 x Chair Front Leg Assemblies
- 4 x Chair Rear Leg Assemblies
- Hardware Pack (screws, washers, Allen wrench)

ASSEMBLY INSTRUCTIONS (SETUP)

Follow these steps carefully for proper assembly. It is recommended to have two people for table assembly.

Table Assembly

1. Attach the table legs to the table support frames using the provided screws and Allen wrench. Do not fully tighten yet.
2. Align the assembled leg and frame structure with the tabletop.
3. Securely attach the tabletop to the frame using the remaining screws.
4. Once all connections are made, fully tighten all screws.

Chair Assembly

1. Connect the chair backrest to the rear leg assembly using screws.
2. Attach the front leg assembly to the chair seat.
3. Connect the assembled backrest/rear legs to the seat/front legs using the remaining screws.
4. Ensure all connections are secure and fully tighten all screws. Repeat for all four chairs.



Image: Detailed assembly diagram illustrating the steps for constructing the dining table and chairs.

USAGE AND FEATURES

This dining set is designed for versatility and comfort in various settings.

- **Space-Saving Design:** The chairs are specifically designed to tuck neatly under the table when not in use, optimizing space in smaller rooms.
- **Sturdy Construction:** Both the table and chairs feature robust metal legs and thick, durable surfaces, ensuring stability and longevity. The table supports up to 220 lbs, and each chair up to 330 lbs.
- **Comfortable Seating:** Chairs are ergonomically designed with a reclining backrest for optimal support during prolonged sitting.
- **Safety Features:** All corners of the table are rounded to minimize the risk of accidental injuries. Chairs are equipped with non-slip foot pads for enhanced stability.

Space-saving Design

You can store the dining chairs under the table when not in use




Image: The dining set showcasing its space-saving capability, with chairs stored compactly under the table.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your dining set, follow these care instructions:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. For stubborn stains, use a mild soap solution and dry immediately. Avoid

harsh chemicals or abrasive cleaners.

- **Spills:** Clean spills immediately to prevent staining, especially on the tabletop. The tabletop is waterproof, but prolonged exposure to liquids should be avoided.
- **Heat Protection:** Always use placemats or coasters under hot dishes to protect the tabletop surface.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or damage to the finish.
- **Regular Checks:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary.



Image: Demonstrating the easy-to-clean surface of the dining table.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Wobbly Table/Chairs:** Ensure all screws are fully tightened. If the issue persists, loosen all screws slightly, press down firmly on the wobbly part to level it, then re-tighten all screws. Check that the non-slip foot pads are intact and evenly placed.
- **Difficulty Aligning Parts:** Do not fully tighten screws until all parts are loosely assembled. This allows for minor adjustments. If parts still don't align, double-check the assembly diagram to ensure components are oriented correctly.
- **Scratches on Surface:** Minor scratches can sometimes be minimized with furniture polish or a touch-up pen matching the finish. For deeper scratches, professional repair may be needed.

SPECIFICATIONS

Feature	Detail
Brand	AMICLIBER
Model Number	DT-0001-GY
Color	Retro Grey
Material	Metal, Wood (MDF with PVC Veneer)
Table Dimensions (L x W x H)	43.3 x 26.8 x 29.3 inches
Chair Dimensions (L x W x H)	16.1 x 14.6 x 34.3 inches

Feature	Detail
Seat Height	17 inches
Item Weight	53 pounds
Table Load Capacity	Up to 220 pounds
Chair Load Capacity (each)	Up to 330 pounds



Scratch-Resistant



Waterproof



Easy to Clean



MDF Board

43.3"X26.8"Spacious Tabletop

Provides a comfy dining area for you and your family

Image: Detailed dimensions of the dining table and chairs.

WARRANTY AND SUPPORT

AMICLIBER products are designed for quality and durability. For specific warranty information, please refer to the documentation included with your purchase or contact our customer support.

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact

AMICLIBER customer service through the retailer's platform or our official website. Please have your model number (DT-0001-GY) and purchase date ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DSP59H6G>

More documents and user manuals: <https://manuals.plus/>