Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EMBATHER EMTJ068

EMBATHER Filtered Handheld Shower Head User Manual

Model: EMTJ068 | Brand: EMBATHER

Introduction

Thank you for choosing the EMBATHER Filtered Handheld Shower Head. This product is designed to enhance your showering experience by providing filtered water and versatile spray options. It features advanced filtration to reduce chlorine and other impurities, and offers 9 adjustable spray modes for personalized comfort. This manual provides detailed instructions for installation, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your shower head.



Image: The EMBATHER Filtered Handheld Shower Head, showcasing its design and the visible filter cartridge.

Package Contents

Please verify that all components are present before proceeding with installation:

- Handheld Shower Head
- Filter Cartridges (4 total, including one pre-installed)
- 59-inch Stainless Steel Shower Hose

- Adjustable Mounting Bracket
- Teflon Tape
- Removable Flow Restrictor
- Rubber Washer Set
- User Manual



Image: A visual representation of all items included in the package: shower head, filter cartridges, hose, bracket, Teflon tape, flow restrictor, washers, and user manual.

Setup and Installation

Installation of the EMBATHER Filtered Handheld Shower Head is designed to be straightforward and does not require specialized plumbing skills. Follow these steps for a secure and leak-free setup.

1. **Prepare Your Shower Area:** Ensure the main water supply to your shower is turned off. Remove your existing shower head and hose from the shower arm. You may need pliers for this step.

2. **Apply Teflon Tape:** Wrap the included Teflon tape clockwise around the threads of your shower arm 3-5 times. This helps create a watertight seal and prevents leaks.
3. **Install Adjustable Mounting Bracket:** Screw the adjustable mounting bracket onto the shower arm. Hand-tighten first, then use a wrench to gently tighten until secure. Do not overtighten.
4. **Connect Shower Hose:**
    - Connect the conical nut end of the 59-inch stainless steel shower hose to the adjustable mounting bracket. Ensure a rubber washer is inside the nut.
    - Connect the hexagonal nut end of the shower hose to the handheld shower head. Ensure a rubber washer is inside this nut as well.

    Hand-tighten both connections, then use a wrench for a final gentle tightening.
5. **Insert Filter Cartridge:** The shower head comes with one filter cartridge pre-installed. If you need to replace it or verify its presence, unscrew the handle of the shower head and insert a filter cartridge. Ensure it is seated correctly.
6. **Optional: Install Flow Restrictor:** A removable flow restrictor is included. If you desire higher water pressure and your local regulations permit, you may choose not to install it or remove it from the shower head's connection point. Refer to the diagram in the package for its location.
7. **Test for Leaks:** Turn on the main water supply and check all connections for leaks. If any leaks occur, tighten the connections slightly or reapply Teflon tape.



Image: The 360-degree adjustable shower holder, illustrating its universal G1/2" thread for easy installation.



Image: The 59-inch stainless steel shower hose, highlighting its flexibility and durable construction.

Operating Instructions

Your EMBATHER Filtered Handheld Shower Head offers a variety of spray modes and a powerful cleaning function for a customized showering and cleaning experience.

Adjusting Spray Modes

The shower head features 9 distinct spray modes. To switch between modes, rotate the water mode selector switch located on the shower head's face. Each click will change the spray pattern.

- **Rain Mode:** A gentle, full-coverage spray.
- **Massage Mode:** A focused, pulsating spray for muscle relief.
- **Mist Mode:** A fine, soft mist.
- Combinations of Rain, Massage, and Mist modes are also available.
- **Pause Mode:** Temporarily reduces water flow to a trickle, useful for lathering or shaving without changing temperature settings.



Image: Visual guide to the 9 adjustable spray modes, including Rain, Massage, Mist, and their combinations, along with the Pause mode.

Using the Gun Mode (Power Wash)

For quick rinsing or targeted cleaning, press the button on the back of the shower head to activate the powerful "Gun Mode" spray. Press again to deactivate.

- Ideal for cleaning bathtubs, tiles, toilets, and floor drains.
- Provides a strong, concentrated stream of water.



Image: The "Gun Mode" in action, illustrating its use for cleaning a toilet, floor drain, bathroom floor, and bathtub.

Maintenance

Regular maintenance ensures the continued performance and effectiveness of your EMBATHER Filtered Handheld Shower Head.

Filter Cartridge Replacement

The filter cartridges are crucial for water purification. Replace them regularly to maintain optimal filtration.

- **Replacement Frequency:** Replace the filter cartridge every 3-4 months, or more frequently depending on your local water quality and usage.
- **Replacement Process:**
    a. Turn off the water supply to the shower.
    b. Unscrew the handle of the handheld shower head.
    c. Remove the old filter cartridge.

d. Insert a new filter cartridge, ensuring it is properly seated.
e. Screw the handle back onto the shower head until secure.
f. Turn on the water supply and check for leaks.



Image: Illustration of the replaceable filter cartridges, their components, and recommended replacement schedule.

Cleaning the Shower Head Nozzles

The shower head features self-cleaning silicone nozzles. If mineral deposits or dirt accumulate, gently rub the silicone nozzles with your finger or a soft brush to dislodge them. For stubborn buildup, a mild descaling solution can be used, followed by thorough rinsing.

Troubleshooting

Refer to this section for solutions to common issues you might encounter.

Problem	Possible Cause	Solution
Low Water Pressure	• Flow restrictor installed. • Clogged nozzles. • Clogged filter cartridge.	• Remove the flow restrictor (if permitted by local regulations). • Clean silicone nozzles by gently rubbing them. • Replace the filter cartridge.
Water Leaks from Connections	• Loose connections. • Insufficient Teflon tape. • Missing or damaged rubber washers.	• Tighten all connections. • Reapply Teflon tape to threaded connections. • Ensure rubber washers are correctly seated in hose nuts.
Filter Not Working Effectively	• Expired filter cartridge. • Incorrect filter installation.	• Replace the filter cartridge (every 3-4 months). • Ensure the filter cartridge is correctly seated in the handle.

Specifications

Feature	Detail
Brand	EMBATHER
Model Number	EMTJ068
Style	Modern
Color	Brushed Nickel
Material	Acrylonitrile Butadiene Styrene (ABS)
Finish Type	Nickel
Installation Type	Wall Mounted
Product Dimensions	10.03"L x 4.72"W
Hose Length	59 Inches
Item Weight	2.09 pounds
Filter Type	9 types of filter balls (KDF 55, Calcium Sulfite, etc.)
Spray Modes	9 adjustable modes



Image: The handheld shower head with its key dimensions (length and width) indicated.

Warranty and Support

EMBATHER is committed to customer satisfaction. While specific warranty details are not provided in this manual, if you have any questions or require assistance with your product, please contact EMBATHER customer service through the Amazon platform. Our team aims to respond within 24 hours to assist you.
For further information or to explore other EMBATHER products, please visit the official EMBATHER store on Amazon.




Image: A customer service representative, symbolizing support availability.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DSP6RDH1

More documents and user manuals: **https://manuals.plus/**