

LOVEVOOK 22 inch_Carry on

LOVEVOOK 22-Inch Carry-On Luggage User Manual

Model: 22 inch_Carry on | Brand: LOVEVOOK

INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your LOVEVOOK 22-inch Carry-On Luggage. Designed for convenience and durability, this softside luggage features spinner wheels, a TSA-approved lock, and multiple compartments for organized travel.

SETUP

Unpacking

Carefully remove the luggage from its packaging. Inspect for any signs of damage. Retain packaging for future storage or returns if necessary.

Setting the TSA Lock

Your luggage is equipped with a TSA-approved combination lock. The default combination is 0-0-0. To set your personal combination:

1. Ensure the lock is set to the original number (0-0-0).
2. Locate the reset button (usually a small, recessed button on the side of the lock).
3. Using a pen or a pointed tool, press and hold the reset button until you hear a "click" sound.
4. While holding the reset button, set your desired 3-digit combination by turning the dials.
5. Release the reset button. You should hear another "click" sound, indicating your new combination is set.
6. Test your new combination by scrambling the dials and then entering your set combination to open the lock.

Your browser does not support the video tag.

Video: Instructions for setting the TSA combination lock on your LOVEVOOK luggage.

OPERATING INSTRUCTIONS

Extending and Retracting the Telescopic Handle

To extend the handle, press the button located on the top of the handle and pull upwards. The handle can be adjusted to multiple heights for comfortable maneuvering. To retract, press the button again and push the handle down until it locks into place.



SMOOTH TELESCOPIC HANDLE

multi-height settings

Image: The smooth telescopic handle can be adjusted to multiple heights for user comfort.

Your browser does not support the video tag.

Video: Demonstration of the adjustable telescopic handle and smooth spinner wheels in use.

Using the Spinner Wheels

Your luggage features 360° silent spinner wheels for effortless mobility. These wheels allow the luggage to glide smoothly in any direction, reducing strain during travel. Ensure no debris is caught in the wheels for optimal performance.



Image: The 360° silent dual spinner wheels provide smooth and quiet movement.

Your browser does not support the video tag.

Video: A person demonstrating the smooth rolling of the silent spinner wheels on the LOVEVOOK carry-on luggage.

Packing and Organization

The luggage offers a large 50L capacity with smart packing features:

- **Main Compartment:** Use the internal straps to secure your clothing and prevent shifting during transit.
- **Wet Compartment:** A clear, waterproof zippered pocket is located on the inside lid, ideal for toiletries or damp items to keep them separate from dry belongings.
- **Bonus Storage Bags:** Two additional bags are included: one shoe bag and one 10L clothes pouch. Utilize these for further organization and to protect your items.

AIRLINE APPROVED DIMENSION:

- LOVEVOOK -



5-7
Days Travel

50L
Capacity

Net Weight:
7.6LB (3.44 KG)



Image: The main compartment offers 50L capacity with internal straps to secure belongings.

ACCESSORY MESH BAG AND A SHOE BAG

- LOVEVOOK -




Image: The luggage features a wet and dry separation compartment and includes a 10L mesh bag for organized packing.



Image: The luggage comes with an accessory mesh bag (14.5" x 10.5" x 4") and a shoe bag (17.4" x 9.6").

Using External Compartments

- **Front Laptop Compartment:** The exterior features a dedicated padded compartment for quick and easy access to your 15.6" laptop and tablet, useful for TSA checks.
- **Side Pocket:** A convenient side pocket is available for items like a water bottle or umbrella.



15.6 INCH LAPTOP COMPARTMENT + TABLET POCKET

A

Easy-Access
Side
Cup Holder



B

Organized
Front Storage
Pockets



Image: The front laptop compartment provides quick access for TSA checks, and a side pocket is available for a water bottle.

MAINTENANCE

Cleaning

The luggage is crafted from water-resistant and scratch-resistant polyester. For general cleaning, wipe the exterior with a damp cloth and mild soap. Allow to air dry completely. Do not use harsh chemicals or abrasive cleaners.

TSA-APPROVED LOCK

Allows customs inspection
without damage



Image: The water-resistant fabric helps protect your belongings from moisture.

Storage

Store the luggage in a cool, dry place away from direct sunlight when not in use. Ensure all compartments are empty and clean before storage.

TROUBLESHOOTING


- **Stiff Wheels:** If wheels become stiff or accumulate debris, clean them thoroughly with a damp cloth. Avoid using lubricants that may attract more dirt.
- **Handle Jamming:** Ensure the telescopic handle is fully extended or retracted before attempting to move the luggage. Avoid forcing the handle if it feels stuck.
- **Lock Issues:** If you forget your combination, contact LOVEVOOK customer support for assistance. Do not attempt to force the lock, as this may damage it.

SPECIFICATIONS

Feature	Detail
Product Dimensions	22 x 9 x 14 inches (includes wheels)
Item Weight	7.6 pounds
Capacity	50 Liters
Material	Water-resistant and scratch-resistant polyester
Wheels	360° Silent Spinner Wheels
Lock Type	TSA-Approved Combination Lock
Laptop Compartment	Fits up to 15.6" laptop/tablet

AIRLINE APPROVED DIMENSION:

- LOVEVOOK -



Net Weight:
7.6LB (3.44 KG)



Image: Airline approved dimensions of the LOVEVOOK carry-on luggage.

WARRANTY AND SUPPORT

LOVEVOOK is committed to providing excellent customer service. Each piece of our luggage undergoes rigorous testing to meet strict standards. If you encounter any issues or require support, please contact our customer service team. We are ready to provide timely solutions.

For further assistance, please visit the [LOVEVOOK Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question