



Manuals.plus /

- › Rythflo /
- › Rythflo AC01 Open-Ear Bluetooth Headphones User Manual

Rythflo AC01

Rythflo AC01 Open-Ear Bluetooth Headphones User Manual

Model: AC01

INTRODUCTION

Thank you for choosing Rythflo AC01 Open-Ear Bluetooth Headphones. This manual provides detailed instructions for setting up, operating, and maintaining your headphones to ensure optimal performance and longevity. Please read this manual thoroughly before use.



Image: Rythflo AC01 Open-Ear Bluetooth Headphones with their charging case.

WHAT'S IN THE BOX

Verify that all items are present in your package:

- RY-AC01 Open-ear True Wireless Earbud x1 pair
- Charging Case x1
- Type-C Charging Cable x1
- User Manual x1

What's in the box?



Ry-AC01 Open-ear True Wireless Earbud x1
Charging Case x1 User Manual x1 Type-C Charging Cable x1

Image: Contents of the product package, showing the earbuds, charging case, and USB-C cable.

PRODUCT OVERVIEW

The Rythflo AC01 headphones feature an open-ear design for comfort and situational awareness, equipped with earhooks for a secure fit. The charging case provides extended battery life.

OPEN-EAR COMFORT



Image: Illustration highlighting the open-ear comfort, lightweight design (6.7g), and secure fit of the headphones.

POWERFUL & DYNAMIC AUDIO

16mm drivers with richer details and enhanced bass.



Image: Exploded view of the earbud, detailing the 16mm drivers and Bluetooth 5.4 chip for powerful and dynamic audio.

SETUP

1. Charging

Before first use, fully charge the headphones and the charging case.

- Place the earbuds into the charging case.
- Connect the Type-C charging cable to the charging case and a power source.
- The indicator light on the case will show charging status.
- A 7-minute charge provides approximately 1.5 hours of playback. A full charge offers 8 hours of playback, with the case extending total listening time to 24 hours.



Image: The headphones in their charging case, displaying battery life metrics: 1.5 hours from 7 minutes charge, 8 hours single charge, and

24 hours with the charging case.

2. Pairing with a Device

1. Ensure the earbuds are charged and in the charging case.
2. Open the charging case. The earbuds will automatically enter pairing mode, indicated by alternating red and blue indicator lights.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for "Rythflo AC01" in the list of available Bluetooth devices.
5. Select "Rythflo AC01" to connect. Once connected, the indicator lights will turn off or show a steady blue light.

OPERATING INSTRUCTIONS

Wearing the Earbuds

Gently place the earhooks over your ears, ensuring the speaker rests comfortably outside your ear canal. Adjust for a secure and comfortable fit. The open-ear design allows you to remain aware of your surroundings.



Image: A person cycling while wearing the headphones, illustrating the safety benefit of the open-ear design which allows awareness of surroundings.

Touch Controls

The Rythflo AC01 headphones feature intuitive touch controls on each earbud. Refer to the diagram below for specific functions:



Image: A detailed diagram showing the touch control functions for the left and right earbuds, including actions for voice assistant, answer/play/pause, reject call, volume up/down, and previous/next track.

- **Voice Assistant:** Triple tap (x3) either earbud.
- **Answer/Play/Pause:** Double tap (x2) either earbud.
- **Reject Call:** Press and hold (2") either earbud.
- **Volume Up:** Single tap (x1) the right earbud.
- **Volume Down:** Single tap (x1) the left earbud.
- **Previous Track:** Press and hold (2") the left earbud.
- **Next Track:** Press and hold (2") the right earbud.

MAINTENANCE

Cleaning

Wipe the earbuds and charging case with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.

Water Resistance (IPX7)

The earbuds are IPX7 waterproof, meaning they can withstand immersion in water up to 1 meter for 30 minutes. They are suitable for workouts, running, and exposure to sweat and rain. However, the charging case is not waterproof. Ensure earbuds are dry before placing them in the charging case.



IPX7 WATERPROOF
Perfect for workouts even at high intensity.

Image: A person exercising with water droplets, emphasizing the IPX7 waterproof feature, suitable for intense workouts.

Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.

Common Issues and Solutions

- **No Sound/Connection Issues:**

- Ensure earbuds are charged.
- Verify Bluetooth is enabled on your device and "Rythflo AC01" is selected.
- Try re-pairing the earbuds (see "Resetting the Earbuds" below).
- Ensure earbuds are within Bluetooth range of your device.

- **One Earbud Not Working:**

- Place both earbuds back in the charging case, close the lid, then open it again.
- Ensure both earbuds are charged.
- Perform a reset.

Resetting the Earbuds

If you experience persistent connection issues or other malfunctions, resetting the earbuds may resolve the problem:

1. Place both earbuds into the charging case, ensuring they are powered off.
2. Press and hold the touch buttons on both the left and right earbuds simultaneously for 8 seconds.
3. The indicator lights will flash red and blue alternately, indicating they are in pairing mode after the reset.
4. After resetting, re-pair the earbuds with your device as described in the "Pairing with a Device" section.




Image: Step-by-step diagram illustrating the reset procedure for the earbuds, showing placing them in the case or turning them off, then holding the touch areas for 8 seconds until lights flash red and blue.

Model Name	AC01
Bluetooth Version	5.4
Connectivity Technology	Wireless (Bluetooth)
Ear Placement	Open Ear
Earpiece Shape	Earhook
Water Resistance Level	IPX7 (Earbuds only)
Battery Life (Single Charge)	8 Hours
Battery Life (with Charging Case)	Up to 24 Hours
Quick Charge	7 minutes for 1.5 hours playback
Control Type	Touch Control, Media Control
Audio Driver Type	Dynamic Driver (16mm)
Frequency Range	20 Hz - 20,000 Hz
Item Weight	6.7g (per earbud) / 3.84 ounces (total package)
Material	Acrylonitrile Butadiene Styrene (ABS), Plastic, Silicone
Product Dimensions	6.6 x 4.96 x 0.58 inches

SAFETY INFORMATION

- Do not expose the charging case to water or moisture.
- Avoid listening at high volumes for extended periods to prevent hearing damage.
- Keep out of reach of children and pets.
- Do not disassemble, repair, or modify the product.
- Dispose of the product and batteries according to local regulations.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Rythflo website. The product includes a user manual and a Type-C charging cable. For any issues, please contact customer service.

