

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SoBuy](#) /

› [SoBuy FSR189-WN Narrow Shoe Cabinet Instruction Manual](#)

## SoBuy FSR189-WN

# SoBuy FSR189-WN Narrow Shoe Cabinet Instruction Manual

Model: FSR189-WN

## PRODUCT OVERVIEW

The SoBuy FSR189-WN is a narrow shoe cabinet designed for entryways and hallways, offering efficient storage in a compact and elegant white finish. It features a minimalist design with a wooden side strip, providing both functionality and aesthetic appeal.

- Compact and Elegant Design:** This narrow white shoe cabinet integrates seamlessly with modern home decor, ideal for entryways or hallways.
- Efficient Storage Capacity:** Equipped with three spacious flap compartments, it can store approximately 15-20 pairs of shoes, including sneakers, heels, or slippers, helping to maintain an organized space.
- Versatile Multifunctional Storage:** A side door conceals five adjustable shelves, suitable for storing keys, umbrellas, or small boxes, offering comprehensive storage solutions.
- Durable and Easy-to-Maintain Materials:** Constructed from MDF and bamboo, this shoe cabinet is designed for durability and is easy to clean. It includes an anti-tip system for enhanced safety.



The SoBuy FSR189-WN shoe cabinet, showcasing its compact design and white finish with bamboo accents, positioned in an entryway.

## SAFETY INFORMATION

To ensure safe use and prevent potential hazards, please adhere to the following safety guidelines:

- **Anti-Tip Device:** It is crucial to correctly install the provided anti-tip device to secure the furniture to the wall. This prevents the risk of tipping, especially in households with children.
- **Weight Distribution:** Do not overload the furniture. Distribute items evenly to maintain stability. Overloading or placing heavy items on top can cause instability and potential tipping.
- **Assembly:** Follow all assembly instructions carefully. Incorrect assembly can compromise the structural integrity and safety of the unit.



Diagram showing the correct installation of the anti-tip device to prevent the shoe cabinet from falling over.

## SETUP AND ASSEMBLY

---

The SoBuy FSR189-WN shoe cabinet is designed for straightforward assembly. Clear instructions are included with the product. It is recommended to have a screwdriver or power drill for easier assembly.

### General Assembly Steps:

1. **Unpack Components:** Carefully unpack all parts and hardware. Verify that all pieces are present according to the parts list in the included manual. Components are typically labeled for easy identification.
2. **Assemble Frame:** Follow the step-by-step diagrams to assemble the main frame of the cabinet. Ensure all connections are secure.
3. **Install Flap Mechanisms:** Attach the mechanisms for the shoe flap doors as per the instructions.
4. **Install Side Door and Shelves:** Mount the side door and insert the adjustable shelves into the designated slots.
5. **Attach Feet:** Secure the bamboo feet to the base of the cabinet.
6. **Secure Anti-Tip Device:** Crucially, attach the anti-tip device to the back of the cabinet and secure it to a wall stud using appropriate hardware.




Detail of the sturdy bamboo feet, which are attached during assembly.

## OPERATING INSTRUCTIONS

The SoBuy FSR189-WN shoe cabinet offers organized storage for various shoe types and other small items.

### Shoe Storage (Flap Compartments):

- Gently pull the front of each flap compartment to open.
- Place shoes neatly on the internal racks. The design allows for shoes to be stored at an angle, maximizing space.
- For larger shoes or boots, the internal divider within each flap can be adjusted or removed to create a single, taller storage space. Refer to the diagram below for adjustment options.
- Push the flap back into the cabinet until it closes securely.



The internal dividers of the shoe flaps can be set to two levels for smaller shoes or removed for a single level to accommodate larger footwear like boots.

#### **Side Storage Compartment:**

- Open the side door to access the internal shelves.
- The five shelves are adjustable to three different heights, allowing customization for various items such as keys, wallets, small bags, or decorative items.
- Close the door firmly after use.

# Almacenamiento ordenado



Visual representation of organized shoe storage within the cabinet compared to a disorganized pile of shoes.

## MAINTENANCE

To keep your SoBuy FSR189-WN shoe cabinet in optimal condition, follow these simple maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood and MDF components.
- **Dusting:** Regularly dust the cabinet with a dry, soft cloth to prevent dust buildup.
- **Inspection:** Periodically check all screws and fittings to ensure they remain tight. Retighten if necessary to maintain structural integrity.
- **Avoid Direct Sunlight and Moisture:** Prolonged exposure to direct sunlight or excessive moisture can cause fading, warping, or damage to the materials.

## TROUBLESHOOTING

If you encounter any issues with your SoBuy FSR189-WN shoe cabinet, refer to the following common problems and solutions:

- **Cabinet feels unstable or wobbly:**

Ensure the anti-tip device is securely installed to the wall. Check that all assembly screws are tightened. Verify the cabinet is placed on a flat, level surface.

- Shoe flaps do not close properly:**

Check if shoes are correctly positioned within the compartments and not obstructing the closing mechanism. For larger shoe sizes, consider adjusting the internal divider to a single-level configuration or removing it entirely if possible.

- Side door does not close smoothly:**

Inspect for any obstructions on the shelves or within the door frame. Check the hinges for proper alignment and tightness.

- Difficulty during assembly:**

Refer back to the detailed assembly instructions provided with the product. Ensure all parts are correctly oriented and that the correct hardware is used for each step. If a part is missing or damaged, contact customer support.

## PRODUCT SPECIFICATIONS

Feature	Specification
Brand	SoBuy
Model Number	FSR189-WN
Color	White
Product Dimensions (L x W x H)	80 x 34 x 122 cm
Product Weight	39.7 kg
Maximum Capacity	35 Kilograms
Material	Engineered Wood (MDF) and Bamboo
Recommended Uses	Shoes
Mounting Type	Floor Mount
Special Features	Shoe flaps, Adjustable shelves, Anti-tip system



Detailed dimensions of the SoBuy FSR189-WN shoe cabinet.

## WARRANTY INFORMATION

Specific warranty details for the SoBuy FSR189-WN shoe cabinet may vary by retailer and region. Please refer to the warranty information provided at the time of purchase or contact your retailer directly for details regarding warranty coverage, terms, and conditions.

## CUSTOMER SUPPORT

For further assistance, questions, or to report any issues with your SoBuy FSR189-WN shoe cabinet, please contact SoBuy customer service or your point of purchase. SoBuy offers specialized customer attention to address your needs.

You can typically find contact information on the SoBuy official website or through the retailer where you purchased the product.

