

Samsung GP-PWU024WIABU

Samsung 3-in-1 Qi2-Certified Wireless Charging Station User Manual

Model: GP-PWU024WIABU

INTRODUCTION

The Samsung 3-in-1 Wireless Charging Station is designed to provide fast and convenient wireless charging for your compatible Samsung Galaxy devices. Featuring Qi2 technology and a magnetic design, this station allows simultaneous charging of your Galaxy phone, Watch, and Buds.

Key features include:

- **3-in-1 Fast Wireless Charging:** Equipped with Qi2 technology for fast and easy charging of multiple devices simultaneously.
- **Magnetic Design:** Phone and watch charging pads feature a secure magnetic attachment.
- **Adjustable Viewing Angle:** The phone charging pad can be adjusted up to 40 degrees for comfortable viewing.
- **Durable Construction:** Made with aluminum steel for a modern design and scratch prevention.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- Samsung 3-in-1 Wireless Charging Station (Model: GP-PWU024WIABU)
- USB Type-C Charging Cable
- Power Adapter (Fast Charging compatible)



Figure 1: Contents of the Samsung 3-in-1 Wireless Charging Station package.

SETUP

1. **Connect the Power Adapter:** Insert the USB Type-C cable into the 'Power In' port on the back of the charging station.
2. **Plug into Power Outlet:** Connect the other end of the USB Type-C cable to the provided power adapter, then plug the adapter into a wall outlet.

3. **Power On:** The charging station will power on automatically. Indicator lights may illuminate briefly.



Figure 2: USB Type-C port on the rear of the charging station for power input.

Video 1: Demonstration of connecting devices to a similar Samsung Wireless Charger.

OPERATING INSTRUCTIONS

Charging Your Devices

The Samsung 3-in-1 Wireless Charging Station features dedicated areas for your smartphone, smartwatch, and wireless earbuds.

- **Charging a Galaxy Phone:** Place your compatible Galaxy phone (S10 or later, requiring a magnetic case) onto the magnetic phone charging pad. Ensure proper alignment for optimal charging. The phone

pad can be adjusted up to 40 degrees for a comfortable viewing angle.

- **Charging a Galaxy Watch:** Place your compatible Galaxy Watch (Watch3 or later) onto the magnetic watch charging pad.
- **Charging Galaxy Buds:** Place your compatible Galaxy Buds (Buds2 Pro or later) or Galaxy Ring onto the designated flat charging area on the base.



Figure 3: The charging station in use, simultaneously charging a smartphone, smartwatch, and wireless earbuds.




Figure 4: The phone charging pad offers up to 40 degrees of tilt for optimal viewing.

Indicator Lights

The charging station features LED indicator lights to show the charging status of your devices:

- **Solid Red:** Device is charging.
- **Solid Green:** Device is fully charged.
- **Blinking Red:** Indicates a charging error (e.g., improper placement, foreign object detected, or incompatible device).

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the charging station. Do not use abrasive cleaners or solvents.
- **Storage:** Store the charging station in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Avoid Liquids:** Keep the device away from water and other liquids.

TROUBLESHOOTING

- **Device not charging:**
 - Ensure the power adapter is securely plugged into both the charging station and a working wall outlet.
 - Verify that your device is wirelessly charging compatible and correctly placed on the charging pad.
 - For Galaxy phones, ensure your phone case has magnetic capabilities for proper attachment.
 - Remove any foreign objects between the device and the charging pad.
- **Slow charging:**
 - Confirm you are using the included Fast Charging compatible power adapter and cable.
 - Ensure your device supports Fast Wireless Charging.
 - If issues persist with a Samsung phone, try disabling 'Fast Wireless Charging' in your phone's settings to see if it resolves the problem.
- **Device overheating:**
 - Ensure the charging station has adequate ventilation and is not covered.

- Remove any thick cases or accessories that might impede heat dissipation.

SPECIFICATIONS

Feature	Detail
Model Number	GP-PWU024WIABU
Product Dimensions	6.3 x 3.54 x 6.06 inches
Item Weight	14.1 ounces
Color	Black
Connectivity	USB Type-C
Input Voltage	9 Volts
Output Current	3 Amps
Special Features	Lightweight Design, Wireless Charging, Magnetic Attachment, Adjustable Viewing Angle
Compatible Devices	Qi-Certified Galaxy Phones (S10 or later with magnetic case), Galaxy Watches (Watch3 or later), Galaxy Buds (Buds2 Pro or later), Galaxy Ring

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your product or visit the official Samsung support website. Keep your purchase receipt for warranty claims.