



Manuals.plus /

› TERENCE /

› TERENCE 88-Key Semi-Weighted Digital Piano (Model DZQ-P10) Instruction Manual

## TERENCE DZQ-P10

# TERENCE 88-Key Semi-Weighted Digital Piano Instruction Manual

Model: DZQ-P10

## 1. INTRODUCTION

---

Thank you for choosing the TERENCE 88-Key Semi-Weighted Digital Piano, Model DZQ-P10. This instrument is designed to provide a realistic piano playing experience for beginners, advanced players, and professionals alike. Featuring a semi-weighted keyboard, premium sound, and versatile connectivity options, this manual will guide you through the setup, operation, and maintenance of your new digital piano.

## 2. PACKAGE CONTENTS

---

Please verify that all items are present in the package before proceeding with assembly and setup. If any items are missing or damaged, please contact TERENCE customer support.

- TERENCE 88-Key Digital Piano Unit
- Wooden Piano Stand (if included with your model)
- Triple Pedal Unit (Sustain, Soft, Sostenuto)
- Power Adapter
- Music Rest
- User Manual

## 3. SETUP

---

Follow these steps to set up your TERENCE digital piano.

### 3.1 Assembling the Stand

If your package includes a wooden stand, carefully assemble it according to the separate assembly

instructions provided with the stand. Ensure all screws are tightened securely for stability.

### 3.2 Placing the Piano Unit

Carefully place the 88-key digital piano unit onto the assembled stand or a stable, flat surface. Ensure it is centered and secure.



Image: The TERENCE digital piano with its wooden stand, indicating its dimensions for proper placement.

### 3.3 Connecting Pedals

Locate the 3-Pedal input port on the rear panel of the piano. Connect the triple pedal unit cable firmly into this port.

### 3.4 Connecting Power

Connect the power adapter to the 'Type-C 5V' power input port on the rear panel of the piano. Plug the other end of the adapter into a standard electrical outlet.

# 88 key Weight-Sensing Keyboard




Image: Close-up of the rear panel of the TERENCE digital piano, showing USB MIDI, Sustain, 3-Pedal, Aux In, Headphone, Volume, Power, and Type-C 5V ports.

## 4. OPERATING INSTRUCTIONS

### 4.1 Power On/Off and Volume

- To power on the piano, press the 'PIL SW' button on the rear panel. The power indicator light will illuminate.
- Adjust the master volume using the 'VOL' knob on the rear panel.
- To power off, press the 'PIL SW' button again.

### 4.2 Dual-Player Mode

The Dual-Player Mode allows two individuals to play simultaneously on the same keyboard. This mode splits the 88-key keyboard into two 44-key zones, each with independent volume control for balanced harmony. This is ideal for teacher-student duets or collaborative playing.

# Domestic Melodies with Dual-playing mode

A Touch of Elegance with the Digital Piano Keyboard



88 Keys



Grand Piano Sound



Dual-Player Mode splits the keyboard into two 44-key zones. No sound overlap, with independent volume controls for balanced harmony.



Image: Illustration of the dual-player mode on the TERENCE digital piano, showing two sets of hands playing on the keyboard simultaneously.

## 4.3 Silent Practice (Headphone Jack)

For private practice, connect standard 3.5mm headphones to the 'HEADPHONE' jack on the rear panel. This will mute the internal speakers, allowing you to practice without disturbing others. The piano supports dual headphone mode for two users to listen simultaneously.



## Silent Mode

To spare others, turn on mute and enjoy.  
Headphones are not included.



Dual Headphone Mode



Bluetooth

Image: A user practicing silently with headphones connected to the TERENCE digital piano.

### 4.4 Bluetooth and MIDI Functionality

The piano features dual-mode integrated Bluetooth for both audio playback and MIDI connectivity.

- **Bluetooth Audio:** Pair your smartphone or tablet with the piano via Bluetooth to play external audio through the piano's speakers.
- **MIDI Function:** Connect the piano to a computer or other MIDI-compatible device using the 'USB MIDI' port. This allows you to use the piano with various music software, learning apps, for recording, or as a MIDI controller.

# Unleash Your Inner Musician

Savor the Art of Playing the TERENCE Electronic Keyboard in the Comfort of Your Home



20W Dual Speaker



Image: Highlighting the MIDI and Bluetooth connectivity features of the TERENCE digital piano, showing various ports and connections to external devices.

## 4.5 Using Pedals

The included triple pedal unit provides the following functions, similar to an acoustic piano:

- **Sustain Pedal (Right):** Sustains the notes played, allowing them to ring out after the keys are released.
- **Sostenuto Pedal (Middle):** Sustains only the notes that are held down at the moment the pedal is pressed, while subsequent notes are unaffected.
- **Soft Pedal (Left):** Reduces the volume and alters the timbre of the notes played.

## 5. KEY FEATURES

### 5.1 88-Key Semi-Weighted Keyboard

The TERENCE digital piano features a full range of 88 semi-weighted keys designed to replicate the feel of an acoustic piano. The keys are sensitive to force, allowing for dynamic expression from soft to strong tones. This design provides a comfortable and smooth playing experience.

# Standard 88-key Semi-Weighted Full Size Keyboard

Comfortable and smooth playing experience




Image: Details of the TERENCE 88-key semi-weighted digital piano keyboard, illustrating key response and dimensions for a comfortable playing experience.



Image: Diagram illustrating the internal mechanism of the 88-key weight-sensing keyboard, showing key structure and noise reduction features.

## 5.2 Premium Sound System

Equipped with powerful 20W stereo speakers (10W x 2) and a high-quality DREAM sound chip, the piano delivers a full, clear, and authentic piano tone. The sound reproduction is delicate and realistic, capturing subtle changes in sound quality based on playing dynamics.

## 6. MAINTENANCE

Proper care will ensure the longevity and optimal performance of your digital piano.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the piano. For stubborn dirt, slightly dampen the cloth with water and a mild soap, then wipe dry immediately. Avoid abrasive cleaners or solvents.
- **Key Care:** Keep the keys clean. If they become dirty, wipe them gently with a soft, slightly damp cloth.
- **Environment:** Avoid exposing the piano to direct sunlight, extreme temperatures, high humidity, or excessive dust.
- **Power:** Always disconnect the power adapter from the outlet when the piano is not in use for extended periods.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your TERENCE digital piano, please refer to the following common solutions:

Problem	Possible Cause	Solution
No sound from speakers	Volume too low; Headphones connected; Power issue	Increase volume knob; Disconnect headphones; Ensure power adapter is securely connected and piano is powered on.
Bluetooth not connecting	Piano not in pairing mode; Device too far; Interference	Ensure Bluetooth is enabled on piano and device; Move device closer; Restart both devices.
Pedals not working	Pedal unit not connected properly	Check the connection of the triple pedal unit to the '3-Pedal' port on the rear panel.
Keys feel unresponsive	Dust or debris under keys; Power cycle needed	Gently clean around keys; Power off and on the piano.

If the problem persists after trying these solutions, please contact TERENCE customer support for further assistance.

## 8. SPECIFICATIONS

---

- **Model Name:** P10
- **Item Model Number:** DZQ-P10
- **Number of Keys:** 88
- **Key Type:** Semi-Weighted, Touch-Sensitive
- **Connectivity Technology:** Bluetooth
- **Connector Types:** 3.5mm Jack (Headphone/Aux In), MIDI USB
- **Speakers:** 20W Stereo (10W x 2) Built-In
- **Pedals:** Sustain, Soft, Sostenuto (Triple Pedal Unit)
- **Power Input:** Type-C 5V
- **Dimensions (without stand):** 123 x 25 x 9 cm (approx. 48.43 x 9.84 x 3.54 inches)
- **Dimensions (with stand):** 123 x 25 x 74 cm (approx. 48.43 x 9.84 x 29.13 inches)
- **Item Weight:** 31.9 pounds
- **Manufacturer:** TERENCE

## 9. WARRANTY AND SUPPORT

---

TERENCE products are manufactured to high-quality standards. For information regarding warranty coverage, technical support, or service, please refer to the warranty card included with your product or visit the official TERENCE website. Please retain your proof of purchase for any warranty claims.

