

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [LIORQUE](#) /

› [LIORQUE SM-01 White Noise Machine with Alarm Clock User Manual](#)

LIORQUE SM-01

LIORQUE SM-01 White Noise Machine with Alarm Clock User Manual

Model: **SM-01** | Brand: **LIORQUE**

INTRODUCTION

Thank you for choosing the LIORQUE SM-01 White Noise Machine with Alarm Clock. This device is designed to enhance your sleep, relaxation, and wake-up experience with a variety of soothing sounds, an adjustable night light, and a customizable alarm clock. Please read this manual carefully to ensure proper use and to fully enjoy all its features.

SAFETY INFORMATION

- **Caution:** Use only with the provided power cable.
- Do not use in humid environments.
- Do not expose to excessive heat.
- This device is not a toy.
- Risk of sunburn or electric shock if mishandled.
- Avoid prolonged exposure to high sound levels.
- Keep out of reach of children.

PACKAGE CONTENTS

Que contient la boîte ?



- Réveil *1
- Câble de Charge *1
- Adaptateur *1
- Manuel d'Utilisation *1

The image displays the LIORQUE SM-01 White Noise Machine, a charging cable, a power adapter, and the user manual, all neatly arranged with the product packaging.

Upon unpacking, please ensure all the following items are present:

- LIORQUE SM-01 White Noise Machine with Alarm Clock (x1)
- Charging Cable (x1)
- Power Adapter (x1)
- User Manual (x1)



This image illustrates the top panel of the device, highlighting the various buttons and their corresponding functions for easy identification and operation.

Familiarize yourself with the control buttons located on the top of the device:

1. **Alarm Switch:** Activates or deactivates the alarm.
2. **Time Set / Dimmer:** Long press to set the time; short press to adjust display brightness.
3. **Volume -:** Decreases the volume.
4. **Snooze / Light Button:** Activates snooze during an alarm; short press to turn on/off or adjust the night light.
5. **Volume +:** Increases the volume.
6. **Sound Button:** Selects soothing sounds.
7. **Timer Button:** Sets the sleep timer duration.

Design de Boutons Surélevés

Facile à Utiliser Même dans l'Obscurité



Design de Housse en Tissu de Grande Surface

Meilleure Texture, Meilleure Durabilité

The device features raised buttons for intuitive operation, even in low light conditions, and a durable fabric-wrapped casing.

SETUP

- Power Connection:** Connect the provided power cable to the device and plug the adapter into a standard electrical outlet. The device will power on automatically.
- Initial Time Setting:** Long press the **Time Set** button. Use the Volume +/- buttons to adjust the hour and minute. Press the Time Set button again to confirm each setting.

OPERATING INSTRUCTIONS

1. White Noise and Soothing Sounds



25 Sons Apaisants
Détendez-vous et laissez-vous emporter dans des rêves doux

 Vagues	 Feu de camp	 Tempête	 Nuit d'été	 Chant des oiseaux
 Ruisseau	 Grillons	 Carillons	 Cloches d'église	 Plus

The device offers 25 natural sounds, including various nature sounds and lullabies, to promote relaxation and sleep.

- Selecting Sounds:** Press the **Sound Button** to cycle through the 25 available natural sounds (e.g., thunderstorms, rain, lullabies).
- Adjusting Volume:** Use the **Volume +** and **Volume -** buttons to set your desired sound level. The device offers 16 levels of volume adjustment.

2. Alarm Clock Function

Réveil Numérique



5 Niveaux de Luminosité de l'Écran



7 Sonneries de Réveil



16 Niveaux de Volume



9 Minutes Temps de Snooze



The digital alarm clock features 5 display brightness levels, 7 alarm tones, 16 volume levels, and a 9-minute snooze function.

- **Setting Alarm:** Long press the **Alarm Switch** button. Use the Volume +/- buttons to set the alarm time. Press the Alarm Switch again to confirm.
- **Choosing Alarm Tone:** While setting the alarm, you can select from 7 pleasant alarm tones.
- **Snooze Function:** When the alarm sounds, press the **Snooze / Light Button** to get an additional 9 minutes of sleep.
- **Disabling Alarm:** Press the **Alarm Switch** button to turn off the alarm for the day.

3. Night Light

10 Niveaux de Lumière, Température de Couleur 1500K-6500K

La luminosité et la température de couleur se règlent simultanément, passant du jaune chaud au blanc froid, pour créer l'atmosphère lumineuse idéale.




The night light offers 10 adjustable levels of brightness and color temperature from 1500K to 6500K, allowing for personalized ambiance.

- **Activating/Adjusting Light:** Short press the **Snooze / Light Button** to turn on the night light. Continue pressing to cycle through 10 levels of brightness and color temperature (1500K to 6500K).
- **Turning Off Light:** Press the **Snooze / Light Button** until the light turns off.

4. Display Brightness

5 Niveaux de Luminosité de l'Écran

La luminosité peut être ajustée selon les besoins ou complètement éteinte.



The display brightness can be adjusted across 5 levels, including a completely dark mode, suitable for light-sensitive sleepers.

- **Adjusting Display:** Short press the **Time Set / Dimmer** button to cycle through 5 levels of display brightness, including a complete blackout mode.

5. Sleep Timer

Fonction de Minuterie de Sommeil de 5 à 480 Minutes

Éteint automatiquement la musique et les lumières à l'heure prévue, vous permettant de dormir sans être dérangé.

5 150 480



The sleep timer allows you to set the device to automatically turn off sounds and lights after a duration between 5 and 480 minutes.

- **Setting Timer:** Press the **Timer Button** to select a desired sleep timer duration (e.g., 5, 15, 30, 60, 90, 120, 180, 240, 300, 360, 420, 480 minutes). The sound and light will automatically turn off after the set time.
- **Disabling Timer:** Continue pressing the Timer Button until the timer indicator disappears from the display.

MAINTENANCE

- Cleaning:** Disconnect the power before cleaning. Wipe the device with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- Storage:** Store the device in a cool, dry place when not in use for extended periods.

TROUBLESHOOTING

- Device not powering on:** Ensure the power cable is securely connected to both the device and the power outlet. Verify the outlet is functional.
- No sound:** Check the volume level using the Volume +/- buttons. Ensure a sound is selected.
- Alarm not sounding:** Verify the alarm is set and activated (check the alarm icon on the display). Ensure the alarm volume is not set to zero.
- Display too bright/dark:** Adjust the display brightness using the Time Set / Dimmer button.

SPECIFICATIONS

Feature	Specification
Model Number	SM-01
Brand	LIORQUE
Dimensions	14.7 x 13.6 x 13.5 cm
Weight	480 grams
Power Source	Electric Cable
Number of Soothing Sounds	25
Display Brightness Levels	5 (including off)
Night Light Levels	10
Night Light Color Temperature	1500K - 6500K
Alarm Tones	7
Snooze Duration	9 minutes
Sleep Timer Duration	5 to 480 minutes

WARRANTY AND SUPPORT

LIORQUE products are designed and manufactured to the highest quality standards. For any questions, technical support, or warranty claims, please refer to the contact information provided on the product packaging or visit the official LIORQUE website.

Please retain your proof of purchase for warranty purposes.

© 2026 LIORQUE. All rights reserved.