

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [WHYKJTEK](#) /

› [WHYKJTEK Wireless Earbuds Bluetooth 5.4 Headphones User Manual](#)

WHYKJTEK A1

WHYKJTEK Wireless Earbuds User Manual

Model: A1

INTRODUCTION

Thank you for choosing the WHYKJTEK Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your new earbuds. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.



Image: The WHYKJTEK Wireless Earbuds in their open charging case, displaying the dual LED battery indicator.

PACKAGE CONTENTS

Please verify that all items are present in your package:

- WHYKJTEK Wireless Earbuds (Left and Right)
- Wireless Charging Case
- USB Charging Cable
- Multiple sizes of ear tips (S/M/L)
- User Manual

SETUP GUIDE

1. Initial Charging

Before first use, fully charge the earbuds and the charging case. The charging case features a dual LED display to show battery levels for both the case and individual earbuds.

1. Connect the charging case to a USB power source using the provided USB cable.
2. Place the earbuds into the charging case. Ensure they are properly seated to initiate charging.
3. The LED display on the case will indicate the charging status. A full charge typically takes approximately 1.5 hours.



Image: The charging case displaying its own battery percentage and the individual charge levels of the left and right earbuds.

The earbuds offer up to 8 hours of playtime on a single charge, and the charging case extends this to a total of 48 hours.

50 Hours of Unstoppable Playtime with Charging Case



6 Hrs
on a single
charge up to



50 Hrs
charge case
up to



4 Hrs
10 min charge
up to





Image: Visual representation of battery life: 6 hours on a single charge, 50 hours with the charging case, and 4 hours from a 10-minute charge.

2. Pairing with Your Device

The earbuds feature Bluetooth 5.4 for stable and low-latency connections. They support one-step pairing.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, laptop, etc.), enable Bluetooth.
3. Search for "A1 Pro" (or similar model name) in the list of available Bluetooth devices.
4. Select "A1 Pro" to connect. Once connected, you will hear a confirmation tone.
5. For subsequent uses, the earbuds will automatically connect to the last paired device when removed from the case.

One Step Pairing and Fast Connection



Close

Auto power off and charging.



Close

Auto power off and charging.




Image: A diagram illustrating the one-step pairing process: open the case, and the earbuds automatically connect to the device's Bluetooth.



Image: The earbuds and charging case shown next to icons representing compatible devices such as notebooks, TVs, desktops, watches, phones, and tablets.

3. Wearing the Earbuds

For optimal sound quality and comfort, choose the ear tips that best fit your ears. The earbuds are designed to fit securely for various activities, including sports.

1. Select the appropriate size of ear tips (S/M/L) for a snug fit.
2. Gently insert each earbud into your ear canal and rotate slightly until it feels secure and comfortable.



Image: An illustration demonstrating how the earbud fits the ear structure and the availability of different ear tip sizes for a secure and comfortable wear.

OPERATING INSTRUCTIONS

Touch Controls

The WHYKJTEK Wireless Earbuds feature smart touch controls for easy management of music playback, calls, and voice assistant activation.

Action	Left Earbud (L)	Right Earbud (R)
Play/Pause Music	Double Tap (L/R)	
Volume Up		Once Tap (R)
Volume Down	Once Tap (L)	
Previous Song	Long Press (L)	
Next Song		Long Press (R)
Answer/End Call	Long Press (L/R)	
Activate Voice Assistant	Triple Tap (L/R)	




Image: A visual guide detailing the touch control gestures for various functions like volume adjustment, track skipping, call management, and voice assistant activation.

Environmental Noise Cancelling (ENC)

The earbuds are equipped with 4 microphones and personalized algorithms for AI-enhanced clear calls and effective environmental noise cancellation, reducing ambient noise by up to 35dB.

ENC Environmental Noise Cancelling



Image: An internal view of an earbud highlighting the ENC noise cancelling mic and main mic for talk, illustrating how 4 mics reduce environmental noise for clear calls.

Hi-Fi Stereo Sound

Experience immersive sound with 13mm speakers and a unique acoustic design that delivers deep bass, rich mids, and clear highs.

MAINTENANCE AND CARE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Ear Tips:** Remove ear tips periodically and clean them with a damp cloth. Ensure they are completely dry before reattaching.
- **Water Resistance:** The earbuds have an IPX7 waterproof rating, making them resistant to sweat, rain, and minor water splashes. Do not submerge them in water or expose them to high-pressure water jets. Dry them thoroughly after exposure to moisture.

- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds and charging case frequently. Charge them regularly, even if not in constant use.

TROUBLESHOOTING

Problem	Possible Solution
Earbuds not pairing/connecting	<ul style="list-style-type: none"> • Ensure earbuds are charged. • Turn off and on Bluetooth on your device. • Forget "A1 Pro" from your device's Bluetooth list and re-pair. • Place earbuds back in the case, close, wait a few seconds, then open again.
Only one earbud working	<ul style="list-style-type: none"> • Ensure both earbuds are charged. • Place both earbuds back in the charging case, close the lid, then open it again to reset the connection. • Try re-pairing the earbuds with your device.
Low volume or poor sound quality	<ul style="list-style-type: none"> • Adjust volume on both your device and using earbud touch controls. • Ensure ear tips are the correct size for a snug fit. • Clean any debris from the earbud speakers and ear tips. • Ensure there are no obstructions between the earbuds and your device.
Charging issues	<ul style="list-style-type: none"> • Ensure the charging cable is securely connected to both the case and the power source. • Try a different USB cable or power adapter. • Ensure earbuds are correctly seated in the charging case. • Clean the charging contacts on both the earbuds and the case.
Touch controls unresponsive	<ul style="list-style-type: none"> • Ensure your fingers are clean and dry when using touch controls. • Restart the earbuds by placing them in the case and taking them out.

SPECIFICATIONS

Feature	Detail
Model	A1
Connectivity Technology	Wireless, Bluetooth 5.4
Noise Control	Active Noise Cancellation (ENC)

Feature	Detail
Headphones Jack	No Jack
Included Components	Wireless Charging Case
Material	Plastic
Specific Uses	Sport, Everyday Use
Charging Time	1.5 Hours
Compatible Devices	Smartphones, TVs, Computers, Laptops
Water Resistance Level	IPX7 Waterproof
Frequency Range	20 Hz - Unknown
Unit Count	2.0 Count (Earbuds)
Battery Average Life (Earbuds)	7 Hours (single charge)
Total Playtime with Case	Up to 48-50 Hours
Battery Type	Lithium Polymer
Ear Placement	In Ear
Form Factor	In Ear
Impedance	30 Ohm
Parcel Dimensions	10.7 x 8.2 x 3.5 cm; 110 g

WARRANTY AND SUPPORT

Specific warranty details are not provided in this manual. For warranty information, technical support, or customer service inquiries, please refer to the product packaging or contact the manufacturer directly via their official website or the retailer where the product was purchased.

Manufacturer: WHYKJTEK

© 2025 WHYKJTEK. All rights reserved.

Related Documents - A1

	<p>SilverCrest SKRO 24 A1 Bluetooth On-Ear Kopfhörer mit Geräuschunterdrückung – Bedienungsanleitung</p> <p>Entdecken Sie die SilverCrest SKRO 24 A1 Bluetooth On-Ear Kopfhörer. Diese Anleitung bietet detaillierte Informationen zur Einrichtung, Bedienung und Wartung Ihrer kabellosen Kopfhörer mit aktiver Geräuschunterdrückung.</p>
---	---

	<p>TOZO A1 True Wireless Stereo Earbuds User Manual</p> <p>This user manual provides comprehensive instructions for the TOZO A1 True Wireless Stereo earbuds, covering product features, operation, music and call controls, voice assistant activation, app integration, and proper wearing techniques. Learn how to pair, reset, and customize your audio experience.</p>
	<p>TOZO A1 True Wireless Stereo Earbuds Quick Guide</p> <p>A concise guide to the TOZO A1 True Wireless Stereo Earbuds, covering Bluetooth pairing, wearing instructions, smart touch controls, power management, reset procedures, and charging. Optimized for accessibility and SEO.</p>
	<p>UBIBOT UB-WB-A1 Waterproof Case User Guide</p> <p>User guide for the UBIBOT UB-WB-A1 outdoor PVC waterproof resistant case, designed for temperature and humidity recorders. Details features, specifications, and usage notes.</p>
	<p>TOZO A1 True Wireless Stereo Earbuds Quick Guide</p> <p>Comprehensive quick guide for TOZO A1 True Wireless Stereo Earbuds, covering Bluetooth pairing, wearing, touch controls, power operations, reset procedures, and charging.</p>
	<p>Soundcore Life A1 User Manual - Charging, Wearing, and Controls</p> <p>Comprehensive user manual for the Soundcore Life A1 wireless earbuds. Learn about charging, proper wearing techniques, Bluetooth pairing, controls, and troubleshooting.</p>