

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SICOTAS](#) /

› [SICOTAS Rattan Sideboard Buffet Cabinet \(Model SC119\) Instruction Manual](#)

SICOTAS SC119

SICOTAS Rattan Sideboard Buffet Cabinet (Model SC119) Instruction Manual

Your guide to assembly, use, and care.

PRODUCT OVERVIEW

The SICOTAS Rattan Sideboard Buffet Cabinet, Model SC119, is a versatile storage solution designed for various home environments such as dining rooms, kitchens, and hallways. It features a white cream oak finish with rattan detailing, gold-accented handles, and sturdy engineered wood construction. This cabinet offers ample storage with four doors and adjustable interior shelves, complemented by a large open lower shelf.



Figure 1: The SICOTAS Rattan Sideboard Buffet Cabinet, showcasing its white cream oak finish, rattan doors, and gold handles.

IMPORTANT SAFETY INFORMATION

- Always assemble this product with at least two people to ensure stability and safety.
- Secure the cabinet to the wall using appropriate hardware to prevent tip-overs, especially if there are children or pets in the household. Wall anchoring hardware is included.
- Always follow the assembly instructions carefully to avoid injury and ensure proper construction.
- Inspect all pieces before assembly to ensure no damage or scratches are present.

SETUP AND ASSEMBLY

The SICOTAS Rattan Sideboard Buffet Cabinet requires assembly. All necessary hardware and tools are included. Follow the step-by-step instructions provided in the packaging. For a visual guide, refer to the installation video below.

Assembly Steps Overview:

1. Unpack all components and verify against the parts list.
2. Attach the metal support bars to the bottom shelves.
3. Assemble the side panels and central dividers.
4. Secure the top panel.
5. Install the adjustable shelves using the provided pegs.
6. Attach the door hinges and then the rattan doors with gold pull rings.
7. Install the anti-tip hardware to secure the cabinet to a wall.

Large Buffet Cabinet



Figure 2: Product dimensions: 14.2"D x 55"W x 33.5"H. Ensure adequate space for assembly.

Your browser does not support the video tag.

Video 1: Official SICOTAS Buffet Cabinet Installation Video. This video provides a visual guide for assembling your cabinet, demonstrating each step clearly.

OPERATING INSTRUCTIONS

The SICOTAS Rattan Sideboard Buffet Cabinet is designed for convenient storage and display. Its features include:

- **Four Doors:** Each door opens to reveal enclosed storage space. The doors are equipped with soft-closing hinges to prevent slamming and protect fingers.
- **Adjustable Shelves:** The interior of the cabinet features adjustable shelves, allowing you to customize the storage height to accommodate items of various sizes. Simply remove the shelf pegs and reposition the shelf to your desired height.

- **Open Lower Shelf:** A spacious open shelf at the bottom provides additional storage or display area for items like books, decorative baskets, or shoes.
- **Wide Table Top:** The top surface offers ample space for displaying decor, serving food, or housing small appliances like a coffee maker.

Adjustable Shelf

Adjust the height to meet various storage needs



Figure 3: The adjustable shelves allow for flexible storage configurations within the cabinet.

Spacious Countertop

Offers ample tabletop space for living room



Figure 4: Key features of the cabinet, including the wide tabletop, gold handles, rattan design, sturdy legs, adjustable shelves, and large open shelf.

MAINTENANCE

To ensure the longevity and appearance of your SICOTAS Rattan Sideboard Buffet Cabinet, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Rattan Care:** Gently dust the rattan panels with a soft brush or cloth. Avoid excessive moisture.
- **Spills:** Clean spills immediately to prevent staining, especially on the engineered wood surfaces.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or discoloration of the wood and rattan.
- **Hardware:** Periodically check and tighten all screws and fittings to maintain stability.

TROUBLESHOOTING

If you encounter any issues with your cabinet, refer to the following common troubleshooting tips:

- **Wobbly Cabinet:** Ensure all cam locks and screws are fully tightened. Verify that the cabinet is placed on a level surface. Adjust the leveling feet if present.
- **Doors Not Aligning:** The hinges are adjustable. Loosen the hinge screws slightly, adjust the door position, and then re-tighten. Refer to the hinge adjustment section in your detailed assembly manual for specific instructions.
- **Damaged or Missing Parts:** If any parts arrived damaged or are missing, contact SICOTAS customer support immediately for assistance.

SPECIFICATIONS

Feature	Detail
Brand	SICOTAS
Model Number	SC119
Color	White Cream Oak
Product Dimensions	14.2"D x 55"W x 33.5"H
Item Weight	90 Pounds
Material	Engineered Wood (FSC-certified)
Door Style	Boho (Rattan)
Hardware Color	Gold
Number of Doors	4
Number of Shelves	3 (Adjustable)
Assembly Required	Yes
Installation Type	Freestanding (Wall anchoring recommended)

WARRANTY AND SUPPORT

For customer support, warranty information, or to report any issues with your SICOTAS Rattan Sideboard Buffet Cabinet, please contact SICOTAS directly. Refer to your purchase documentation for specific warranty terms and contact details. Returns are typically accepted within a specified period, as indicated at the time of purchase (e.g., returnable until Jan 31, 2026).

SICOTAS is committed to sustainability, using eco-conscious materials and embracing circular design principles.

Visit the SICOTAS
Store