Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Lava /
- > Lava A5 (2025) Dual SIM Keypad Mobile User Manual

Lava A5

Lava A5 (2025) Dual SIM Keypad Mobile User Manual

INTRODUCTION

This manual provides essential instructions for the proper use and maintenance of your Lava A5 (2025) Dual SIM Keypad Mobile. Please read this guide thoroughly before operating your device to ensure optimal performance and longevity.

The Lava A5 (2025) is a classic keypad phone designed for reliable communication. It features a 2.4-inch display, dual SIM support, a 1200mAh battery, a digital camera, and unique features like UPI support and the BOL (Voice Activated) feature.



Image: Front and back view of the Lava A5 (2025) mobile phone, showcasing its keypad and camera module.

PACKAGE CONTENTS

Upon opening the product packaging, please verify that all items listed below are present and in good condition:

- Lava A5 (2025) Handset
- Power Adapter
- Battery (1 Lithium Ion battery)

DEVICE OVERVIEW

Familiarize yourself with the physical components of your Lava A5 (2025) mobile phone.



Image: Front view of the Lava A5 (2025) mobile phone, highlighting the 2.4-inch display and keypad.



Image: Side view of the Lava A5 (2025) mobile phone, showing its slim profile.

Key Components:

- **Display:** 2.4-inch screen for clear visuals.
- **Keypad:** Physical alphanumeric keypad for input, designed to be dirt-resistant.
- Navigation Key: Central key for menu navigation and selection.
- Call/End Keys: Dedicated keys for initiating and ending calls.
- Camera: Rear-mounted digital camera for capturing photos.
- Speaker: For audio output during calls and multimedia playback.
- Charging Port: For connecting the power adapter.
- 3.5mm Audio Jack: For connecting headphones or earphones.

SETUP

1. Inserting the SIM Card(s) and Battery:

- 1. Carefully remove the back cover of the phone.
- 2. Insert your SIM card(s) into the designated SIM slots. The Lava A5 (2025) supports Dual SIM functionality.

- 3. Insert the 1200mAh Lithium Ion battery into its compartment, ensuring the contacts align correctly.
- 4. Replace the back cover until it clicks securely into place.

2. Charging the Device:

- 1. Connect the power adapter to the charging port on your phone.
- 2. Plug the power adapter into a standard electrical outlet.
- 3. Allow the phone to charge completely before initial use. The battery indicator on the screen will show charging status.

3. Powering On/Off:

- To power on, press and hold the End Call key until the screen illuminates.
- To power off, press and hold the End Call key until the power-off options appear, then select 'Power
 off'.

OPERATING INSTRUCTIONS

Basic Navigation:

- Use the navigation key (up, down, left, right) to move through menus and options.
- Press the center key of the navigation pad to select an option.
- The left and right soft keys (located directly below the display) perform functions indicated on the screen.



Image: Close-up of the Lava A5 (2025) keypad, highlighting its dust-resistant design and large keys for easy operation.

Making and Receiving Calls:

- To make a call: Enter the phone number using the keypad and press the Call key.
- To answer a call: Press the Call key when the phone rings.
- To end a call: Press the End Call key.
- Auto Call Recording: This feature automatically records your phone conversations. Refer to the phone's settings menu to manage this function.

Messaging:

- Navigate to the 'Messages' menu.
- Select 'Write message' to compose a new SMS.
- Enter the recipient's number and your message, then send.



Image: The Lava A5 (2025) display showing larger, clearer menu icons for improved readability and ease of use.

Camera Functionality:

- Access the camera from the main menu.
- Frame your shot using the display.
- Press the center navigation key or a designated camera button to capture a photo.



Image: The Lava A5 (2025) showcasing its digital camera feature, with example photos.

UPI Support:

The Lava A5 (2025) includes built-in UPI support, allowing for easy sending and receiving of money. Access this feature through the dedicated UPI application on your phone's menu.



Image: The Lava A5 (2025) displaying the UPI application on its screen, indicating support for digital payments.

BOL Feature (Voice Activated):

The BOL feature provides voice assistance for various phone functions. It can speak when you press any key and read messages aloud, enhancing accessibility and ease of interaction.

- Keypad Bol: Announces the number or character pressed on the keypad.
- Message Bol: Reads incoming messages aloud.
- Menu Bol: Announces menu options as you navigate.
- Time Bol: Announces the current time.
- Call Bol: Announces incoming caller ID.



Image: Visual representation of the Lava A5 (2025) BOL features, illustrating voice activation for calls, messages, keypad, menu, and time.

Smart Photo Icons:

This feature allows you to assign photos to contacts, making it easier to identify callers visually and initiate calls.



Image: The Lava A5 (2025) display showing contact list with assigned photo icons, simplifying contact identification.

MAINTENANCE

- Cleaning: Use a soft, dry cloth to clean the phone's display and body. Avoid using liquid cleaners or abrasive materials.
- **Battery Care:** To prolong battery life, avoid extreme temperatures. Charge the phone regularly and avoid letting the battery drain completely too often.
- Storage: Store the phone in a cool, dry place away from direct sunlight and moisture.
- **Handling:** Handle the phone with care to prevent physical damage. The keypad is designed to be dirt-resistant, but excessive exposure to dust or debris should be avoided.



Image: Illustration of the Lava A5 (2025) with its 1200mAh battery, emphasizing its extended battery backup capability.

TROUBLESHOOTING

If you encounter issues with your Lava A5 (2025), refer to the following common problems and solutions:

Problem	Possible Solution	
Phone does not power on	Ensure the battery is correctly inserted and fully charged. Connect to the power adapter and try again.	
Low calling sound/volume	Check the volume settings during a call. Ensure the speaker is not obstructed. If using headphones, check their connection and volume.	
Phone switches off automatically	This could indicate a low battery. Charge the phone fully. If the issue persists, contact customer support.	
Memory card not read	Ensure the memory card is inserted correctly. Try reinserting it or using a different compatible memory card.	

Problem	Possible Solution
Difficulty with BOL feature	Ensure the BOL feature is enabled in the phone's settings. Check the language settings for voice output.
Network signal issues	Check if your SIM card is properly inserted. Move to an area with better network coverage. Restart the phone.

SPECIFICATIONS

Feature	Detail
Model Number	A5
Operating System	RTOS
RAM Memory Installed Size	4 MB
Memory Storage Capacity	32 GB (Expandable)
Screen Size	2.4 Inches
Resolution	320 x 240
Battery Power Rating	1200 mAh (Lithium Ion)
Connectivity Technologies	USB
Special Features	Dual SIM, Expandable Memory, UPI, BOL Feature, Auto Call Recording
Audio Jack	3.5 mm
Item Weight	87 g
Product Dimensions	4.56 x 0.58 x 2.92 cm
Manufacturer	Lava, Lava International Ltd.
Country of Origin	India

WARRANTY AND SUPPORT

Your Lava A5 (2025) mobile phone is covered by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Lava customer support. Contact details can typically be found on the manufacturer's official website or on the product packaging.

