

[Manuals.plus](#) /

› [gladswing](#) /

› gladswing 3-in-1 Wooden Baby Bouncer and Rocker Chair Instruction Manual

gladswing B0DSVQNGMM

gladswing 3-in-1 Wooden Baby Bouncer and Rocker Chair Instruction Manual

Model: B0DSVQNGMM

INTRODUCTION

This manual provides essential information for the safe and proper use, assembly, and maintenance of your gladswing 3-in-1 Wooden Baby Bouncer and Rocker Chair. Please read all instructions carefully before use and retain this manual for future reference.

The gladswing 3-in-1 Wooden Baby Bouncer and Rocker Chair is designed to adapt to your child's growth, offering multiple modes from infant bouncer to toddler chair. It features an adjustable backrest, a secure 5-point harness, and a comfortable headrest and cushion support.



Image: The gladswing 3-in-1 Wooden Baby Bouncer and Rocker Chair, featuring a beige cushion and wooden frame, positioned in a home environment.

IMPORTANT SAFETY INFORMATION

WARNING: THIS PRODUCT SHOULD NOT REPLACE RESPONSIBLE ADULT SUPERVISION AND IS NOT FOR SLEEPING PURPOSES. NEVER leave the child unattended.

- Always use the 5-point safety harness to secure your child.
- Ensure the chair is placed on a flat, stable surface.
- Do not use this product if any components are damaged or missing.
- Keep children away from the product during assembly.
- Maximum weight recommendation: 40 lbs.
- Suitable for babies aged 6 to 48 months.

SETUP AND ASSEMBLY

The gladswing 3-in-1 Wooden Baby Bouncer and Rocker Chair is designed for straightforward assembly. All necessary parts and clear instructions are provided.

1. Unpack all components and verify against the parts list (not provided in this manual, refer to packaging).
2. Assemble the wooden frame according to the included diagrams. Ensure all screws are tightened securely. The wood is of high quality with precise cuts and sanded edges.
3. Attach the padded cushion and headrest to the assembled frame.
4. Ensure the 5-point safety harness is correctly threaded and adjusted.



Image: Components of the gladswing 3-in-1 Wooden Baby Bouncer and Rocker Chair laid out for assembly. The image shows various wooden pieces, screws, and the padded seat cushion, indicating the parts involved in the setup process.

OPERATING INSTRUCTIONS

Multiple Modes and Adjustments

This versatile chair offers three modes to accommodate your child's developmental stages:

- **Infant Bouncer:** Provides a gentle rocking motion for soothing infants.
- **Baby Rocker/Chair:** A slightly more upright position for older babies.
- **Kids Rocker/Chair:** A fixed, upright chair for toddlers during playtime or reading.

3 Modes Grow Up With Your Kids



Image: This diagram illustrates the three adjustable modes of the gladswing 3-in-1 Wooden Baby Bouncer and Rocker Chair: Infant Bouncer, Baby Rocker/Chair, and Kids Rocker/Chair, demonstrating its adaptability as the child grows. To adjust the backrest angle, locate the adjustment mechanism at the rear of the chair. Carefully lift and slide the support bar into the desired slot. Ensure it is securely locked in place before placing your child in the chair. The chair can be adjusted to a more reclined position for infants or a more upright position for toddlers.

Baby Bouncer Switch to Kids Chair




Image: A close-up view of the adjustment mechanism on the gladswing 3-in-1 Wooden Baby Bouncer and Rocker Chair, showing how to switch it from a bouncer to a fixed kids chair by engaging or disengaging the rocking base.

Safety Harness and Headrest

The chair is equipped with a 5-point safety harness to keep your child secure. Adjust the shoulder straps to ensure a snug and comfortable fit. The headrest is also height-adjustable to provide optimal support for your baby's head and neck, promoting proper posture.

Safety First Fits the Baby's Body



Height-adjustable
shoulder straps
ensure the perfect
fit.



Safer five-point
safety harness.

Image: This image highlights the 5-point safety harness and height-adjustable shoulder straps of the gladswing baby bouncer, emphasizing the secure fit for the child.

Height Adjustable Headrest



Provides Comfort & Head Support

Image: A child is shown comfortably seated in the gladswing baby bouncer, demonstrating the effectiveness of the height-adjustable headrest in providing proper head and neck support.

MAINTENANCE

- **Cushion Care:** The soft, cozy cushion is removable for easy cleaning. Follow the care instructions on the label for washing.
- **Wooden Frame Care:** The natural pine and birch wood frame can be wiped clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Harness Maintenance:** Periodically check the safety harness for wear and tear. Clean with mild soap and water if necessary.

TROUBLESHOOTING

If you encounter any issues with your gladswing 3-in-1 Wooden Baby Bouncer and Rocker Chair, please refer to the following common solutions:

- **Chair not rocking smoothly:** Ensure the chair is on a level surface and that the rocking base is free from obstructions. Check that all assembly screws are properly tightened.
- **Harness not securing properly:** Verify that the harness straps are correctly threaded through the

slots and that the buckle engages fully. Adjust straps for a snug fit.

- **Stability concerns:** Double-check all connections and ensure the adjustment bar for the backrest is firmly seated in its chosen slot.

For persistent issues, please contact customer support.

SPECIFICATIONS

Feature	Detail
Product Dimensions	27.6 x 15.8 x 21.7 inches (L x W x H)
Maximum Weight Recommendation	40 Pounds
Material Type	Wood (Pine and Birch), Cotton, Polyester
Item Weight	10.67 pounds
Age Range	6 to 48 months
Safety Certifications	ASTM, CPC
Portability	Yes

Natural Wood Material

Suitable for Baby to Toddler From 6-48 Months



Image: This image displays the gladswing 3-in-1 Wooden Baby Bouncer and Rocker Chair with key dimensions labeled, showing a child seated to provide a sense of scale and usage.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided with your product packaging or visit the official gladswing website. Please retain your proof of purchase for any warranty claims.