



[Manuals.plus](#) /

> [VONZOY](#) /

> VONZOY 3-Piece Outdoor Wicker Patio Set: 360° Swivel Chairs and Wicker Table User Manual

VONZOY

VONZOY 3-Piece Outdoor Wicker Patio Set User Manual

Model: B0DSVTV1ZP

INTRODUCTION

Thank you for choosing the VONZOY 3-Piece Outdoor Wicker Patio Set. This manual provides essential information for the safe assembly, operation, and maintenance of your new patio furniture. Please read these instructions carefully before assembly and retain this manual for future reference.



The VONZOY 3-Piece Outdoor Wicker Patio Set, featuring two 360° swivel chairs and a matching wicker table.

SAFETY INFORMATION

To ensure safe use and prevent injury or damage, please adhere to the following safety guidelines:

- Always assemble the product on a soft, non-abrasive surface to prevent scratches.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum weight capacity of 400 pounds per chair.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Avoid placing hot items directly on the tempered glass table surface without protection.
- Do not stand on the chairs or table.
- Use caution when rocking or swiveling to avoid collisions with surrounding objects or people.

PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or

damaged, please contact customer service immediately.

- 2 x Swivel Chairs (unassembled)
- 1 x Wicker Table (unassembled)
- 2 x Seat Cushions (Blue)
- 2 x Back Cushions (Blue)
- 1 x Hardware Pack (bolts, washers, nuts, Allen wrench)
- 1 x Assembly Manual



All components included in the VONZOY 3-Piece Outdoor Wicker Patio Set.

SETUP AND ASSEMBLY

Follow these steps to assemble your VONZOY patio set. It is recommended to have two people for assembly.

Chair Assembly:

1. Carefully unpack all chair components and lay them on a soft, flat surface.
2. Attach the chair backrest to the seat frame using the provided bolts and Allen wrench. Do not fully tighten yet.
3. Connect the armrests to both the backrest and seat frame. Ensure all holes align before inserting bolts.
4. Attach the swivel base to the assembled chair frame. Ensure the base is oriented correctly for smooth rotation.
5. Once all components are loosely assembled, gradually tighten all bolts evenly until secure. Do not overtighten.
6. Place the seat and back cushions onto the assembled chair.

Table Assembly:

1. Unpack the table components.
2. Attach the table legs to the tabletop frame.
3. Secure the lower shelf to the table legs.
4. Tighten all bolts evenly.
5. Carefully place the tempered glass top into the table frame.



Visual guide for chair assembly steps.

360° Swivel & 15° Gentle Rocking

Our Swivel Chair Allows You To Feel Comfortable From Different



Detailed assembly sequence for the patio chair.

Your VONZOY patio chairs are designed for comfort and versatility, featuring both 360° swivel and 15° gentle rocking motions.

360° Swivel Function:

The chairs are equipped with a smooth 360° swivel mechanism. To rotate, simply apply gentle pressure with your feet or body in the desired direction. The swivel function allows for easy conversation and viewing in any direction without needing to reposition the entire chair.

15° Gentle Rocking Motion:

In addition to swiveling, the chairs offer a slight 15° rocking motion for added relaxation. Lean back gently to engage the rocking feature. This motion is designed to be subtle and comfortable, enhancing your lounging experience.

360° Swivel & 15° Gentle Rocking

Enjoy Freedom and Comfort in Every Direction




Illustration of the chair's swivel and rocking capabilities.

Product Design Details



▶ Handmade Rattan Weaving

High Density Memory Foam



▶ Waterproof and Breathable Fabric

Visual demonstration of the chair's swivel and gentle rocking motion.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your patio set.

Frame Care:

- Wipe the aluminum frame with a soft, damp cloth and mild soap. Rinse thoroughly and dry completely to prevent water spots.
- Avoid using harsh chemicals, abrasive cleaners, or wire brushes, as these can damage the wood-grain finish and powder coating.
- Periodically check all bolts and connections and tighten if necessary to maintain stability.


Cushion Care:

- The cushions are made with water-resistant fabric. For light cleaning, wipe with a damp cloth.
- For deeper cleaning, the cushion covers feature hidden zippers for easy removal. Hand wash with mild soap and cold water, or machine wash on a gentle cycle. Air dry only; do not tumble dry.
- Store cushions indoors during prolonged periods of rain or extreme weather to maintain their quality and extend their lifespan.

Hidden Zipper for Easy Removal and Cleaning



Hidden zipper for easy cushion cover removal and cleaning.



Water Resistant Fabric

The water-resistant fabric of the cushions repels moisture.

TROUBLESHOOTING

If you encounter any issues with your patio set, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Chair wobbles or feels unstable.	Loose bolts; uneven surface.	Ensure all assembly bolts are securely tightened. Move the chair to a flat, even surface.
Swivel mechanism is stiff or noisy.	Lack of lubrication; debris in mechanism.	Apply a silicone-based lubricant to the swivel mechanism. Clean any visible debris from the base.
Cushions appear flattened or misshapen.	Prolonged compression; exposure to moisture.	Fluff cushions regularly. Ensure cushions are dry before storing. High-density foam should regain shape over time.
Table glass top shifts.	Missing or worn suction cups/spacers.	Ensure the glass top is properly seated. Check if any rubber spacers or suction cups (if included) are missing or need replacement.

SPECIFICATIONS

Detailed specifications for the VONZOY 3-Piece Outdoor Wicker Patio Set.

Feature	Detail
Product Dimensions (L x W x H)	20.08 x 22.84 x 33.86 inches (per chair)
Item Weight	59.5 pounds (total set)
Material	Powder-coated Metal Frame, Handwoven Wicker, High-Density Foam Cushions, Tempered Glass Tabletop
Color	Blue Cushions, Wood-grain Frame, Brown Wicker
Chair Weight Capacity	Up to 400 pounds per chair

Feature	Detail
Swivel Angle	360°
Rocking Angle	15°

Dimensions

 (Unit:Inch)



Detailed dimensions of the chair and table, along with chair weight capacity.

WARRANTY AND SUPPORT

VONZOY stands behind the quality of its products. This product comes with a standard manufacturer's warranty covering defects in materials and workmanship from the date of purchase. For specific warranty terms and conditions, please refer to the warranty card included in your package or visit the official VONZOY website.

Customer Support:

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact our customer service team. Our dedicated support staff is available to help resolve any concerns promptly.

Email: support@vonzoy.com

Phone: Please refer to the contact information provided on the product packaging or warranty card.

Online: Visit the [VONZOY Store on Amazon](#) for FAQs and additional product information.

© 2025 VONZOY. All rights reserved.