

Toxicologist M5

Toxicologist M5 Electric Nail Clipper User Manual

Model: M5 | Brand: Toxicologist

1. INTRODUCTION

The Toxicologist M5 Electric Nail Clipper is a versatile and safe grooming tool designed for individuals of all ages, including babies, adults, and seniors. This device offers automatic nail trimming and polishing functions, aiming to provide a gentle and precise nail care experience. Its compact design and user-friendly features make it suitable for both home and travel use.

2. PRODUCT FEATURES

- **2-in-1 Trimming and Polishing:** This device automatically trims nails and includes a polishing function for smooth, neat results.
- **Simple Operation:** Designed for ease of use, simply open the lid, press the power button, and begin trimming. Suitable for both left-handed and right-handed users.
- **Portable Design:** With dimensions of 64x32x74mm and a weight of 85g, the clipper is compact and lightweight, making it ideal for travel and on-the-go use.
- **Integrated Nail Catcher:** A built-in compartment collects trimmed nail debris, ensuring a clean grooming experience.
- **Adjustable Speed & Type-C Charging:** Features two adjustable speeds to accommodate different nail trimming needs. It is equipped with a Type-C charging port and a 300mAh battery for convenient and long-lasting use.
- **Magnetic Cover & Quiet Operation:** A magnetic cover prevents accidental activation and protects the blade. The low-noise motor allows for quiet operation, suitable for use without disturbance.
- **Auxiliary LED Light:** An integrated LED light illuminates the nail area, assisting with precise trimming even in dim lighting conditions.



Name: Electric nail clippers

Model: M5

Battery capacity: 300mAh

Input: 5V/1A

Charging Interface: TYPE-C

Color: White Gray

Figure 1: The electric nail clipper features an automatic nail debris organizer for easy cleanup.

One-touch automatic trimming says goodbye
to traditional nail clippers

All-in-One Polish for Smooth, Rounded Nails



Figure 2: The auxiliary LED light provides illumination for trimming in various lighting conditions.

3. SETUP

1. **Unboxing:** Carefully remove the Electric Nail Clipper from its packaging.
2. **Initial Charge:** Before first use, fully charge the device using the provided Type-C charging cable. Connect the cable to the Type-C port on the device and a compatible USB power source. The charging indicator light will show charging status.
3. **Familiarization:** Open the magnetic top cover to expose the trimming head. Observe the internal blade and the LED light.

Compact and portable free trimming anytime, anywhere

Get rid of the bulky weight and put it in your pocket to hold it easily with one hand without taking up much space.



Figure 3: The device charges via a Type-C port for convenience.

4. OPERATING INSTRUCTIONS

1. **Power On/Off:** Long press the power button (located on the device body) to turn the clipper on or off. The LED light will illuminate when the device is active.
2. **Adjusting Speed:** While the device is on, tap the power button to cycle between the two available trimming speeds.
3. **Nail Trimming:** Gently place your fingernail or toenail into the trimming slot. Ensure the LED light is shining directly onto your nail for optimal visibility. Move the nail slowly against the rotating blade to trim. The device is designed to safely trim without cutting skin.
4. **Nail Polishing:** The device also provides a polishing action as it trims, leaving nails smooth. No separate polishing step is typically required.
5. **For Children and Infants:** When trimming nails for babies or young children, ensure they are calm. The low-noise operation is designed to minimize disturbance, even during sleep. Always supervise children during use.

Auxiliary Lighting Trimming even in dim light

The head of the knife to increase the auxiliary lighting, power on automatically open simple and convenient, the night does not disturb, do not say shear



Figure 4: Gently guide your nail into the trimming slot for safe and effective trimming.

Magnetic top cover leads in automatic

Magnetic force full put down automatic
adsorption open and close exceptionally easy



One charge,
long-lasting battery life



Type-c ultra long battery life

Faster charging and longer battery life



Figure 5: The quiet operation is suitable for trimming a baby's nails without causing disturbance.

5. MAINTENANCE

1. **Emptying Nail Debris:** After use, slide open the back storage design (nail catcher) to empty collected nail clippings. Dispose of the debris properly.
2. **Cleaning the Trimming Head:** Use a small brush (not included) to gently clean any remaining nail dust from the trimming head. Ensure the device is turned off before cleaning.
3. **General Cleaning:** Wipe the exterior of the device with a soft, dry cloth. Do not use harsh chemicals or immerse the device in water.

Automatic nail debris organizer easier to clean up

Trim your nails in public
without embarrassment



Figure 6: The internal design includes a nail catcher for easy maintenance.

6. TROUBLESHOOTING

- **Device Not Turning On:** Ensure the device is fully charged. Connect it to a Type-C charger and allow sufficient time for charging.
- **Ineffective Trimming:**
 - Ensure the nail is properly positioned against the rotating blade.
 - Check if the battery is low; a low battery can reduce motor speed.
 - Clean the trimming head to remove any accumulated debris that might hinder performance.
- **Unusual Noise:** If the device makes unusual noises, turn it off immediately and check for any obstructions in the trimming head. If the issue persists, discontinue use.

7. SPECIFICATIONS

Model Name	Electric Nail Clipper
Model Number	M5 (also referred to as m7 in some specifications)

Battery Capacity	300mAh Lithium Ion (included)
Charging Interface	Type-C
Input Voltage/Current	5V/1A
Dimensions	64 x 32 x 74 mm (approx. 4.25 x 3.86 x 1.54 inches)
Weight	85g (approx. 0.16 Kilograms / 5.61 ounces)
Blade Material	Alloy Steel
Target Audience	Adults, Elderly, Kids



Figure 7: Key dimensions and specifications of the M5 Electric Nail Clipper.

8. SAFETY INFORMATION

- Keep the device out of reach of young children when not in use.
- The magnetic cover helps prevent accidental activation; always ensure it is properly closed when storing.

- Do not attempt to disassemble or modify the device.
- Avoid contact with water or other liquids to prevent electrical shock or damage.
- Use only for its intended purpose of trimming and polishing nails.
- If the device is damaged, discontinue use immediately.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. *(Note: This disclaimer was found in the product data and is included as provided, though its relevance to a nail clipper is unusual.)*

9. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Toxicologist M5 Electric Nail Clipper, please contact the manufacturer or your point of purchase. Please refer to your purchase documentation for specific warranty details.
