SOWO Soundwave MagePro

SOWO Wireless Dual Bluetooth Speakers Set User Manual

Model: Soundwave MagePro | Brand: SOWO

Introduction

This user manual provides detailed instructions for the SOWO Wireless Dual Bluetooth Speakers Set, Model Soundwave MagePro. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your speakers. These speakers are designed to deliver high-fidelity stereo sound with smart pairing capabilities, suitable for various indoor and outdoor environments.

What's in the Box

- Bluetooth speaker x 2
- Adjustable stand x 2
- Clip x 2
- Charging cable x 2
- Instructions manual



Figure 1: Included components and portable case.

Product Overview

The SOWO Wireless Dual Bluetooth Speakers are designed for versatility and high-quality audio. Each speaker is compact and features a durable build, with intuitive controls. The set includes two adjustable stands for optimal sound positioning and portability.



Figure 2: SOWO Wireless Dual Bluetooth Speakers with adjustable stands.



Figure 3: Adjustable stands allow for optimal sound positioning.

Setup

1. Charging the Speakers

Before first use, fully charge both speakers. Connect the provided charging cables to the charging ports on each speaker and to a compatible USB power source (e.g., computer USB port, USB wall adapter). The charging time is approximately 2.5 hours for a full charge. A full charge provides up to 24 hours of battery life, depending on volume levels.

2. Assembling the Stands

The adjustable stands are designed for quick and easy setup. Simply attach each speaker to the top of its respective stand. The stands can be adjusted to various heights and angles to optimize sound projection.



Figure 4: Step-by-step guide for speaker and stand assembly.

Operating Instructions

1. Power On/Off

To power on each speaker, press and hold the power button located on the side of the speaker until you hear an audible prompt or see an indicator light. To power off, press and hold the power button again.

2. Bluetooth Pairing (Single Speaker)

1. Ensure the speaker is powered on.
2. Activate Bluetooth on your device (smartphone, tablet, laptop, etc.).
3. Search for "Soundwave MagePro" in your device's Bluetooth settings and select it to connect.
4. Once connected, the speaker will indicate successful pairing.

3. Smart Pairing (Dual Speakers for Stereo Sound)

For an immersive stereo experience, you can pair both SOWO speakers together. This feature creates independent left and right audio channels, providing 3D surround sound.

1. Power on both speakers.
2. The speakers will automatically attempt to pair with each other. A successful connection will be indicated by an audible prompt.
3. Once the two speakers are paired with each other, connect your device to one of the speakers via Bluetooth as described in "Bluetooth Pairing (Single Speaker)". The audio will then play in stereo across both speakers.

Note: Only two speakers can be paired together for stereo sound. More than two speakers cannot be paired simultaneously.



Figure 5: Stereo sound with complete vocal range for an immersive experience.



Figure 6: Dual speakers providing stereo sound for an enhanced viewing experience.



Figure 7: Low latency Bluetooth 5.3 technology ensures audio-video synchronization.

4. Hands-free Calling

The speakers feature a built-in microphone, allowing you to answer calls directly through the speaker when connected to your smartphone. Press the multi-function button (usually the play/pause button) to answer or end a call.

5. Adjusting Volume and Playback

Use the volume buttons (+/-) on the speaker to adjust the audio level. The same buttons may also control track skipping (long press) depending on the model. Refer to the specific button layout on your speaker for precise controls.

Maintenance

To ensure the longevity and optimal performance of your SOWO speakers, follow these maintenance guidelines:

- **Cleaning:** Wipe the speakers with a soft, dry cloth. Avoid using abrasive cleaners or solvents.

- **Water Resistance:** The speakers are IP67 waterproof. While they can withstand splashes and brief immersion, avoid prolonged submersion or exposure to high-pressure water jets. Ensure charging ports are dry before charging.
- **Storage:** Store the speakers in a cool, dry place away from extreme temperatures and direct sunlight. Use the provided portable case for safe transport and storage.
- **Battery Care:** For best battery life, avoid fully discharging the speakers frequently. Charge them regularly, even if not in use for extended periods.



Figure 8: The speakers are designed for portability and outdoor use, featuring IP67 waterproofing.

Troubleshooting

Problem	Possible Cause	Solution
Speakers do not power on.	Low battery.	Charge the speakers fully.

Problem	Possible Cause	Solution
Cannot pair with Bluetooth device.	Bluetooth not enabled on device; speakers too far; speakers already paired.	Ensure Bluetooth is on and within range (39 feet). Disconnect from other devices. Restart speakers and device.
No sound or low volume.	Volume too low; device not connected; audio source issue.	Increase volume on both speaker and device. Re-pair the device. Check audio source.
Dual speakers not pairing together.	One speaker not powered on; out of range; interference.	Ensure both speakers are powered on and close to each other. Restart both speakers.

Specifications

Feature	Detail
Model Name	Soundwave MagePro
Speaker Type	Outdoor
Connectivity Technology	Bluetooth 5.3
Audio Output Mode	Stereo
Speaker Maximum Output Power	12 Watts
Battery Life	Up to 24 Hours (at 50% volume)
Charging Time	2.5 Hours
Battery Capacity	1500 Milliamp Hours
Water Resistance Level	IP67 Waterproof
Bluetooth Range	39 Feet
Product Dimensions	11.7"D x 8"W x 3"H
Item Weight	3.01 pounds
Built-in Microphone	Yes (for hands-free calls)

Warranty Information

SOWO provides a limited warranty for this product. Please refer to the warranty card included in your package or visit the official SOWO website for detailed warranty terms and conditions. Keep your purchase receipt as proof of purchase for any warranty claims.

Customer Support

For any questions, technical assistance, or support regarding your SOWO Wireless Dual Bluetooth Speakers Set, please contact SOWO customer service. You can find contact information on the official SOWO website or through the retailer where you purchased the product.

You may also visit the SOWO Store on Amazon for more information and product updates.

© 2025 SOWO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question