

Toxicologist M7

Toxicologist M7 3-in-1 Electric Nail Clipper User Manual

Model: M7

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Toxicologist M7 3-in-1 Electric Nail Clipper. Please read this manual thoroughly before operating the device and retain it for future reference.

The Toxicologist M7 is an innovative device designed for automatic nail trimming and polishing, featuring an integrated nail catcher. It is suitable for individuals of all ages, including children, adults, and seniors, offering a convenient and mess-free nail care experience.

2. SAFETY INFORMATION

To ensure safe operation and prevent injury or damage, please observe the following safety precautions:

- Keep the device out of reach of infants and young children when not in use.
- Do not disassemble, repair, or modify the device yourself. Contact customer support for assistance.
- Avoid contact with water or other liquids. This device is not waterproof.
- Do not use the device if it appears damaged or is not functioning correctly.
- Ensure the charging port is dry before connecting the Type-C charging cable.
- Use only the provided or a certified Type-C charging cable.
- Do not force nails into the trimming slot. Allow the device to trim naturally.
- Supervise children and individuals with limited dexterity during use.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- Toxicologist M7 Electric Nail Clipper
- Type-C Charging Cable

4. PRODUCT FEATURES AND COMPONENTS

Familiarize yourself with the key features and components of your electric nail clipper.



Product name: Multi-function electric nail clippers

Model: M7

Battery capacity: 500mAh

Input: 5V/1A

Charging Interface: TYPE-C

Color: White Gray
Dark Gray

Material: ABS+PC
spraying metal paint

Size: 86*30*59mm

Image 4.1: Diagram illustrating the components of the Toxicologist M7 Electric Nail Clipper, including the cover, polish nail area, nail clippers, floodlight, polish switch, trim switch, and charging port. Dimensions are also shown.

- **Cover:** Protects the trimming and polishing mechanisms.
- **Polish Nail Area:** Integrated surface for smoothing nail edges after trimming.
- **Nail Clippers:** Automatic rotating blade for safe and precise nail trimming.
- **Floodlight (Auxiliary Lighting):** Illuminates the nail area for improved visibility, especially in dim

conditions.

- **Polish Switch:** Activates the nail polishing function.
- **Trim Switch:** Activates the nail trimming function.
- **Charging Port:** Type-C port for recharging the internal battery.
- **Nail Catcher:** Internal compartment that collects trimmed nail debris.

Auxiliary Lighting trimming even when the light is dim

The head of the knife to increase the auxiliary lighting illumination, power on automatically open simple and convenient, the night does not disturb, do not say shear



Image 4.2: The auxiliary lighting feature of the M7 Electric Nail Clipper, shown illuminating the nail area for enhanced visibility during use.

Shock absorption and low noise Cutting baby's nails in peaceful sleep

High-performance motor, light sound damping,
sound size as a whisper.



Image 4.3: The M7 Electric Nail Clipper features a low-noise motor, allowing for quiet operation, suitable for use even when a child is sleeping nearby.

5. SETUP

The Toxicologist M7 Electric Nail Clipper comes ready for use after an initial charge.

1. **Unpack:** Carefully remove the nail clipper and all accessories from the packaging.
2. **Initial Charge:** Before first use, fully charge the device. Refer to the "Charging" section for instructions.
3. **Inspect:** Check the device for any visible damage. If damaged, do not use and contact customer support.

6. OPERATING INSTRUCTIONS

Follow these steps for safe and effective nail trimming and polishing.



Image 6.1: A user's finger being gently guided into the trimming slot of the M7 Electric Nail Clipper.

6.1 Trimming Nails

1. **Open Cover:** Gently slide or lift the protective cover to expose the trimming slot.
2. **Power On:** Press the Trim Switch (usually marked with a scissor icon or similar) to activate the trimming function. The auxiliary light will also turn on.
3. **Insert Nail:** Carefully insert your fingernail or toenail into the trimming slot. Do not force it. The device will automatically trim the nail.
4. **Move Slowly:** Gently move your finger or toe to allow the clipper to trim the entire nail edge. Avoid rapid movements.
5. **Repeat:** Repeat for all nails.
6. **Power Off:** Press the Trim Switch again to turn off the device.

6.2 Polishing Nails

After trimming, you can use the polishing function for a smooth finish.

1. **Activate Polishing:** Press the Polish Switch (usually marked with a polishing icon or similar) to activate the polishing function.

2. **Polish Nail:** Gently rub the trimmed edge of your nail against the polishing surface.
3. **Power Off:** Press the Polish Switch again to turn off the polishing function.

6.3 Speed Adjustment

The device features 2 adjustable speeds for different nail types and user preferences.

- To switch between speeds, press the Trim Switch briefly while the device is on. The indicator light may change or flash to indicate the current speed setting.
- Use a lower speed for delicate nails (e.g., baby nails) and a higher speed for thicker adult nails.

7. CHARGING

The Toxicologist M7 is equipped with a rechargeable Lithium-Ion battery.

1. **Connect Cable:** Insert the Type-C end of the charging cable into the charging port on the device.
2. **Connect to Power:** Plug the USB-A end of the charging cable into a compatible USB power adapter (e.g., phone charger, computer USB port) or a power bank.
3. **Charging Indicator:** The indicator light on the device will illuminate or change color to show that it is charging.
4. **Full Charge:** Once fully charged, the indicator light will change again or turn off. Disconnect the device from the charger.

Note: A full charge typically takes approximately 1-2 hours and provides long-lasting use.

8. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene.

1. **Empty Nail Catcher:** After each use, or when the nail catcher is full, gently open the back storage design or designated compartment to empty the collected nail clippings. Dispose of clippings responsibly.
2. **Clean Trimming Head:** Use a small brush (not included) to gently remove any remaining debris from the trimming head. Do not use water or harsh chemicals.
3. **Wipe Exterior:** Wipe the exterior of the device with a soft, dry cloth.
4. **Storage:** Store the device in a cool, dry place, away from direct sunlight and moisture.

9. TROUBLESHOOTING

If you encounter issues with your Toxicologist M7, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully using the Type-C cable.
Nails are not trimming effectively.	Nail catcher is full; trimming head is clogged; incorrect speed setting.	Empty the nail catcher. Clean the trimming head. Try a higher speed setting.

Problem	Possible Cause	Solution
Device makes unusual noise.	Debris in the trimming mechanism.	Turn off the device and carefully clean the trimming head.
Device not charging.	Cable or adapter issue; charging port dirty.	Ensure the Type-C cable is securely connected. Try a different USB adapter or cable. Check for debris in the charging port.

If the problem persists after attempting these solutions, please contact Toxicologist customer support for further assistance.

10. SPECIFICATIONS

Detailed technical specifications for the Toxicologist M7 Electric Nail Clipper:

- **Model:** M7
- **Brand:** Toxicologist
- **Functions:** 3-in-1 (Trimming, Polishing, Nail Catcher)
- **Speed Settings:** 2-Speed Adjustable
- **Battery Type:** 1 Lithium Ion (included)
- **Battery Capacity:** 500mAh
- **Charging Interface:** Type-C
- **Input:** 5V/1A
- **Material:** Metal, Plastic (ABS+PC spraying metal paint)
- **Blade Material:** Alloy Steel
- **Blade Edge:** Curved
- **Dimensions:** 86mm x 30mm x 59mm (approximately 3.39 x 1.18 x 2.32 inches)
- **Weight:** Approximately 85g (0.19 lbs)
- **Color:** Grey (M7)

11. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Toxicologist customer service directly. Keep your purchase receipt as proof of purchase.

Customer Support: Please visit the official Toxicologist website or contact your retailer for support options.