Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Happybuy /
- Happybuy Zero Gravity Chair HQB-FAN003 User Manual

Happybuy HQB-FAN003

Happybuy Zero Gravity Chair User Manual

Model: HQB-FAN003

1. Introduction

This manual provides essential instructions for the safe and effective use of your Happybuy Zero Gravity Chair, Model HQB-FAN003. Please read this manual thoroughly before assembly and operation, and retain it for future reference.

The Happybuy Zero Gravity Chair is designed for relaxation, offering adjustable recline positions for both indoor and outdoor use. It features a sturdy frame, a comfortable cushion, and convenient accessories.

2. SAFETY INFORMATION

Your Happybuy Zero Gravity Chair is designed with safety and durability in mind. Please adhere to the following guidelines to ensure safe operation and longevity of the product:

- Weight Capacity: Do not exceed the maximum weight capacity of 500 lbs (226.8 kg). Overloading can cause damage to the chair and potential injury.
- Stable Surface: Always place the chair on a flat, stable, and non-slip surface to prevent tipping.
- Children and Pets: Keep children and pets away from the chair during adjustment to prevent pinching or injury.
- Adjustment Safety: Ensure the locking mechanisms are fully engaged after adjusting the recline
 position to prevent accidental movement. The chair features 8mm aluminum locks and a safety pin
 mechanism for secure transitions.
- **Inspection:** Regularly inspect the chair for any signs of wear, damage, or loose components, especially the double-layer elastic cords and frame connections. Do not use the chair if it is damaged.
- **Proper Use:** Use the chair only for its intended purpose of seating and reclining. Avoid standing on the chair or using it as a step stool.




Figure 2.1: Illustration highlighting the robust construction of the chair, including the triangular frame, thick square steel tubing, double-layer elastic cords, and aluminum alloy lock, supporting up to 500 lbs.

3. PACKAGE CONTENTS

Verify that all components listed below are present in your package:

- 1 x Zero Gravity Chair Frame
- 1 x Removable 10cm Thick Cushion
- 1 x Headrest Pillow
- 1 x Detachable Tray (with Cup Holder and Phone Holder)
- 1 x Eye Mask
- 1 x Pair of Earplugs



Flat: 62.6 × 32.48 × 31.3 in / 1590 × 825 × 795 mm

Folded: 36.02 × 32.48 × 5.91 in / 915 × 825 × 150 mm

Figure 3.1: All included components of the Happybuy Zero Gravity Chair, Model HQB-FAN003. This image displays the chair, a detachable tray with cup and phone holders, a headrest, an eye mask, and a pair of earplugs, alongside key dimensions.

4. SETUP INSTRUCTIONS

- 1. **Unfold the Chair:** Carefully remove the chair from its packaging. Hold the frame and gently pull the chair open until it is fully extended. Ensure all legs are firmly on the ground.
- 2. **Attach the Cushion:** Place the thick cushion onto the chair frame. The cushion typically has ties or elastic bands to secure it to the frame, preventing it from slipping.
- 3. **Position the Headrest:** Slide the headrest pillow onto the top portion of the chair back. It is usually adjustable to your preferred height.
- 4. **Attach the Detachable Tray:** Locate the attachment points on the side of the chair armrest. Align the tray with these points and securely clip or slide it into place. Ensure it is stable before placing items on it.



Figure 4.1: The Happybuy Zero Gravity Chair fully assembled, showcasing the cushion, headrest, and detachable side tray with cup and phone holders.

5. OPERATING INSTRUCTIONS

1. Adjusting Recline Position:

To recline, gently push back on the chair while lifting your feet. The chair will smoothly transition from an upright position (approximately 90°) to a fully reclined zero-gravity position (up to 170°). Find your desired angle by shifting your body weight.



Figure 5.1: Illustration of the chair's adjustable recline angles, ranging from 90° (upright) to 170° (fully reclined).

2. Locking the Position:

Once you have found your preferred recline angle, locate the locking levers on both armrests. Push the levers downwards to engage the lock and secure the chair in position. Ensure both locks are fully engaged before relaxing.



Figure 5.2: Detail of the aluminum alloy lock mechanism, designed for stability and safety during recline.

3. Unlocking and Returning Upright:

To change the recline angle or return to an upright position, lift the locking levers upwards to disengage the locks. Gently shift your weight forward to bring the chair back to an upright position.

4. Using the Detachable Tray:

The side tray provides convenient access to beverages and your phone. Place drinks in the cup holder and your phone in the designated slot. Do not overload the tray.

6. MAINTENANCE

- Cleaning the Frame: Wipe the metal frame with a damp cloth and mild soap. Dry thoroughly to prevent rust. Avoid abrasive cleaners.
- Cleaning the Cushion: The cushion is removable. Spot clean with a mild detergent and water. For deeper cleaning, follow the care instructions on the cushion's label. Ensure the cushion is completely dry before reattaching or storing.
- **Storage:** When not in use, especially during inclement weather or off-season, fold the chair for compact storage. Store in a dry, protected area to prolong its lifespan.
- **Elastic Cords:** Periodically check the elastic cords for wear or damage. Replace if necessary to maintain proper support and function.



Figure 6.1: The Happybuy Zero Gravity Chair in its folded state, illustrating its compact design for easy storage.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair does not recline smoothly.	Locking levers are engaged.	Ensure both locking levers are fully disengaged (lifted upwards) before attempting to recline.
Chair feels unstable or wobbly.	Not placed on a flat surface; loose components.	Move the chair to a flat, even surface. Inspect all bolts and connections for tightness.
Cushion slips off the chair.	Cushion not properly secured.	Ensure all ties or elastic bands on the cushion are securely fastened to the chair frame.
Locking mechanism does not hold position.	Levers not fully engaged; worn mechanism.	Push the locking levers firmly downwards until they click into place. If the issue persists, contact customer support.

8. SPECIFICATIONS

Model Number	HQB-FAN003	
Brand	Happybuy	
Color	Black	
Net Weight	25.13 lbs (11.4 kg)	
Weight Capacity	500 lbs (226.8 kg)	
Adjustable Angle	90° - 170°	
Product Dimensions (Back Vertical)	34.05"D x 32.48"W x 43.7"H (865 x 825 x 1110 mm)	
Product Dimensions (Flat)	62.6"D x 32.48"W x 31.3"H (1590 x 825 x 795 mm)	
Product Dimensions (Folded)	36.02"D x 32.48"W x 5.91"H (915 x 825 x 150 mm)	
Included Components	Zero Gravity Chair, Removable Cushion, Headrest, Detachable Tray (with Cup Holder and Phone Holder), Eye Mask, Earplugs	

9. WARRANTY AND SUPPORT

Warranty information for the Happybuy Zero Gravity Chair (Model HQB-FAN003) is not provided in this document. Please refer to the product packaging, the retailer's website, or the official Happybuy website for detailed warranty terms and conditions.

For customer support, technical assistance, or to inquire about replacement parts, please visit the official Happybuy store or contact their customer service department.

Visit the Happybuy Store

Related Documents - HQB-FAN003



plastic regulating nut blades regulating nut hand crank feeding panel blades fleed screw shalt

Manual Cable Stripper SD-025 Mini - Operation and Instructions

Detailed instructions and operation guide for the Happybuy SD-025 mini manual cable stripper, including part identification and usage steps.



Happybuy Extra Large Collapsible Garden Cart Assembly Guide

Assembly instructions and fittings overview for the Happybuy Extra Large Collapsible Garden Cart, a folding utility wagon for garden, camping, and shopping.



VEVOR Mesh Safety Pool Cover Installation Guide

Comprehensive guide to installing a VEVOR Mesh Safety Pool Cover, detailing anchor setting and spring attachment for secure pool protection. Learn how to safely install your pool cover, including setting anchors and attaching springs. Protect your family and pets with this durable pool safety solution.

User Manual of Product 1:

Happyoby Commercial Food Maker 10C 600W 3 Speeds
Adjustade 1417-1000 FPM Heavy Cluy 111V with Editories
28ed Educ Tough Hobis Wilks Baser Premium for Schools
Bashware Resistants Placeries

User Manual of Product 2:

User Manual of Product 2:

Inch Product 2:

Inch Product 2:

Inch Product 3:

Inch Pro

<u>Happybuy Commercial Food Mixer and Mophorn Stainless Steel Work Table User Manuals</u>

User manuals for the Happybuy Commercial Food Mixer (15Qt, 600W, 3 Speeds) and the Mophorn Stainless Steel Work Table with Wheels (24x30x32 Inch). Includes specifications, operation, maintenance, and troubleshooting.