

SEUNKWANG TK100

SEUNKWANG EWEADN TK100 Wired Mechanical Keyboard User Manual

Model: TK100 | Brand: SEUNKWANG

1. INTRODUCTION

Thank you for choosing the SEUNKWANG EWEADN TK100 Wired Mechanical Keyboard. This keyboard combines a retro typewriter aesthetic with modern mechanical performance, designed for both office and gaming use. It features 104 keys, white backlighting, anti-ghosting technology, and durable blue mechanical switches for a tactile and clicky typing experience.



Image: The SEUNKWANG EWEADN TK100 keyboard showcasing its punk typewriter mechanical design and backlighting.

2. SAFETY INFORMATION

- Keep the keyboard away from liquids and excessive moisture to prevent damage.
- Avoid exposing the keyboard to extreme temperatures or direct sunlight.
- Do not attempt to disassemble or modify the keyboard, as this may void the warranty and cause damage.

- Use only the provided USB cable for connection.

3. PACKAGE CONTENTS

- SEUNKWANG EWEADN TK100 Wired Mechanical Keyboard
- USB-A Connection Cable
- User Manual (this document)

4. SETUP

4.1 Connecting the Keyboard

1. Locate an available USB-A port on your computer (PC, Mac, laptop, tablet, or desktop).
2. Plug the USB-A connector of the keyboard cable into the USB-A port on your device.
3. The keyboard is plug-and-play and does not require additional drivers or software installation. It should be recognized automatically by your operating system.



Image: The TK100 keyboard ready for use, highlighting its wired connection for reliable performance.

4.2 Adjusting Ergonomic Foot Support

The keyboard features adjustable feet on the underside to customize the typing angle for improved comfort and reduced fatigue during long sessions.



Image: The TK100 keyboard's two-level adjustable feet, designed for ergonomic typing.

Your browser does not support the video tag.

Video: Demonstrates the ergonomic foot support of the TK100 keyboard, showing how it can be adjusted for a more comfortable typing experience.

5. OPERATING INSTRUCTIONS


5.1 Backlight Control

The TK100 keyboard features a unique white backlight with 19 preset light effects and 5 brightness levels. You can also adjust the breathing speed of the backlight.

- **Change Light Effects:** Press **FN + INS** to cycle through 19 basic lighting effects.
- **Game Lighting Effects:** Press **FN + 6/7/8/9/0** to activate 4 specific game lighting effects.
- **Adjust Brightness/Speed:** Press **FN + Up/Down Arrow Keys** to adjust the backlight brightness (5 levels) or breathing speed.

20 Light Effects

simple white light



- FN + INS** 20 basic lighting effects
- FN + 6/7/8/9** 4 game lighting effects
- FN + ↑/↓** 5 brightness levels

Image: Visual guide for controlling the 20 light effects, brightness, and speed of the white backlight.

Your browser does not support the video tag.

Video: Shows the TK100 keyboard's metal panel and various white backlight effects in action.

5.2 Multimedia & Anti-Ghosting Features

The TK100 keyboard includes dedicated quick-access buttons for media control and features anti-ghosting technology for precise input.

- **Multimedia Control:** Use the dedicated buttons for volume adjustment, play/pause, and track switching.
- **104-Key Anti-Ghosting:** Every keystroke is accurately registered, even during high-speed, multi-key commands, making it ideal for gaming and fast typing.




Image: The keyboard highlighting its full key rollover feature, ensuring smooth and conflict-free simultaneous key presses.

Your browser does not support the video tag.

Video: Illustrates the 104-key anti-ghosting feature of the TK100 keyboard, ensuring all key presses are registered accurately.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the keyboard surface. For deeper cleaning, use a can of compressed air to remove dust and debris from between the keys.
- **Keycap Removal:** The retro round keycaps are designed for durability. If necessary, they can be carefully removed for cleaning or replacement using a keycap puller (not included).
- **Storage:** Store the keyboard in a cool, dry place when not in use.

7. TROUBLESHOOTING

- **Keyboard Not Responding:** Ensure the USB cable is securely plugged into both the keyboard and the computer. Try plugging it into a different USB port.
- **Backlight Not Working/Changing:** Verify that the backlight is turned on using the FN key combinations. If issues persist, refer to the backlight control section or contact support.

- **Keys Not Registering:** Check for any physical obstructions under the keycaps. If the issue is with specific keys, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	TK100
Key Layout	104 Keys
Switch Type	Blue Mechanical Switches
Keycap Style	Retro Typewriter Style Round Keycaps (Double-shot injection)
Backlight	White Backlit (19 preset effects, 5 brightness levels, adjustable breathing speed)
Anti-Ghosting	Full 104-Key Anti-Ghosting
Connectivity	Wired USB-A
Panel Material	High-quality Aluminum Alloy
Ergonomics	Ergonomic Foot Support
Dimensions	17.91 x 6.38 x 1.81 inches
Item Weight	1.85 pounds



Image: Detailed specifications of the blue mechanical switches, including operating force, trigger travel, and key strokes durability.

9. WARRANTY AND SUPPORT

The SEUNKWANG EWEADN TK100 keyboard comes with **48-month brand support**. For any inquiries, technical assistance, or warranty claims, please contact our expert team via email:

eweadnkeyboard@outlook.com

POWERFUL AFTER-SALES BACKING



Pre-Sales Q&A



Troubleshooting



Accessories Reissue



Returns And Exchanges



Email Support: eweadnkeyboard@outlook.com

Image: Overview of available after-sales support services.