

[Manuals.plus](#) /

› [SUPRENT](#) /

› SUPRENT Beard Trimmer (Model BT576BX) Instruction Manual

SUPRENT BT576BX

SUPRENT Beard Trimmer (Model BT576BX) Instruction Manual

Your All-in-One Grooming Solution

1. IMPORTANT SAFETY WARNINGS

Please read all instructions carefully before using this appliance. Keep this manual for future reference.

- **Water Safety:** Avoid using the appliance near water sources such as bathtubs, showers, basins, or other vessels containing water. Do not immerse the appliance in water.
- **Children:** This appliance is not intended for use on infants. Keep out of reach of children.
- **Power Source:** Use only the provided USB-C charging cable. Ensure the power adapter (not included) meets local safety standards.
- **Blade Care:** Handle blades with care. They are sharp. Do not use if blades are damaged, as this may cause injury.
- **Maintenance:** Do not attempt to repair the appliance yourself. Contact customer support for assistance.
- **Storage:** Store the appliance in a dry place, away from extreme temperatures.

2. PRODUCT OVERVIEW AND COMPONENTS

The SUPRENT BT576BX is a versatile grooming kit designed for various hair trimming needs. It includes multiple interchangeable heads and guide combs for precise styling.

ALL IN ONE MENS GROOMING KIT



Image: The SUPRENT grooming kit displaying its various components, including the T-Blade Trimmer, Full-Size Trimmer, Precision Trimmer, Body Hair Trimmer, and Nose Hair Trimmer, along with their respective functions.

Included Components:

- Main Trimmer Unit
- T-Blade Trimmer Head
- Full-Size Trimmer Head
- Precision Trimmer Head
- Body Hair Trimmer Head
- Nose Hair Trimmer Head
- Guide Combs (various sizes for T-Blade and Full-Size trimmers)
- USB-C Charging Cable
- Storage Base
- Cleaning Brush

- Lubricating Oil

3. SETUP AND CHARGING

Initial Charge:

Before first use, fully charge the trimmer. Connect the USB-C charging cable to the port on the trimmer and plug the other end into a compatible USB power adapter (not included). The LED display will indicate charging status.



LONG-LASTING BATTERY & LARGE LED DISPLAY

1 CHARGE = 180 MINS



One Single Charge for
60 Days Running Time



Convenient USB-C
Rechargeable Design

Image: The SUPRENT trimmer being charged via USB-C, highlighting its long-lasting battery and clear LED display for battery status.

A single full charge provides approximately 180 minutes of running time, which can last up to 60 days for typical use.

Attaching/Detaching Trimmer Heads:

1. Ensure the trimmer is turned off.
2. To attach a head, align the head with the main unit and press firmly until it clicks into place.

3. To detach a head, gently push the head upwards from the front while holding the main unit.

4. OPERATING INSTRUCTIONS

Power On/Off:

Press the power button once to turn the trimmer on. Press it again to turn it off.

Using Guide Combs and Adjustable Dial:

For beard and hair trimming, attach the desired guide comb to the T-Blade or Full-Size Trimmer head. The main unit features an adjustable dial to select cutting lengths from 1mm to 20mm.



Image: The SUPRENT trimmer's adjustable dial, allowing precise length settings for beard and hair trimming, along with examples of T-Blade and Full-Size trimmer combs.

- **T-Blade Trimmer:** Ideal for sharp lines, detailing, and shorter beard styles. Use with 1-10mm or 11-20mm combs.

- **Full-Size Trimmer:** Suitable for general beard trimming and hair cutting. Use with 1-10mm or 11-20mm combs.
- **Precision Trimmer:** For intricate detailing and fine lines.
- **Body Hair Trimmer:** Designed for grooming body hair.
- **Nose Hair Trimmer:** For safely trimming nose and ear hair.

Always start with a longer length setting if you are unsure, and gradually reduce it until you achieve the desired length.

Wet and Dry Shaving:

The SUPRENT BT576BX is IPX7 waterproof, allowing for both dry and wet shaving. For a more comfortable shave, you may use it with shaving foam or gel.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your trimmer.

Cleaning the Blades:

1. Turn off the trimmer and detach the trimmer head.
2. Rinse the detached head and blades under running water. The main unit is also waterproof, allowing for full rinsing.
3. Use the provided cleaning brush to remove any trapped hairs.
4. Allow all parts to air dry completely before reattaching or storing.



REMOVABLE BLADES FOR EASY CLEANING



IPX7
Waterproof



Dry
Shaving



Wet
Shaving



Storage
Base

Image: The SUPRENT trimmer head being rinsed under running water, demonstrating its waterproof design and ease of cleaning.

Lubrication:

After every few uses, apply a small drop of the provided lubricating oil to the blades to maintain their sharpness and smooth operation.

Storage:

Store the trimmer and all its accessories in the provided storage base or a dry, safe place when not in use.

6. TROUBLESHOOTING

- **Trimmer not turning on:** Ensure the battery is charged. Connect to the charger and check the LED display.
- **Poor cutting performance:** Clean the blades thoroughly to remove any hair buildup. Apply lubricating oil. Ensure the correct guide comb is properly attached.
- **Battery not charging:** Check the USB-C cable and power adapter for damage. Try a different USB port or adapter.

- **Excessive noise or vibration:** Ensure the trimmer head is securely attached. Clean and lubricate the blades.

If problems persist, please contact SUPRENT customer support.

7. SPECIFICATIONS

Model Number	BT576BX
Brand	SUPRENT
Power Source	Battery Powered (USB-C Rechargeable)
Battery Type	1 AA (included)
Blade Material	Ceramic
Body Material	Metal
Color	Black
Waterproof Rating	IPX7
Max Cutting Length	20 Millimeters
Special Features	Replaceable Blade, Storage Base, Waterproof, USB Charging, Long Battery Life
Recommended Uses	Face, Nose Hair, Beard, Body Hair
Item Weight	8.6 Ounces (243.81 grams)
Package Dimensions	22 x 19.7 x 8.4 cm

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official SUPRENT website. Keep your proof of purchase for any warranty claims.

If you encounter any issues or have questions regarding your SUPRENT Beard Trimmer, please do not hesitate to contact our customer service team.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question