

[Manuals.plus](#) /

> [Ceenwes](#) /

> Ceenwes 3L Dog Grooming Vacuum: Professional Pet Hair Removal Kit Instruction Manual

Ceenwes 3L Dog Grooming Vacuum

Ceenwes 3L Dog Grooming Vacuum Instruction Manual

Model: 3L Dog Grooming Vacuum

1. INTRODUCTION

Thank you for choosing the Ceenwes 3L Dog Grooming Vacuum. This professional pet grooming kit is designed to provide an efficient and mess-free grooming experience for your pets. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. IMPORTANT SAFETY INSTRUCTIONS

- Always ensure the device is unplugged before cleaning or maintenance.
- Do not immerse the main unit in water or other liquids.
- Keep out of reach of children and pets when not in use.
- Use only the provided attachments and accessories.
- Do not operate if the power cord or plug is damaged.
- Avoid blocking air vents during operation.
- This appliance is for household pet grooming use only.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- Ceenwes 3L Dog Grooming Vacuum Main Unit
- Flexible Hose (5.24 ft)
- Electric Clipper
- Grooming Brush
- De-Shedding Brush
- Crevice Suction Tool
- Hair Remover Roller
- Massage Head

- 5 Detachable Guard Combs (3mm, 6mm, 12mm, 18mm, 24mm)
- Power Adapter (14.7 ft cable)
- User Manual



Image: The Ceenwes 3L Dog Grooming Vacuum main unit shown with all its accessories, including various brushes, clippers, and guide combs.

4. SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove all components from the packaging.
2. **Connect Hose:** Insert one end of the flexible hose into the suction port on the main unit until it clicks securely.
3. **Attach Tool:** Select the desired grooming tool (e.g., Grooming Brush, De-Shedding Brush, Electric Clipper) and attach it to the other end of the flexible hose. Ensure it is firmly connected.
4. **Power Connection:** Plug the power adapter into the main unit's power input, then plug the other end into a standard electrical outlet.

5. OPERATING INSTRUCTIONS

5.1 Powering On and Suction Levels

Turn the rotary switch on the main unit to power on the device. There are three adjustable suction levels:

- **Mode 1 (Low):** Suitable for cats and small dogs, or for pets sensitive to noise.
- **Mode 2 (Medium):** Recommended for medium-sized dogs.
- **Mode 3 (High):** Ideal for large dogs and for maximum hair collection.



Image: A person grooming a Golden Retriever with the Ceenwes 3L Dog Grooming Vacuum, demonstrating its use on a large dog.

5.2 Using Grooming Attachments

Each attachment serves a specific purpose:

- **Grooming Brush:** For daily use to remove loose fur and detangle. Works with all coat types.
- **De-Shedding Brush:** For weekly use to remove dead loose hair from the undercoat, stimulating blood flow without

damaging the top coat.

- **Electric Clipper:** For monthly use to trim excess fur. Attach one of the 5 guard combs (3mm, 6mm, 12mm, 18mm, 24mm) to achieve desired hair length.
- **Massage Head:** For daily use to improve blood and lymph circulation, increase range of motion, and aid digestion.
- **Crevice Suction Tool:** For daily use to clean pet hair from narrow gaps in furniture.
- **Hair Remover Roller:** For daily use to clean pet hair from large surfaces like carpets and sofas.



Image: Close-up view of the various attachments included with the grooming vacuum, such as the deshedding brush, clipper, and cleaning tools.

5.3 Noise Level Considerations

The Ceenwes grooming vacuum operates at a low noise level, starting from 50 dB, which is significantly quieter than standard vacuums. This design helps prevent startling pets during grooming. Adjusting the suction level can further manage noise output.



Image: A cat being groomed with the Ceenwes 3L Dog Grooming Vacuum, illustrating the low noise operation that keeps pets calm.

6. MAINTENANCE AND CLEANING

6.1 Emptying the Dust Box

The 3L detachable dust cup features an easy-empty lid. When the dust box is full, simply detach it from the main unit and open the lid to dispose of collected pet hair. Regular emptying ensures optimal suction performance.



Image: The Ceenwes 3L Dog Grooming Vacuum with its large capacity dust box, illustrating how it collects a significant amount of pet hair.

6.2 Self-Cleaning Function

The grooming vacuum includes a self-cleaning function for certain brushes. After use, press the designated clean button on the brush to retract the bristles, allowing the vacuum to suck the removed hair directly into the dust box. This keeps your home clean and simplifies brush maintenance.

6.3 General Cleaning

- Wipe the exterior of the main unit and attachments with a damp cloth. Do not use abrasive cleaners.
- Ensure all parts are completely dry before reassembling or storing.
- Periodically check the hose for any blockages and clear them if necessary.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cord not properly connected; Power outlet malfunction.	Ensure power cord is securely plugged into both the unit and the outlet. Test the outlet with another device.
Weak suction	Dust box full; Hose or attachment blocked; Filter dirty.	Empty the dust box. Check and clear any blockages in the hose or attachment. Clean or replace the filter.
Excessive noise	High suction level selected; Blockage in the system.	Reduce the suction level. Check for and clear any blockages.
Attachments not staying on	Attachment not properly secured.	Ensure attachments are pushed firmly onto the hose until they click into place.

8. SPECIFICATIONS

- **Model:** 3L Dog Grooming Vacuum
- **Brand:** Ceenwes
- **Dust Box Capacity:** 3 Liters
- **Suction Levels:** 3 (Low, Medium, High)
- **Hose Length:** 5.24 feet
- **Power Cable Length:** 14.7 feet
- **Operation Radius:** 19.7 feet
- **Lowest Noise Level:** 50 dB
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Color:** White
- **Package Dimensions:** 15.13 x 12.75 x 11.13 inches
- **Weight:** 11.25 Pounds
- **Special Features:** Detachable Head, Low Noise, Self Cleaning, Vacuum System

9. WARRANTY AND SUPPORT

The Ceenwes 3L Dog Grooming Vacuum comes with a **1-Year Warranty**. For technical support, warranty claims, or any inquiries, please contact Ceenwes customer service. We aim to provide quick replies within 24 hours.

For more information, visit the official Ceenwes store: [Ceenwes Store on Amazon](#)




Image: A customer service representative, symbolizing the available 1-year warranty and 24/7 support.

© 2023 Ceenwes. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DSW7RGW7>

More documents and user manuals: <https://manuals.plus/>