

SEALIGHT VS01

SEALIGHT VS01 Portable Cordless Handheld Vacuum Cleaner User Manual

Model: VS01 | Brand: SEALIGHT

1. INTRODUCTION

Thank you for choosing the SEALIGHT VS01 Portable Cordless Handheld Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your device. Please read it thoroughly before first use and retain it for future reference.

Safety Warnings

- Do not use the vacuum cleaner to pick up flammable or combustible liquids, hot ashes, or sharp objects.
- Keep the device away from water and high humidity.
- Ensure the HEPA filter is properly installed before operation.
- Do not operate the vacuum cleaner if it is damaged or malfunctioning.
- Keep out of reach of children.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- SEALIGHT VS01 Handheld Vacuum Cleaner
- Long Nozzle
- Short Nozzle
- 2-in-1 Brush
- Floor Brush
- Hose
- Air Suction Nozzle
- Type-C Charging Cable
- User Manual

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your SEALIGHT VS01 vacuum cleaner:




Figure 3.1: Overview of the SEALIGHT VS01 Handheld Vacuum and its accessories. Key features include the vacuum inlet, clean button, dust cup, HEPA filter, LED light, working button, Type-C port, and air outlet.

4. SETUP

Charging the Vacuum Cleaner

1. Connect the Type-C charging cable to the charging port on the vacuum cleaner.
2. Plug the other end of the cable into a compatible USB power adapter (not included).
3. The LED indicator will show charging status. A full charge typically takes approximately 2-3 hours.




Figure 4.1: The vacuum cleaner features a Type-C port for convenient and fast charging, allowing for quick power-ups in various locations.

Attaching Accessories

Select the appropriate nozzle or brush for your cleaning task and firmly attach it to the vacuum's inlet or outlet

depending on the desired function (suction or blowing).



Figure 4.2: The vacuum comes with a variety of accessories, each designed for specific cleaning tasks, from reaching tight gaps to cleaning larger surfaces.

5. OPERATING INSTRUCTIONS

Powering On/Off and Suction Modes

- Press the power button once to turn on the vacuum in Eco Mode (12000Pa, up to 40 minutes runtime).
- Press the power button a second time to switch to Max Mode (18000Pa, up to 25 minutes runtime) for stronger suction.
- Press the power button a third time to turn off the vacuum.

Using the 4-in-1 Functions

The SEALIGHT VS01 offers four versatile functions:

- **Suction:** Attach the desired nozzle (e.g., 2-in-1 brush for car seats, floor brush for mats) to the vacuum inlet for effective dust and debris collection.
- **Blowing:** Attach a nozzle (e.g., long nozzle) to the air outlet to blow away dust from keyboards, car vents, or other hard-to-reach areas.
- **Deflation:** Use the appropriate nozzle on the air outlet to quickly deflate inflatable items like air mattresses or swimming rings.
- **Inflation:** Attach the correct nozzle to the air outlet to inflate small items.



Figure 5.1: The 4-in-1 multifunctional design allows for vacuuming, blowing, deflation, and inflation, making it suitable for various scenarios.

Demonstration Video

Watch this video for a visual guide on using your SEALIGHT portable car vacuum:

Your browser does not support the video tag.

Video 5.1: An official SEALIGHT video demonstrating the portable car vacuum's features and effectiveness in cleaning car interiors.

6. MAINTENANCE

Emptying the Dust Cup

1. Ensure the vacuum cleaner is turned off.
2. Press the one-touch release button to open the dust cup lid.
3. Empty the collected debris into a trash bin.
4. Close the dust cup lid securely until it clicks into place.



Figure 6.1: The one-touch spotless cleaning design allows for easy and hygienic emptying of the dust cup without direct contact with debris.

Cleaning the HEPA Filter

1. Twist and remove the dust cup from the main body.
2. Carefully remove the HEPA filter from the dust cup.
3. Rinse the HEPA filter under running water until clean. Do not use detergents.
4. Allow the filter to air dry completely before reinserting it into the dust cup.
5. Reattach the dust cup to the main body.



Figure 6.2: The HEPA filter is washable for easy maintenance, ensuring optimal suction and air quality. Ensure it is completely dry before reinstallation.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum does not turn on	Low battery; Power button not pressed correctly	Charge the vacuum; Press and hold the power button for 2 seconds
Weak suction power	Full dust cup; Clogged filter; Blocked nozzle	Empty dust cup; Clean or replace filter; Clear any blockages in the nozzle/hose
Short operating time	Battery not fully charged; Operating in Max Mode continuously	Ensure full charge; Use Eco Mode for longer runtime
Device overheating	Prolonged use; Blocked airflow	Allow device to cool down; Check for and clear any blockages

8. SPECIFICATIONS

Feature	Detail
Model Name	VS01
Suction Power	Up to 18000Pa
Motor Speed	90000 RPM
Battery Life	Eco Mode: Up to 40 minutes; Max Mode: Up to 25 minutes
Charging Type	Type-C Fast Charging
Weight	1 lbs

Feature	Detail
Dust Cup Capacity	120 Milliliters
Filter Type	HEPA Filter
Wattage	75 watts
Number of Speeds	2

9. WARRANTY AND SUPPORT

SEALIGHT products are manufactured to the highest quality standards. For warranty information, technical support, or customer service inquiries, please refer to the contact details provided on the product packaging or visit the official SEALIGHT website. Please retain your proof of purchase for warranty claims.