

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [FiveWillowise](#) /
- › [FiveWillowise Farmhouse Lift Top Coffee Table User Manual](#)

FiveWillowise 35.4"W Grey Coffee Table

FiveWillowise Farmhouse Lift Top Coffee Table User Manual

Brand: FiveWillowise | **Model:** 35.4"W Grey Coffee Table with Charging Station

1. PRODUCT OVERVIEW

The FiveWillowise Farmhouse Lift Top Coffee Table is designed to enhance your living space with its versatile functionality and rustic aesthetic. This square center table features a unique lift-top mechanism, providing an elevated surface for dining or working, and a spacious hidden storage compartment to help keep your living area organized. Additionally, it includes an integrated charging station for convenient power access.



Image 1.1: The FiveWillowise coffee table in a living room setting, showcasing its farmhouse design and grey finish. The table features a square shape and is designed to complement various home decor styles.

2. SETUP AND ASSEMBLY

This coffee table is designed for straightforward assembly. Please ensure all components are present before beginning. Detailed assembly instructions, clear labels, and pre-drilled holes are provided to facilitate the process. A screwdriver is recommended for assembly.

2.1. Package Contents

Verify that all parts listed in the assembly guide are included in your package. If any parts are missing or damaged, please contact customer support.

2.2. Assembly Steps

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify each part using the labels provided in the assembly guide.

3. Follow the step-by-step diagrams and instructions in the included Assembly Guide to connect the panels and frame.
4. Secure all fasteners firmly, but do not overtighten.
5. Install the lift-top mechanism and charging station according to the specific instructions.
6. Once assembled, ensure the table is stable and all moving parts operate smoothly.

Product Dimension



Image 2.1: This diagram illustrates the key dimensions of the coffee table, including its width (35.4 inches), depth (35.4 inches), and height (18.5 inches when closed, and extended height when open). It also shows the internal storage depth and the angle of the lift-top.



Image 2.2: Various views of the coffee table (front, angled, back, top) to assist with component identification during assembly.

3. OPERATING INSTRUCTIONS

3.1. Lift-Top Mechanism

The coffee table features a hydraulic lifting device for smooth and safe operation of the tabletop. To raise the top, gently lift it upwards. The hydraulic mechanism will assist in the movement and hold the top securely in place at the desired height. To lower, gently push the top down, and the hydraulic system will provide a buffering effect for a controlled descent.

LIFT-TOP DESIGN

According to your needs, you can adjust the placement of the lifting desktop






Image 3.1: This visual guide demonstrates the versatility of the lift-top design. The first image shows the table in its standard closed position, while the second image shows the lift-top partially raised, revealing the internal storage and an elevated surface for use.



Image 3.2: Detailed views of the hydraulic lifting device and robust support hinges. These components ensure a smooth and controlled adjustment of the table's height, providing stability and preventing sudden drops or pinches during operation.

3.2. Integrated Charging Station

The coffee table is equipped with a convenient charging station on its side. This station includes two 125V/12A AC outlets and two 5V/2A USB ports. To use, simply plug the table's power cord into a standard wall outlet. You can then connect your electronic devices to the AC outlets or USB ports for charging.



Upgraded Charging Stations



125V/12A
[AC Outlets*2]



5V/2A
[USB Ports*2]

Image 3.3: This image highlights the integrated charging station on the side of the coffee table. It features two 125V/12A AC outlets and two 5V/2A USB ports, allowing convenient charging of electronic devices directly from the table.

Charge at any Time

Enjoy Afternoon Tea Time



Image 3.4: This photo demonstrates the practical use of the charging station, showing a smartphone connected and charging while the lift-top is raised, providing a convenient surface for work or leisure activities.

3.3. Hidden Storage

The coffee table features a hidden storage space beneath the lift-top. To access, simply raise the lift-top. This ample space is ideal for storing books, blankets, remote controls, and other daily items, helping to keep your living area tidy and clutter-free.



Image 3.5: This image illustrates the coffee table's functionality with the lift-top fully raised. The hidden storage compartment is visible, containing pillows and a blanket, while a laptop is placed on the elevated surface, demonstrating its utility for work or dining.

3.4. Product Demonstration Video

Video 3.1: This video demonstrates the key features and functionality of the FiveWillowise coffee table, including the smooth operation of the lift-top mechanism, the spacious hidden storage, and the convenient integrated charging station. It provides a dynamic view of the product in a home environment.

4. MAINTENANCE

4.1. Cleaning

- Wipe the surface with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- Promptly wipe up spills to prevent staining or water damage.

4.2. General Care

- Avoid placing hot items directly on the surface; use coasters or protective pads.
- Keep the table away from direct sunlight and extreme temperature changes to prevent warping or fading.
- Periodically check and tighten all fasteners to ensure stability.




Image 4.1: A composite image showcasing various design and structural details of the coffee table, including the durable top plate, decorative paneling, sturdy base, and protective feet pads.

5. TROUBLESHOOTING

5.1. Lift Mechanism is Stiff or Uneven

- Ensure no objects are obstructing the mechanism or the internal storage area.
- Check that all screws securing the lift mechanism are properly tightened.
- If the issue persists, refer to the assembly guide to ensure correct installation of the hydraulic device.

5.2. Charging Station Not Working

- Verify that the table's power cord is securely plugged into a functional wall outlet.
- Check if the wall outlet itself is receiving power (e.g., by plugging in another device).

- Ensure your device's charging cable is properly connected to the charging station's ports.
- Confirm that your device is compatible with the specified voltage and amperage (125V/12A for AC, 5V/2A for USB).

5.3. Table Wobbles or is Unstable

- Check all assembly screws and bolts to ensure they are fully tightened.
- Ensure the table is placed on a flat, even surface.
- Verify that the protective feet pads are correctly installed and not damaged.

6. SPECIFICATIONS

Feature	Detail
Brand	FiveWillowise
Product Dimensions (D x W x H)	35.4"D x 35.4"W x 18.5"H
Item Weight	80.25 Pounds
Maximum Weight Recommendation	36.4 Kilograms
Color	Grey
Table Design	Coffee Table
Style Name	Farmhouse
Frame Material Type	Engineered Wood
Top Material Type	Engineered Wood
Included Components	Assembly Guide
Indoor Outdoor Usage	Indoor
Tools Recommended For Assembly	Screw Driver
Shape	Square
Furniture Finish	Wooden (Stained/Lacquered)
Top Color	Grey

7. SAFETY INFORMATION

Please read and adhere to the following safety guidelines to ensure safe use of your coffee table:

- Be careful when adjusting the table height to avoid pinching fingers.
- Follow the assembly instructions precisely for safe and secure installation.
- Do not overload the table or the hidden storage compartment beyond the recommended weight capacity.
- Keep small children and pets away from the lift mechanism during operation.
- Ensure the power cord for the charging station is not pinched or damaged.

8. WARRANTY AND SUPPORT

Your FiveWillowise coffee table is covered by a standard manufacturer's warranty against defects in materials and workmanship. For specific warranty details, including duration and coverage, please refer to the documentation included with your purchase or contact FiveWillowise customer service.

8.1. Customer Support

If you encounter any issues, have questions regarding assembly, operation, or require replacement parts, please contact FiveWillowise customer support. Have your product model number and purchase information ready to assist the support team.

For further assistance, please visit the official FiveWillowise store or contact their customer service channels as provided at the point of purchase.