

[Manuals.plus](#) /

› [little dove](#) /

› little dove Kids Tent LD-newtent-GR Instruction Manual

little dove LD-newtent-GR

little dove Kids Tent LD-newtent-GR Instruction Manual

Model: LD-newtent-GR

1. INTRODUCTION

Thank you for choosing the little dove Kids Tent. This spacious and versatile play tent is designed to provide a fun and safe environment for children aged 3 years and up. It features two windows for ventilation, a durable PVC frame, and skin-friendly polyester fabric. This manual will guide you through the assembly, operation, and maintenance of your new play tent.



Bedroom Oasis

Seamlessly transforms
into a bed tent



Compatible Bed Size

Width: **< 33 in**

Image 1.1: The little dove Kids Tent in a home setting.

2. SAFETY INFORMATION

- **Stay Away From Fire:** Keep the tent away from all flame and heat sources.
- **Adult Assembly Required:** Ensure an adult assembles the tent to prevent improper setup and potential hazards.
- **Supervision:** Always supervise children while they are playing in or around the tent.
- **Stable Surface:** Set up the tent on a flat, stable surface to prevent tipping.
- **Choking Hazard:** Keep small parts and packaging materials away from young children.
- **Ventilation:** Ensure adequate ventilation, especially during prolonged use, by keeping windows open.

3. WHAT'S IN THE BOX

Please check that all components are present before beginning assembly:

- Play tent body (fabric cover)
- PVC frame poles (various lengths)
- PVC connectors
- Decorative string lights
- Flag garland

4. SETUP INSTRUCTIONS

Follow these steps for quick and easy assembly. No additional tools are required.

4.1. Assemble the PVC Frame

1. Unpack all PVC poles and connectors. Sort them by size and type.
2. Begin by connecting the base frame using the longest poles and appropriate corner connectors. Ensure all connections are secure.
3. Attach the vertical poles to the base frame's corners.
4. Connect the roof frame using shorter poles and angled connectors to form the tent's peak.
5. Ensure the entire frame is stable and all joints are firmly connected.



Image 4.1: Assembling the PVC frame.

4.2. Attach the Fabric Cover

1. Carefully drape the tent fabric body over the assembled PVC frame.
2. Align the fabric so that the windows and door openings are correctly positioned.
3. Locate the hidden zippered fabric cover along the bottom edge of the tent. Zip it around the base poles to secure the fabric to the frame. This anti-trip design ensures the plastic pipes are safely enclosed.
4. Use the hook-and-loop fasteners and ties to secure the fabric to the frame at various points, ensuring a snug fit.

Unwind in Pure Comfort



Zipper design



Machine washable

Image 4.2: Securing the fabric cover with the zipper design.

4.3. Add Decorative Accessories

1. Drape the decorative string lights around the top interior or exterior of the tent as desired. Insert 2 AA batteries (not included) into the battery pack for the string lights.
2. Hang the flag garland to add a charming touch.

All-in-One Accessories Package

No need to purchase additional decorations



Image 4.3: Decorative string lights and flag garland.

4.4. Assembly Video Guide

Your browser does not support the video tag.

Video 4.4.1: Official assembly guide for the little dove Kids Tent, demonstrating step-by-step setup and features.

5. OPERATING THE TENT

- **Door Closure:** The full-length curtain door can be tied open for easy access or left closed for a private space.
- **Window Ventilation:** The two windows provide excellent airflow. Curtains can be drawn for a serene reading nook or left open for increased visibility and ventilation.
- **Star Lights:** Turn the string lights on/off using the switch on the battery pack to create a cozy ambiance.



• Napping Spot •



• Reading Nook •



• Playhouse •

Image 5.1: Children enjoying the spacious interior of the tent.

6. MAINTENANCE

- **Cleaning the Fabric:** The tent fabric is machine washable. For best results, wash on a gentle cycle with cold water and mild detergent. Air dry or tumble dry on low heat. Do not bleach.

- **Frame Care:** Wipe the PVC poles and connectors with a damp cloth as needed. Ensure they are completely dry before storage.
- **Storage:** When not in use, disassemble the tent and store all components in a dry, cool place away from direct sunlight to prolong its lifespan.

7. TROUBLESHOOTING

- **Tent Instability:** If the tent feels wobbly, recheck all PVC pole connections to ensure they are fully inserted into the connectors. The frame should be rigid once assembled correctly.
- **Fabric Not Fitting:** Ensure the correct poles are used in their designated positions as per the assembly instructions. The fabric should fit snugly around the frame.
- **String Lights Not Working:** Check if the batteries are inserted correctly and are not depleted. Replace with fresh AA batteries if necessary.
- **Damaged Fabric/Zipper:** In case of minor tears or zipper issues, temporary repairs can be made with fabric repair kits. For significant damage, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	little dove
Model Number	LD-newtent-GR
Dimensions (D x W x H)	35"D x 52"W x 51"H (90 x 132 x 130 cm)
Material Type	Polyester
Frame Material Type	Polyvinyl Chloride (PVC)
Item Weight	6.2 Pounds
Age Range Description	3 years and up
Assembly Required	Yes

Dimensions

cozy for **LITTLE DOVE**



Image 8.1: Tent dimensions.

Two Security Safeguards

Anti-distortion design



Anti-trip design



Image 8.2: Security safeguards: Anti-distortion and Anti-trip designs.

9. WARRANTY AND SUPPORT

little dove is committed to providing quality products and customer satisfaction. Your Kids Tent comes with a quality guarantee.

If you have any questions, concerns, or require assistance with your product, please do not hesitate to contact our customer service team. We aim to respond to all inquiries within 24 hours and ensure your satisfaction.

For support, please visit the official little dove store or contact us through your purchase platform.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DT12YJ91>

More documents and user manuals: <https://manuals.plus/>