



[Manuals.plus](#) /

› [BANTI](#) /

› BANTI 55x24 Inches Electric Standing Desk User Manual

BANTI B-DC-V2

BANTI 55x24 Inches Electric Standing Desk User Manual

Model: B-DC-V2 | Brand: BANTI

PRODUCT OVERVIEW

The BANTI 55x24 Inches Electric Standing Desk with Drawer is designed to provide a versatile and ergonomic workspace. This desk allows for seamless transitions between sitting and standing positions, promoting better posture and comfort during extended periods of work. It features an electric lifting mechanism, memory height presets, and a convenient integrated drawer for storage.



Figure 1: Overview of the BANTI Electric Standing Desk, showcasing its spacious desktop, integrated drawer, and control panel.

Desk Dimensions



Figure 2: Detailed dimensions of the BANTI Electric Standing Desk, illustrating its 55-inch width, 24-inch depth, and height range.

SETUP AND ASSEMBLY

Assembly of the BANTI Electric Standing Desk is designed to be straightforward. It is recommended that two people participate in the assembly process for ease and safety.

Included Components:

- Desktop Surface
- Electric Lifting Legs (2)
- Control Panel
- Integrated Drawer
- Headphone Hook (2)
- Installation Hardware (screws, bolts, etc.)
- Assembly Tools

- Installation Instruction Manual

Assembly Steps:

1. Unpack all components and verify against the parts list in the included instruction manual.
2. Attach the lifting legs to the desktop following the detailed diagrams.
3. Install the control panel and connect the necessary cables.
4. Secure the integrated drawer beneath the desktop.
5. Attach the headphone hooks to the desired locations on the desk frame.
6. Ensure all connections are secure and the desk is stable before plugging into a power source.




Figure 3: The desk comes with clear installation instructions and all necessary tools for assembly.

OPERATING INSTRUCTIONS

The BANTI Electric Standing Desk offers smooth and quiet height adjustment, allowing you to customize your workspace to your preference.

Control Panel Functions:

Convenient Controller



Up/Down Buttons



2 Memory Buttons

Figure 4: The convenient control panel with up/down buttons and two memory presets.

- **Up/Down Buttons (▲ / ▼):** Press and hold to continuously adjust the desk height. Release to stop at the desired height. The desk can be adjusted from 28.35 inches (minimum) to 46.06 inches (maximum).
- **Memory Presets (1, 2):** The desk features two programmable memory buttons. To save a height: adjust the desk to your desired position, then press and hold the '1' or '2' button until you hear a beep or see the display flash, indicating the height is saved. To recall a saved height, simply press the corresponding memory button.

Anti-Collision Technology:

The desk is equipped with an anti-collision system for safety. If the desk encounters an obstacle during the lifting or lowering process, it will automatically stop and reverse approximately 2 centimeters to prevent damage to the desk or objects in its path.



Figure 5: Illustration of the anti-collision system, showing the desk reversing upon encountering an obstacle.

Quiet Operation:

The electric motor operates quietly, with noise levels typically below 50dB, ensuring a minimal disturbance to your work environment or others nearby.

Quiet Operation

Raise your desk with lower noise.
Keep your focus and don't disturb others

 <50db





Up Button



Down Button



2 Height's Memory



Rest: Press and hold the DOWN button for 5 seconds

Figure 6: The desk operates quietly, allowing for an undisturbed work environment.

MAINTENANCE

Proper care and maintenance will ensure the longevity and optimal performance of your BANTI Electric Standing Desk.

Cleaning Instructions:

- Wipe the desktop surface and frame with a dry, soft cloth.
- For stubborn marks, use a slightly damp cloth with mild soap, then immediately dry the surface thoroughly.
- Avoid using abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish.

Drawer Care:

The integrated leather drawer is designed with waterproof properties for enhanced durability and ease of cleaning.



Upgraded leather drawer with waterproof function and better texture

Figure 7: The upgraded leather drawer offers waterproof functionality and improved texture for easy maintenance.

General Care:

- Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary.

- Avoid placing excessively heavy items on the desk, exceeding the maximum weight recommendation.
- Protect the desk from direct sunlight and extreme temperature changes to prevent material degradation.

Rounded Corner Design

Durable, Stain&Water Resistant Surface




Figure 8: The desk features a rounded corner design with a durable, stain and water-resistant surface for easy cleaning and longevity.

TROUBLESHOOTING

If you encounter any issues with your BANTI Electric Standing Desk, refer to the following common troubleshooting tips.

Common Issues and Solutions:

- **Desk Not Moving:**
 - Ensure the power cord is securely plugged into both the desk and a working power outlet.
 - Check for any obstructions beneath or around the desk that might be triggering the anti-collision system.
 - If the control panel is unresponsive, try unplugging the desk for 30 seconds and then plugging it back in to reset the

system.

• **Uneven Movement or Noise:**

- Verify that the desk is placed on a flat, level surface.
- Check that all assembly screws and bolts are tightened securely. Loose connections can cause instability or noise.
- Ensure the weight on the desk is evenly distributed and does not exceed the maximum weight capacity.

• **Memory Presets Not Working:**

- Re-program the memory presets by adjusting the desk to the desired height and then pressing and holding the corresponding memory button (1 or 2) until the setting is confirmed.

If the issue persists after attempting these troubleshooting steps, please contact BANTI customer support for further assistance.

SPECIFICATIONS

Detailed technical specifications for the BANTI 55x24 Inches Electric Standing Desk.

Feature	Specification
Brand	BANTI
Model Number	B-DC-V2
Product Dimensions (D x W x H)	24"D x 55"W x 28"H
Minimum Height	28.35 Inches
Maximum Height	46.06 Inches
Item Weight	59 Pounds
Maximum Weight Recommendation	155 Pounds
Base Material	Alloy Steel
Top Material Type	Wood
Finish Type	Laminated
Lifting Mechanism	Electric
Number of Height Positions	2 (Memory Presets)
Included Components	1 Drawer, 1 Installation instruction, Headphone Hook
Required Assembly	Yes
Recommended Number of People for Assembly	2

WARRANTY AND SUPPORT

BANTI is committed to providing quality products and customer satisfaction.

Warranty Information:

This product comes with a Limited Warranty. For specific details regarding coverage and duration, please refer to the warranty documentation included with your purchase or contact BANTI customer support.

Customer Support:

If you have any questions, require assistance with assembly, or encounter any issues not covered in the troubleshooting section, please do not hesitate to contact BANTI customer support. You can often find contact information on the BANTI official website or through the retailer where you purchased the product.

For additional resources, including installation videos and electronic versions of manuals, please visit the official BANTI Store: [BANTI Store on Amazon](#)