

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Outsunny](#) /

> [Outsunny Outdoor Bistro Chair Cushions \(Set of 4\) Instruction Manual](#)

Outsunny 84G-609V00BK

Outsunny Outdoor Bistro Chair Cushions (Set of 4)

Model: 84G-609V00BK

Brand: Outsunny

1. INTRODUCTION

This manual provides instructions for the Outsunny Outdoor Bistro Chair Cushions, Model 84G-609V00BK. These round seat cushions are designed for outdoor use with bistro chairs, dining chairs, and other patio furniture, offering comfort and durability. Please read this manual thoroughly before use to ensure proper handling and maintenance.

2. SAFETY INFORMATION

- Ensure cushions are placed securely on chairs to prevent slipping.
- Keep cushions away from open flames, sparks, or extreme heat sources.
- Do not use these cushions for purposes other than intended seating.
- Supervise children and pets around the cushions to prevent damage or misuse.

3. PACKAGE CONTENTS

Verify that all items are present and in good condition upon opening the package:

- 4 x Outsunny Outdoor Bistro Chair Cushions (Model 84G-609V00BK)

4. SETUP AND INSTALLATION

1. **Unpacking and Expansion:** Your cushions arrive vacuum-packed. Gently tap them to help them fluff up. Allow several hours for them to reach their full size and shape. Exposure to a warm environment can sometimes accelerate this process.
2. **Placement:** Place each cushion onto your bistro chair, dining chair, or other suitable patio furniture.
3. **Securing the Cushions:** Utilize the extra-long attached ties on each cushion. Fasten these ties securely around the chair's frame to prevent the cushion from shifting or slipping during use.



HIGH RESILIENCE FOAM

Provides soft yet supportive seating experience

Image: High resilience foam provides soft yet supportive seating.

EXTRA LONG TIES

Keep the cushions stay in place



Image: Extra long ties keep the cushions securely in place.

Your browser does not support the video tag.

Video: Demonstration of Outsunny Outdoor Seat Cushion Set, showing cushions expanding and being placed on chairs.

5. OPERATING INSTRUCTIONS

These cushions are designed to enhance comfort for outdoor seating. Once properly installed, they provide a soft yet supportive surface for relaxation.

- The 2.8-inch thick foam padding offers excellent support, relieving pressure during extended sitting.
- The splash-resistant fabric helps protect against minor liquid spills, making clean-up easier.
- The fade-resistant properties help maintain the color vibrancy over time when exposed to sunlight.

Outsunny
by AOSOM



Image: Outsunny cushions providing comfort on outdoor bistro chairs.

MACHINE-WASHABLE COVERS

Free up your hands and time



Image: Splash-resistant fabric for easy clean-up of minor spills.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your cushions.

1. **Regular Cleaning:** For light dirt or dust, brush off any loose debris.
2. **Spot Cleaning:** For minor spills, wipe immediately with a damp cloth.
3. **Machine Washing Covers:** The cushion covers are removable and machine-washable. Unzip the cover and carefully remove the foam insert before washing. Machine wash the cover in cold water on a gentle cycle. Air dry or tumble dry on low heat. Do not bleach or iron.
4. **Drying:** Ensure covers are completely dry before reinserting foam and using the cushions.
5. **Storage:** When not in use for extended periods, or during harsh weather conditions, store cushions in a dry, protected area to prevent mildew, fading, and wear.



SPLASH-RESISTANT

Spilled your drink? No problem!



Image: Machine-washable covers for effortless cleaning.

7. TROUBLESHOOTING

- **Cushions not fully expanded:** If cushions appear flat after unpacking, allow more time for them to expand. Gently fluff and tap them. Placing them in a warm room can sometimes assist the expansion process.
- **Cushions slipping on chair:** Ensure the attached ties are securely fastened to the chair frame. If ties are loose, re-tie them firmly.
- **Stubborn stains on cover:** For difficult stains, pre-treat the removable cover with a suitable fabric stain remover before machine washing, following the stain remover's instructions.

8. SPECIFICATIONS

Feature	Detail
Model Number	84G-609V00BK
Brand	Outsunny

Color	Black
Size (Diameter x Thickness)	15 inches x 2.8 inches
Shape	Round
Number of Items	4
Fill Material	Foam
Cover Material	100% Polyester
Special Features	Fade-Resistant, Lightweight, Removable Cover, UV-Resistant, Washable
Product Care Instructions	Machine Wash
Indoor/Outdoor Usage	Outdoor
Item Weight (Set)	2 Pounds
Manufacturer	Aosom LLC



NOTE:

Please measure your cushion size carefully before buying

Image: Cushion dimensions: 15 inches diameter, 2.8 inches thickness.

9. WARRANTY AND SUPPORT

For detailed warranty information, product support, or to inquire about replacement parts, please contact Outsunny customer service or visit the official Aosom LLC website. Please have your model number (84G-609V00BK) and purchase date available when contacting support.

Manufacturer: Aosom LLC

