FQIFRFBFF-06

Generic FQIFRFBFF-06 Wireless Typewriter Style Keyboard and Mouse Instruction Manual

Model: FQIFRFBFF-06

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Generic FQIFRFBFF-06 Wireless Typewriter Style Keyboard and Mouse combo. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.

Image: The Generic FQIFRFBFF-06 wireless keyboard and mouse set, featuring a beige keyboard with round, retro-style keycaps and a matching ergonomic mouse.

KEY FEATURES

- **Retro Typewriter Style Round Keycaps:** Mechanical switches provide a responsive and tactile typing experience.
- **High Performance Keyboard:** 104 keys with 19 anti-collision keys for smooth and accurate typing.
- **Ergonomic Design:** Curved keycaps, stepped layout, foldable feet, and crater keys for comfortable use.
- **Dual Connection Modes:** Supports both 2.4GHz wireless and Bluetooth 5.0 for versatile connectivity.
- **Wide Compatibility:** Compatible with Windows XP/7/8/10 operating systems.
- **Intelligent Hibernation:** Three levels of intelligent hibernation for power saving.

- **Extended Range:** 10m long-range reception for flexible placement.
- **High-Speed Transmission:** 1Mbps transmission speed for reliable performance.

Image: Visual representation of key features including retro typewriter design, 2.4GHz wireless technology, rounded floating keycaps, three levels of intelligent hibernation, 10m long-range reception, and 1Mbps high-speed transmission.

SETUP INSTRUCTIONS

1. Unpacking and Battery Installation

1. Carefully remove the keyboard and mouse from their packaging.
2. Locate the battery compartments on the underside of both the keyboard and the mouse.
3. Insert the required batteries (typically AA for keyboard, AAA for mouse) into each device, ensuring correct polarity (+/-).
4. Close the battery compartments securely.

2. Connecting via 2.4GHz Wireless (USB Receiver)

1. Locate the USB receiver, usually stored in the mouse's battery compartment or a dedicated slot.

2. Plug the USB receiver into an available USB port on your computer.

3. Turn on the keyboard and mouse using their respective power switches (if present).

4. The devices should automatically connect to your computer. If not, press the pairing button on the devices (if available) or refer to the troubleshooting section.

3. Connecting via Bluetooth 5.0

1. Ensure your computer or device has Bluetooth enabled.

2. On the keyboard/mouse, switch to Bluetooth mode (if a mode switch is present) or press and hold the Bluetooth pairing button until the indicator light flashes.

3. On your computer/device, go to Bluetooth settings and search for new devices.

4. Select "FQIFRFBFF-06 Keyboard" and/or "FQIFRFBFF-06 Mouse" from the list of available devices to pair.

5. Follow any on-screen prompts to complete the pairing process.

OPERATING INSTRUCTIONS

Keyboard Functions

- The keyboard features 104 standard keys, including a numeric keypad.
- **Anti-Collision Keys:** Up to 19 keys can be pressed simultaneously without conflict, ensuring accurate input during fast typing or gaming.
- **Ergonomic Design:** The curved keycaps and stepped layout are designed for comfortable typing. Adjust the foldable feet on the underside of the keyboard for your preferred typing angle.
- **Function Keys (Fn):** Use the 'Fn' key in combination with F1-F12 keys for multimedia controls or system shortcuts. Specific functions may vary based on your operating system.

Mouse Functions

- The mouse features standard left-click, right-click, and scroll wheel functions.
- DPI Adjustment: Some models may include a DPI button to adjust cursor sensitivity. Refer to the mouse's specific design for this feature.

Power Saving Mode

The keyboard and mouse are equipped with three levels of intelligent hibernation. If inactive for a period, they will enter a low-power state to conserve battery life. To wake them up, simply press any key on the keyboard or move/click the mouse.

MAINTENANCE

Cleaning

- Ensure both devices are turned off before cleaning.
- Use a soft, lint-free cloth lightly dampened with water or a mild cleaning solution to wipe the surfaces.
- Avoid using harsh chemicals, abrasive cleaners, or spraying liquids directly onto the devices.
- For cleaning between keycaps, use compressed air or a small brush.

Battery Replacement

- When battery life is low, replace the batteries in both the keyboard and mouse.
- Open the battery compartment, remove the old batteries, and insert new ones, observing correct polarity.
- Dispose of used batteries responsibly according to local regulations.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard/Mouse not responding (2.4GHz)	Low batteries; USB receiver not properly connected; Interference.	Replace batteries; Re-insert USB receiver into a different port; Move devices closer to the receiver; Avoid placing near other wireless devices.
Keyboard/Mouse not responding (Bluetooth)	Low batteries; Bluetooth not enabled on device; Not paired correctly; Out of range.	Replace batteries; Ensure Bluetooth is enabled on your device; Re-pair the devices via Bluetooth settings; Move devices closer to your computer.
Keys are sticky or unresponsive	Dirt or debris under keycaps.	Clean the keyboard using compressed air or a small brush.
Mouse cursor erratic or not moving	Dirty optical sensor; Unsuitable surface; Low batteries.	Clean the optical sensor on the mouse's underside; Use a mouse pad or a smooth, non-reflective surface; Replace batteries.

PRODUCT SPECIFICATIONS

- **Model Number:** FQIFRFBFF-06
- **Brand:** Generic
- **Keyboard Dimensions:** 445mm x 136mm x 35mm
- **Mouse Dimensions:** 101mm x 75mm x 35mm
- **Product Weight (Combined):** 750g
- **Number of Keyboard Buttons:** 104
- **Connectivity:** 2.4GHz Wireless, Bluetooth 5.0
- **Wireless Range:** Up to 10 meters (33 feet)
- **Compatibility:** Windows XP/Win7/Win8/Win10
- **Item Weight (Package):** 1.76 ounces
- **Package Dimensions:** 1.18 x 0.79 x 0.39 inches

Image: Diagram showing the dimensions of the keyboard (445mm length, 136mm width, 35mm height) and the mouse (101mm length, 75mm width, 34mm height), along with the USB receiver dimensions.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for warranty claims.