

[Manuals.plus](#) /

› [ALLIMITY](#) /

› ALLIMITY RC813 CMB1 Replacement Remote Control User Manual for TCL Smart TVs

ALLIMITY RC813 CMB1

ALLIMITY RC813 CMB1 Replacement Remote Control User Manual

For TCL Mini-LED QLED 4K UHD Smart TVs

1. INTRODUCTION

This manual provides instructions for the ALLIMITY RC813 CMB1 replacement infrared remote control. This remote is designed to be compatible with various TCL Mini-LED QLED 4K UHD Smart TV models, offering a direct replacement for your original remote without the need for complex setup procedures.

Compatible TCL TV Models include: CMB1, 65Q651F, 75Q650F, 55S450F, 75Q550F, 85Q550F, 75Q681F, and others that use the RC813 CMB1 remote model.

2. SETUP

2.1 Battery Installation

The RC813 CMB1 remote control requires two (2) AAA alkaline batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.





Image: Back view of the remote control with the battery cover removed, illustrating the correct orientation for AAA battery insertion.

2.2 Initial Use

No programming or pairing is required for this infrared replacement remote control. Once the batteries are correctly installed, the remote is ready for immediate use with your compatible TCL Smart TV.

3. OPERATING INSTRUCTIONS

The RC813 CMB1 remote control functions identically to your original TCL TV remote. Ensure there is a clear line of sight between the remote control and the infrared receiver on your television for optimal performance.



Image: Front view of the remote control, displaying the layout of all functional buttons.

3.1 Basic Functions

- **Power Button:** Turns the TV on or off.
- **Navigation Pad (Up/Down/Left/Right/OK):** Used to navigate menus and select options.
- **Volume Up/Down:** Adjusts the TV's volume.
- **Channel Up/Down:** Changes TV channels.
- **Mute Button:** Mutes or unmutes the TV audio.

- **Home Button:** Returns to the TV's main home screen.
- **Back Button:** Returns to the previous screen or menu.

3.2 App Shortcut Buttons

Dedicated buttons for popular streaming services and applications are provided for quick access. Simply press the desired button to launch the corresponding application on your TCL Smart TV.

4. MAINTENANCE

4.1 Battery Replacement

Replace the batteries when the remote control's response becomes sluggish or stops functioning. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

4.3 Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

5. TROUBLESHOOTING

- **Remote not responding:**
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace the batteries with new AAA alkaline batteries.
 - Ensure there are no obstructions between the remote control and the TV's infrared receiver.
 - Confirm that the remote is pointed directly at the TV.
- **Buttons are sticky or unresponsive:**
 - This may indicate dirt or debris under the buttons. Clean the remote as described in the Maintenance section.

6. SPECIFICATIONS

- **Brand:** ALLIMITY
- **Model Number:** RC813 CMB1
- **Remote Type:** Infrared (IR)
- **Power Source:** 2 x AAA Batteries (not included)
- **Product Dimensions:** Approximately 5 x 1 x 0.5 inches (12.7 x 2.54 x 1.27 cm)
- **Item Weight:** Approximately 2.19 ounces (62 grams)
- **Color:** Black
- **Special Feature:** Ergonomic design

- **Compatible Devices:** TCL Televisions (specific models listed in Introduction)

20.5 cm / 8.07 in

4 cm / 1.57 in






Image: Front and side views of the remote control with approximate dimensions indicated.

7. WARRANTY INFORMATION

Specific warranty details for this ALLIMITY product are not provided in the product information. Please refer to the retailer or your purchase documentation for any applicable warranty terms and conditions.

8. SUPPORT

For further assistance or inquiries regarding the ALLIMITY RC813 CMB1 replacement remote control, please contact the seller or the retailer from whom the product was purchased. Specific manufacturer support contact information is not available in the provided product details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DT18CQN8>

More documents and user manuals: <https://manuals.plus/>