

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Spigen](#) /

> [Spigen AMP09336 57-inch Selfie Stick Tripod with Bluetooth Remote Control User Manual](#)

Spigen AMP09336

Spigen AMP09336 57-inch Selfie Stick Tripod with Bluetooth Remote Control User Manual

This manual provides detailed instructions for the setup, operation, and maintenance of your Spigen AMP09336 Selfie Stick Tripod.

INTRODUCTION

Thank you for choosing the Spigen AMP09336 Selfie Stick Tripod. This versatile accessory is designed to enhance your mobile photography and videography experience, offering both a portable selfie stick and a stable tripod function. It features a detachable Bluetooth remote control and MagSafe compatibility for ease of use with a wide range of smartphones.

SETUP

1. Unfolding the Tripod

1. Hold the selfie stick vertically with the base facing downwards.
2. Press the bottom button firmly against a flat surface. The tripod legs will automatically deploy.



Simply press the bottom section for quick setup.



Image: Visual guide for automatic tripod deployment.



2. Attaching Your Smartphone

- **For MagSafe Compatible Devices:** Align your MagSafe-compatible iPhone (iPhone 12 series or newer) or MagSafe-compatible case with the magnetic head of the tripod. The strong magnet will securely hold your device.

- **For Other Smartphones:** The magnetic head also features retractable silicone grips. Pull these grips outwards to securely clamp your smartphone. The silicone pads ensure a firm, scratch-free hold for devices between 4.5cm and 9.2cm (1.77" - 3.62") wide.




Image: Demonstrates compatibility with various smartphone sizes and MagSafe attachment.

3. Pairing the Bluetooth Remote Control

1. Locate the detachable Bluetooth remote control on the handle of the selfie stick. Press and slide it out.
2. Turn on the remote control (usually by pressing and holding the button until an indicator light flashes).
3. On your smartphone, go to **Settings > Bluetooth** and enable Bluetooth.
4. Select the device named "Spigen Remote" or similar from the list of available devices to pair.
5. Once paired, the indicator light on the remote will stop flashing, and you can use it to trigger your camera shutter.




Image: Detachable Bluetooth remote control and its function.

OPERATING INSTRUCTIONS

1. Extending the Selfie Stick

Gently pull the top section of the selfie stick upwards to extend it to your desired length. The stick can extend to a maximum height of 57 inches (146 cm).

2. Adjusting the Angle

The phone holder features a ball head mechanism, allowing for 360-degree rotation and various tilt angles. Adjust the phone holder to achieve the perfect shooting angle for your photos or videos.



Premium non-slip silicone grip.
The silicone pads keep your device secure and scratch-free.



Image: Demonstrates the selfie stick in use with a stable base.

3. Using the Bluetooth Remote

Once paired, press the button on the detachable Bluetooth remote to remotely trigger your smartphone's camera shutter. This allows for convenient hands-free shooting from up to 10 meters away.

4. Folding for Storage

1. Push the extended stick sections back into the main body until fully retracted.
2. Gently push the tripod legs inwards until they click securely into the closed position.
3. Re-insert the Bluetooth remote into its slot on the handle.



Extendable Reach: From 31.5cm to 146cm (12.4" to 57.5").




Image: Illustrates the compact folded size and the fully extended tripod.

MAINTENANCE

- Keep the device clean by wiping it with a soft, dry cloth.
- Avoid exposing the device to extreme temperatures, moisture, or corrosive substances.
- The Bluetooth remote control contains a rechargeable Lithium Metal battery. Charge it using the provided USB cable when the battery is low.

TROUBLESHOOTING

1. Bluetooth Remote Not Connecting

- Ensure the remote control is charged and turned on.
- Check your smartphone's Bluetooth settings to confirm it's enabled and searching for devices.

- If previously paired, try unpairing and re-pairing the remote.
- Ensure the remote is within the 10-meter operating range of your phone.

2. Phone Not Holding Securely

- For MagSafe, ensure your phone or case is genuinely MagSafe compatible.
- If using the clamps, ensure the phone is centered and the grips are fully extended and tightened around the device.
- Remove any thick phone cases that might interfere with the magnetic connection or clamp grip.

SPECIFICATIONS

Product Dimensions	12.4 x 1.57 x 1.41 inches
Item Weight	9.8 ounces (278.7 Grams)
Item Model Number	AMP09336
Batteries	1 Lithium Metal battery required (included)
Maximum Height	57 Inches
Minimum Height	35.7 Millimeters
Tripod Head Type	Ball Heads
Compatible Devices	iPhone 12 series and newer (MagSafe compatible), Pixel 10 series, MagSafe Compatible Cases for Galaxy S25, Galaxy S24, Galaxy Z Fold 7, Z Flip 7 Series, and more.

WARRANTY INFORMATION

Specific warranty details for the Spigen AMP09336 Selfie Stick Tripod are not provided in this manual. Please refer to the product packaging or the official Spigen website for the most up-to-date warranty information.

CUSTOMER SUPPORT

For any questions, technical assistance, or support regarding your Spigen AMP09336 Selfie Stick Tripod, please visit the official Spigen website or contact their customer service department. Contact information can typically be found on the product packaging or on the Spigen website.

Related Documents - AMP09336



[Spigen Gimbal Selfie Stick Tripod S620W User Manual](#)

User manual for the Spigen S620W Gimbal Selfie Stick Tripod, detailing its components, operation modes including handheld dolly shot and AI tracking, charging instructions, remote control functions, specifications, and important cautions.




[Spigen ArcField Dual Wireless Charger PF2100 User Manual](#)

Official user manual for the Spigen ArcField Dual Wireless Charger PF2100, detailing setup, safety instructions, specifications, and warranty information.

[Spigen ArcHybrid Mag Wireless Portable Charger PH2100 User Manual](#)

User manual and safety instructions for the Spigen ArcHybrid Mag Wireless Portable Charger PH2100, a 5000mAh magnetic charging power bank with fast wireless charging capabilities for iPhones.



[Spigen ArcStation Pro GaN 1402 Wall Charger User Manual](#)
User manual for the Spigen ArcStation Pro GaN 1402 Wall Charger, providing instructions, safety guidelines, specifications, and warranty information for this 140W dual USB-C power adapter.



[Spigen H3 Bluetooth Headset User Manual](#)
User manual for the Spigen H3 Bluetooth headset, detailing features, connectivity, and specifications. Includes instructions for pairing, multi-point connection, and factory reset.



[Spigen ArcField Wireless Charger PF2402 User Manual & Safety Guide](#)
Official user manual and safety instructions for the Spigen ArcField Wireless Charger PF2402, detailing setup, operation, LED indicators, specifications, and regulatory compliance information.

