Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Babelio BEBAM63

Babelio BEBAM63 Removable No Bottom Bar Baby Gate User Manual

Model: BEBAM63 | Brand: Babelio

1. Introduction

Thank you for choosing the Babelio Removable & No Bottom Bar Baby Gate. This hardware-mounted safety gate is designed to provide a secure barrier for children and pets in various home openings, including stairs and doorways. Its unique no-bottom-bar design minimizes tripping hazards, offering enhanced safety and convenience. The gate features a wide walk-through opening, auto-close functionality, and a stay-open feature for flexible use. It is constructed from durable alloy steel and includes a double-lock mechanism for maximum security.



Figure 1: The Babelio gate features a 100% trip-free design with no bottom bar, ensuring safe passage.

2. Important Safety Warnings

- Always install and use the gate according to the manufacturer's instructions.
- This gate is designed for children aged 6 months and up.
- Never leave children unattended near the gate.

- Ensure the gate is securely latched at all times when in use. The double-lock design provides enhanced security.
- Regularly check all components for wear, damage, or loose parts. Discontinue use if any part is damaged.
- The no-bottom-bar design is intended to minimize tripping hazards, especially at the top of stairs.
- This product has passed the CPSIA test, ensuring its safety standards.

3. Package Contents

Before beginning installation, please ensure all parts are present:

- Main Gate (1)
- Long Gate Accessory (1)
- Short Gate Accessory (1)
- Vertical Bars (2)
- Door Frame (1)
- Plastic Pads (for skirting)
- Screws (various sizes for different wall types)
- Allen Key
- Pipe Covers
- Wall Anchors (for drywall/concrete)



Figure 2: Visual guide to included components and basic installation steps.

4. Setup and Installation

The Babelio gate features a modular design for simple and fast hardware installation. Drill is needed for secure mounting.

4.1 Preparation

- Determine the desired location for your gate (doorway or stairs).
- Measure the width of the opening to ensure it falls within the gate's adjustable range (35.5-55 inches).
- Identify your wall material (wood, drywall, concrete/brick) to select appropriate screws and anchors.

4.2 Attaching Wall Brackets

- Position the vertical bars with their attached brackets against the wall at the desired height. Ensure they are level.
- Mark the drilling points through the bracket holes.
- Pre-drill pilot holes (approx. 2mm for wood, or use appropriate bit for anchors).
- Secure the brackets to the wall using the provided screws. For drywall or concrete, insert wall anchors before screwing.




Figure 3: One-step installation process, minimizing measuring and guesswork.

4.3 Assembling the Gate

- Slide the main gate frame into the installed wall brackets. The gate is designed to fit snugly.
- Adjust the gate's width by loosening the hexagonal nuts on the plastic latches and extending the gate to the other side's bracket. Tighten nuts once width is set.
- Ensure the gate is level and securely attached to both wall brackets. The gate's design allows for adjustment on uneven walls or baseboards.




Figure 4: Gate adjusts to fit uneven walls and baseboards, ensuring a level and secure installation.

4.4 Gate Removal (Modular Design)

When not in use, the gate frame can be quickly removed from the opening for easy storage. This is ideal for intermittent use or when full access is needed.

- To remove the gate, uncover the top end cap on the main gate.

- Loosen the screw inside the top bracket.
- Lift the gate frame upwards to disengage it from the wall brackets.




Figure 5: Steps to quickly remove the gate for full access.

4.5 Installation Videos

Video 1: Official Babelio guide on easy installation and removal of the baby gate.

Video 2: Demonstrates how to remove the main gate from the Babelio Removable Baby Gate.

Video 3: Shows the easy removal process of the Babelio Baby Gate for stairs.

5. Operating the Gate

5.1 Opening and Closing

- To open the gate, press the button on the top handle, pull back slightly, and lift the gate upwards to disengage the latch.
- Swing the gate open in either direction. The extra-wide walk-through door allows for easy passage.
- To close, simply push the gate back into place. The auto-close feature will gently close and latch the door automatically if not fully opened.



Figure 6: One-hand operation and auto-close feature for smooth passage.

5.2 Stay-Open Feature

For added convenience, the gate includes a stay-open feature. If you open the gate past a certain angle (typically 90 degrees), it will remain open, allowing for continuous passage without needing to re-latch. To engage the auto-close feature again, simply push the gate slightly from the open position.

6. Maintenance

- Clean the gate regularly with a soft, damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals.
- Inspect all hardware and mounting points periodically to ensure they remain tight and secure. Tighten screws as needed.
- Check for any signs of wear or damage to the gate frame, latches, or hinges. Replace damaged parts immediately or contact customer support.

7. Troubleshooting

7.1 Gate Feels Wobbly After Installation

Ensure all screws are tightened securely into the wall studs or appropriate anchors. The gate should not wobble if properly installed. Re-check the alignment of the vertical bars and ensure they are parallel.

7.2 Gate Does Not Latch Properly

Verify that the gate is installed at the correct width and that the latches align perfectly with the receiving mechanism. Adjust the gate's width slightly if necessary to achieve a smooth and secure latch. Ensure no obstructions are preventing the latch from engaging fully.

7.3 Difficulty Removing the Gate

Ensure the top end cap is fully uncovered and the internal screw is sufficiently loosened before attempting to lift the gate. The gate is designed for quick removal, but proper disengagement of the top mechanism is crucial.

8. Specifications

Feature	Detail
Brand	Babelio
Model Number	BEBAM63
Adjustable Width	35.5 - 55 inches
Height	30 inches
Material	Alloy Steel
Mounting Type	Wall Mount (Drill Needed)
Target Species	Baby, Pet
Special Features	No Bottom Bar, Auto-Close, Stay-Open, One-Hand Operation, Double Lock

9. Warranty and Support

Babelio is committed to providing high-quality products. For specific warranty details, please refer to the product packaging or contact Babelio customer support. Protection plans may also be available for extended coverage.

For customer support, inquiries, or to explore other Babelio products, please visit the official Babelio store on Amazon or contact their customer service directly.

Babelio Store: Visit Babelio Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DT3TQC21

More documents and user manuals: **https://manuals.plus/**