

LITFAD LT1327790ZM

LITFAD Modern Arc Floor Lamp User Manual

Model: LT1327790ZM

INTRODUCTION

Thank you for purchasing the LITFAD Modern Arc Floor Lamp. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new floor lamp. Please read these instructions carefully before use and retain them for future reference.

SAFETY INSTRUCTIONS

To ensure safe operation and prevent personal injury or damage to the lamp, please observe the following safety guidelines:

- For a safe and secure installation, ensure that the electrical box to which this fixture will be mounted is properly attached to a structural member of the building.
- All wires are connected. When unpacking, be careful not to pull with wires as a bad connection may result.
- Do not connect electricity until your fixture is fully assembled.
- To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug the fixture and allow it to cool prior to replacing the light bulb.
- Do not touch the bulb when the fixture is turned on or look directly at a lit bulb. Keep flammable materials away from a lit bulb.
- This lamp is designed for indoor use only.
- Ensure the lamp is placed on a stable, level surface to prevent tipping.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Marble Base (Rectangle)
- Arc Lamp Arm (Stainless Steel, multiple sections)

- Lamp Shade (Nickel finish)
- Foot Switch with Power Cord
- Assembly Hardware (screws, washers, etc.)
- User Manual (this document)

SETUP AND ASSEMBLY

Assembly is required for this floor lamp. It is recommended to have assistance due to the weight of the marble base. Please follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Attach Arc Arm to Base:** Securely fasten the lower section of the stainless steel arc arm into the marble base using the provided hardware. Ensure all connections are tight.
3. **Assemble Arc Sections:** Connect the remaining sections of the arc arm, twisting or locking them into place as per the design. Ensure the internal wiring is not pinched.
4. **Install Lamp Shade:** Attach the nickel lamp shade to the end of the arc arm. Ensure it is firmly secured.
5. **Insert Bulb:** Screw in an appropriate E26/E27 bulb (not included) into the lamp holder. Do not overtighten.
6. **Position Lamp:** Carefully move the assembled lamp to its desired location. Due to the heavy marble base, it is advisable to have assistance.
7. **Connect Power:** Plug the power cord into a standard AC110-120V electrical outlet.



Image: Overview of the LITFAD Modern Arc Floor Lamp's main structural components, including the arc arm, shade, and marble base.




Image: Diagram illustrating the adjustable dimensions of the LITFAD Modern Arc Floor Lamp, showing its width and height measurements.

OPERATING INSTRUCTIONS

The LITFAD Modern Arc Floor Lamp is operated via a convenient foot switch.

- **Turning On/Off:** Once the lamp is plugged into a power outlet, press the foot switch located on the power cord to turn the light on or off.
- **Bulb Type:** This lamp is compatible with E26/E27 base LED, Incandescent, or Fluorescent bulbs. Ensure the bulb wattage does not exceed the lamp's maximum rating (refer to specifications).



Image: Close-up view of the black circular foot switch and standard two-prong power plug for the LITFAD Modern Arc Floor Lamp.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your lamp.

- **Cleaning:** Disconnect the power before cleaning. Wipe the stainless steel and marble surfaces with a soft, dry cloth. Avoid abrasive cleaners or solvents that may damage the finish.
- **Bulb Replacement:** Always turn off and unplug the lamp before replacing the bulb. Allow the old bulb to cool completely. Unscrew the old bulb and screw in a new E26/E27 bulb of the appropriate type and wattage.
- **Inspecting Wiring:** Periodically check the power cord and connections for any signs of wear or damage. If damage is found, discontinue use and contact customer support.



Image: Close-up of the nickel-finished lamp shade, showing its smooth surface and perforated top for light dispersion.

TROUBLESHOOTING

If you encounter issues with your lamp, refer to the following common problems and solutions:

- **Lamp Does Not Turn On:**

- Ensure the power cord is securely plugged into a working electrical outlet.
- Check if the light bulb is properly screwed in and not burnt out. Replace if necessary.
- Verify that the foot switch is fully pressed.
- Check your home's circuit breaker.

- **Light Flickers:**

- Ensure the bulb is screwed in tightly.
- Try a different bulb to rule out a faulty bulb.
- Check for loose connections in the lamp's wiring (only if safely accessible and you have electrical knowledge).

- **Lamp is Unstable:**

- Ensure the lamp is placed on a flat, level surface.
- Verify that the arc arm is securely fastened to the marble base.

SPECIFICATIONS

Attribute	Detail
Model Number	LT1327790ZM
Fixture Width (Adjustable)	72.8" (185 cm) - 82.6" (210 cm)
Fixture Height (Adjustable)	82.6" (210 cm) - 90.5" (230 cm)
Product Dimensions (Overall)	13"D x 83"W x 90.5"H
Bulb Type	LED/Incandescent/Fluorescent
Bulb Base	E26/E27
Number of Lights	1 Light
Bulb Included	No
Power Source	Plug In Electric (Corded)
Switch Type	Foot Switch
Voltage	AC110-120V
Material	Stainless Steel, Marble
Shade Color	Nickel
Assembly Required	Yes

WARRANTY AND SUPPORT

For any questions regarding your LITFAD Modern Arc Floor Lamp, or if you require assistance, our online service is available 24 hours a day, 7 days a week. Please refer to your purchase documentation for contact details.