

[Manuals.plus](#) /

› [ESR](#) /

› ESR Stylus Pen for iPad (Model TSAJHBQ11) User Manual

ESR TSAJHBQ11

ESR Stylus Pen for iPad (Model TSAJHBQ11) User Manual

Comprehensive instructions for setup, operation, and maintenance.

1. INTRODUCTION

This manual provides detailed instructions for the ESR Stylus Pen, Model TSAJHBQ11. Please read this manual carefully before using the product to ensure proper function and longevity.



Image 1.1: The ESR Stylus Pen, showcasing its sleek black design and included replacement nibs and USB-C charging port.

2. COMPATIBILITY

The ESR Stylus Pen is compatible with specific iPad models released in 2018 or later, running iOS 12.2 and above. Verify your iPad model against the list below to ensure compatibility.

- **NEW 2025 iPad 11th (A16) & 10th Generation** (Writing & Magnetic Attachment)
- **iPad Air 11-inch & 13-inch (M3)**
- **iPad Pro 11-inch & 13-inch (M4)**
- **iPad 9th/8th/7th/6th Generation**
- **iPad Air 11/13 (M2)**
- **iPad Air 3rd/4th/5th Generation**

- iPad Pro 11 inch 1st/2nd/3rd/4th Generation
- iPad Pro 12.9 inch 3rd/4th/5th/6th Generation
- iPad Mini 5th/6th Generation

Note: This stylus is not compatible with other iPad models, iPhone, Android devices, Microsoft devices, or any other non-listed devices.

Compatible with iPads released in 2018 or later



* Requires iOS 12.2 or above

iPad 11" (A16) 2025/ 10th Gen 2022		A3354, A3355, A3356, A2696, A2757, A2777, A3162
iPad Air 11" (M3) 2025		A3266, A3267, A3270
iPad Air 13" (M3) 2025		A3268, A3269, A3271
iPad(9th/8th/7th/6th Gen)		A2605, A2604, A2603, A2602, A2430, A2429, A2428, A2270, A2200, A2198, A2197, A1954, A1893
iPad Air (5th/4thGen)		A2588, A2589, A2591, A2316, A2324, A2325, A2072
iPad Air(3rd Gen)		A2152, A2123, A2153, A2124
iPad mini (6th/5th Gen)		A2124, A2125, A2126, A2133, A2567, A2568, A2569
iPad Pro 11" (2022/2021/2020/2018)		A2759, A2435, A2761, A2762, A2377, A2459, A2301, A2460, A2228, A2068, A2230, A2231, A1980, A2013, A1934, A1979
iPad Pro 12.9" (2022/2021/2020/2018)		A2436, A2764, A2437, A2766, A2378, A2461, A2379, A2462, A2229, A2069, A2032, A2233, A1876, A2014, A1895, A1983
iPad Air 11" (M2) 2024/ Air 13" (M2) 2024		A2902, A2903, A2904, A2898, A2899, A2900
iPad Pro 11" (M4) 2024/ Pro 13" (M4) 2024		A2836, A2837, A3006, A2925, A2926, A3007

*Only iPad models with the icon support magnetic attraction

Image 2.1: Detailed compatibility chart showing supported iPad models and their corresponding model numbers. Models with a blue 'U' icon

support magnetic attachment.

3. SETUP AND FIRST USE


3.1 Charging the Stylus

Before first use, fully charge the stylus. The stylus features a USB-C charging port.

1. Locate the USB-C charging port on the stylus.
2. Connect a USB-C cable to the stylus and a power source.
3. A full charge takes approximately 30 minutes, providing up to 13 hours of in-use time or 5 minutes for standby mode.

Fully Charge in 30 Minutes

30-min USB-C charging



*Based on Pencil that starts fully charged and is used continuously to draw

Image 3.1: The ESR Stylus Pen connected to a USB-C charging cable, illustrating the charging process.

3.2 Activating the Stylus

The ESR Stylus Pen does not require Bluetooth pairing with your iPad. Simply double-tap the top of the stylus to turn it on or off.

No Need to Pair

Just double-tap to start creating



Image 3.2: A hand demonstrating the double-tap gesture on the top of the stylus to power it on or off.

4. OPERATING THE STYLUS

4.1 Smooth and Precise Writing

The stylus provides a smooth and precise writing and drawing experience with minimal lag. The 1.5mm tip allows for

Smooth and Precise



Image 4.1: A close-up view of the stylus tip interacting with an iPad screen, illustrating its precision for drawing and writing.

4.2 Palm Rejection

Rest your hand naturally on the iPad screen while using the stylus. The palm rejection feature prevents unintended marks from your hand, allowing for comfortable and accurate use.

Palm Rejection and Tilt Sensitivity






Image 4.2: A user's hand resting on the iPad screen while drawing with the stylus, highlighting the palm rejection functionality.

4.3 Tilt Sensitivity

The built-in sensor detects the angle of the stylus, allowing you to vary line thickness and create shading effects. Adjust the angle of the nib to achieve different artistic results, similar to a traditional pencil.




Image 4.3: Illustrations showing how the stylus creates different line widths based on the tilt angle (90°, 60°, 45°).

4.4 Magnetic Attachment

For convenient storage, the stylus can magnetically attach to compatible iPad models. This feature helps keep your stylus secure and easily accessible. Note that magnetic attachment does not provide wireless charging for this model.

Secure Magnetic Attachment



Does not support wireless charging

Image 4.4: The stylus attached magnetically to the side of an iPad, indicating secure storage. A note clarifies that wireless charging is not supported.

5. MAINTENANCE

5.1 Replacing the Nib

The stylus comes with durable, replaceable nibs. Regular use may cause wear, and replacement nibs are included to ensure continued optimal performance.

1. Gently twist the existing nib counter-clockwise to remove it.

2. Select a new replacement nib.
3. Twist the new nib clockwise onto the stylus until it is securely fastened.

Durable and Replaceable Nib

Nib supports everyday use for 1 year



Includes 3 replacement nibs

Image 5.1: The ESR Stylus Pen shown with three additional replacement nibs, illustrating the replaceable design.

5.2 Cleaning

Wipe the stylus body with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.

6. TROUBLESHOOTING

Problem	Solution
Stylus does not turn on.	Ensure the stylus is charged. Double-tap the top of the stylus firmly to activate.
Stylus is not responding on iPad.	• Confirm your iPad model is compatible (refer to Section 2). • Ensure the stylus is powered on. • Check if your iPad's iOS version is 12.2 or above. • If you have previously paired an Apple Pencil, disconnect it from your iPad's Bluetooth settings.
Inaccurate or inconsistent lines.	• Check if the nib is securely attached. • Replace the nib if it appears worn (refer to Section 5.1). • Ensure the iPad screen is clean.
Stylus disconnects frequently.	Ensure the stylus is fully charged. If the issue persists, contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	TSAJHBQ11
Brand	ESR
Material	Aluminum
Color	Black
Item Weight	1.76 ounces (0.05 Kilograms)
Package Dimensions	7.99 x 2.2 x 0.67 inches
Batteries	1 Nonstandard Battery required (not included)
Charging Port	USB-C
Charging Time	Approx. 30 minutes for full charge
Usage Time	Up to 13 hours (continuous use)
Standby Time	5 minutes (before auto-power off)
Key Features	Tilt Sensitivity, Palm Rejection, Magnetic Attachment (for compatible iPads), No Bluetooth Pairing Required

8. WARRANTY AND SUPPORT

ESR provides comprehensive customer support for this product, including:

- Detailed setup videos and FAQs.

- A comprehensive 12-month warranty.
- Lifetime support.
- Personalized help.

For assistance, please visit the official ESR support website or contact their customer service team directly.

© 2025 ESR. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question