Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lawyettle XG7003O-W1WH

Lawyettle Dusk to Dawn Outdoor Wall Lights User Manual

Model: XG7003O-W1WH

1. Important Safety Information

Please read all instructions carefully before installation and use. Retain this manual for future reference.

- **Electrical Safety:** Always turn off power at the circuit breaker before installing, servicing, or cleaning the fixture. If you are unsure about electrical wiring, consult a qualified electrician.
- **Grounding:** Ensure the fixture is properly grounded to avoid potential electrical shock.
- **Outdoor Use:** This fixture is designed for outdoor use and is waterproof. However, ensure all connections are sealed properly to prevent water ingress.
- **Bulb Type:** Use only E26 base bulbs with a maximum wattage of 60W. Do not exceed the recommended wattage.
- **Handling:** Handle glass components with care to prevent breakage.

2. What's in the Box

Verify that all components are present before beginning installation.

- Outdoor Wall Light Fixture (2 units)
- Mounting Hardware (including mounting plate, screws, wire nuts)
- User Manual



Image: Detailed view of the outdoor wall light fixture, highlighting its premium metal construction, advanced photocell sensor, water ripple glass, and open bottom design for easy maintenance.

3. Specifications

Feature	Detail
Brand	Lawyettle
Model Number	XG7003O-W1WH
Color	White
Material	Glass, Metal
Dimensions (L x W x H)	7.6" x 6.5" x 12.75"

Mounting Backplate	4.5"L x 5.5"H
Power Source	Corded Electric
Voltage	110 volts
Bulb Base	E26 (Bulb not included)
Max Wattage	60 watts
Light Source Compatibility	Incandescent, LED, CFL
Special Features	Dusk to Dawn Sensor, Waterproof, Anti-Rust
Certification	ETL Listed




Image: Diagram showing the dimensions of the outdoor wall light fixture (7.6" L x 6.5" W x 12.75" H) and the mounting backplate (4.5" L x 5.5" H), along with key specifications like color, voltage, material, power source, and wattage.

4. Setup and Installation

Follow these steps to properly install your outdoor wall light fixture. Ensure power is OFF at the circuit breaker before starting.

1. **Prepare the Area:** Turn off the power to the junction box at your circuit breaker. Ensure the wall surface is clean and dry.
2. **Install Mounting Plate:** Attach the provided mounting plate to your existing junction box using the screws provided. Ensure it is securely fastened.
3. **Connect Wires:**
    - Connect the **black wire** from the fixture to the **black wire** from the junction box (live) using a wire nut.
    - Connect the **white wire** from the fixture to the **white wire** from the junction box (neutral) using a wire nut.
    - Connect the **ground wire** (bare copper or green) from the fixture to the **ground wire** from the junction box.

    Ensure all connections are tight and secure.
4. **Mount the Fixture:** Carefully tuck the wires into the junction box. Align the fixture with the mounting plate and secure it using the provided screws or nuts.
5. **Install Bulb:** Insert an E26 base bulb (max 60W, not included) into the socket.
6. **Restore Power:** Turn the power back on at the circuit breaker.

Your browser does not support the video tag.

Video: A step-by-step guide demonstrating the installation process for the Lawyettle Outdoor Wall Lights, including mounting the backplate and connecting electrical wires.

5. Operating Instructions

Your Lawyettle outdoor wall light features an integrated Dusk to Dawn sensor for automatic operation.

- **Automatic On/Off:** The built-in photocell sensor detects ambient light levels. The light will automatically turn ON when it gets dark (typically below 20 LUX) and turn OFF when it becomes bright (typically above 90 LUX).
- **Sensor Placement:** Ensure the sensor is not obstructed by eaves, trees, or other objects that might block natural light. Avoid placing the fixture near other light sources (e.g., streetlights, other bright outdoor lights) that could interfere with the sensor's operation, causing it to turn off prematurely.




Image: Illustration of the dusk to dawn photocell sensor in action, showing the light automatically turning off in the morning (LUX > 90) and turning on at night (LUX < 20).

6. Maintenance

- **Cleaning:** To clean the fixture, ensure power is off. Wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or glass. The open-bottom design allows for easy cleaning of the interior and bulb.
- **Bulb Replacement:** Ensure power is off before replacing the bulb. The fixture features an open bottom for convenient one-hand bulb replacement. Allow the old bulb to cool before removing. Insert a new E26 base bulb (max 60W).
- **Weather Resistance:** This fixture is designed to be weather-resistant (waterproof, anti-rust, snowproof, heat-resistant). Regular inspection for any damage is recommended, especially after extreme weather conditions.



Image: Display of various E26 bulb types (incandescent, LED, CFL) that are compatible with the Lawyettle outdoor wall light, emphasizing that the bulb is not included.

7. Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on at night.	◦ Power is off at the switch or breaker. ◦ Bulb is faulty or not installed correctly. ◦ Sensor is obstructed or receiving too much light. ◦ Wiring issue.	◦ Check power supply. ◦ Replace bulb and ensure it's screwed in tightly. ◦ Clear obstructions from sensor; relocate if necessary to avoid interference from other light sources. ◦ Check wiring connections (with power off).

Light stays on during the day.	◦ Sensor is obstructed or not receiving enough light. ◦ Sensor is faulty.	◦ Clear obstructions from sensor. Ensure it's exposed to direct daylight. ◦ Contact customer support if sensor is suspected to be faulty.
Light flickers.	◦ Loose bulb. ◦ Faulty bulb. ◦ Loose wiring connection.	◦ Tighten bulb. ◦ Replace bulb. ◦ Check wiring connections (with power off).

8. Warranty Information

This Lawyettle product is covered by a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

The warranty does not cover damage caused by improper installation, accident, misuse, abuse, neglect, or unauthorized modification.

9. Customer Support

If you have any questions, require assistance, or encounter issues not covered in this manual, please contact Lawyettle customer support through your retailer or the official Lawyettle website.

For more information about Lawyettle products, visit the Lawyettle Store on Amazon.

© 2023 Lawyettle. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DT3Y85RZ

More documents and user manuals: **https://manuals.plus/**