



[Manuals.plus](#) /

› [SHA CERLIN](#) /

› SHA CERLIN 81in Multi-Level Tall Cat Tree Tower User Manual

SHA CERLIN AKKT006

SHA CERLIN 81in Multi-Level Tall Cat Tree Tower User Manual

Model: AKKT006

[Contents](#) [Setup](#) [Operation](#) [Introduction](#) [Maintenance](#) [Safety Instructions](#) [Troubleshooting](#) [Package](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for purchasing the SHA CERLIN 81in Multi-Level Tall Cat Tree Tower. This manual provides essential information for the safe assembly, operation, and maintenance of your cat tree. Please read these instructions carefully before assembly and retain them for future reference.

This multi-level cat tree is designed to provide a stable and engaging environment for indoor cats, offering various platforms for climbing, scratching, resting, and playing. It features multiple perches, condos, hammocks, and sisal scratching posts to cater to the natural instincts of cats, including larger breeds and multi-cat households.

2. SAFETY INSTRUCTIONS

- **Adult Assembly Required:** This product requires adult assembly. Keep small parts away from children during assembly.
- **Placement:** Place the cat tree on a flat, stable surface to prevent tipping. Avoid placing it near windows or areas where it could be exposed to extreme temperatures or moisture.
- **Stability:** Ensure all screws and fasteners are tightened securely during assembly. Regularly check for loose parts and tighten as needed. Utilize the included anti-tip kit to secure the cat tree to a wall for enhanced stability, especially for active or multiple cats.
- **Weight Capacity:** The cat tree is designed to support up to 33 pounds on its main platforms. Hammocks have a specific weight capacity of 22 pounds. Do not exceed these limits.
- **Inspection:** Periodically inspect the cat tree for any damage, wear, or loose components. Discontinue use if significant damage is found and repair or replace parts as necessary.

- **Pet Use Only:** This product is intended for pet use only. Do not allow children to climb or play on the cat tree.
- **Choking Hazard:** Small parts, such as dangling toys, can become detached. Monitor your pets and remove any damaged or loose toys to prevent choking hazards.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Baseboard(s)
- Support Posts (various lengths, some wrapped in sisal rope)
- Platforms/Perches (various sizes)
- Cat Condos/Houses
- Hammocks
- Ramp/Scratching Board
- Dangling Toys (optional, may vary)
- Hardware Pack (screws, bolts, washers, Allen wrench)
- Anti-Tip Kit (wall anchor, strap, screw)
- Assembly Instructions

PRODUCT DIMENSIONS



Weight Capacity

Hammock: 22 lbs.
Other: 33 lbs.



81.1"



Image: Diagram showing the overall dimensions and weight capacity of the cat tree. The total height is 81.1 inches. Hammock capacity is 22 lbs, other platforms 33 lbs.

4. SETUP AND ASSEMBLY

Follow these step-by-step instructions for assembling your SHA CERLIN cat tree. It is recommended to assemble the unit in the room where it will be used.

- 1. Prepare the Area:** Clear a spacious area for assembly. Lay out all components and hardware. Refer to the included parts list to identify each piece.
- 2. Assemble the Base:** Attach the lowest support posts to the main baseboard using the provided screws and Allen wrench. Ensure they are tightened securely.
- 3. Build Upwards:** Continue attaching platforms, condos, and additional support posts layer by layer, following the numerical or alphabetical order indicated in the detailed assembly diagram (refer to the separate instruction sheet provided in the package).
- 4. Attach Hammocks and Ramps:** Securely fasten hammocks and ramps to their designated positions on the structure.
- 5. Install Top Perches:** Mount the top perches and any remaining support posts to complete the main structure.

6. **Final Tightening:** Once fully assembled, go back and re-tighten all screws and bolts to ensure maximum stability. Do not overtighten.
7. **Install Anti-Tip Kit:** For enhanced safety, especially with active cats or in multi-cat households, attach the anti-tip strap to a sturdy wall stud using the provided hardware. Secure the other end of the strap to the cat tree.



Image: The fully assembled SHA CERLIN cat tree, showcasing its multi-level design with cats resting on perches and inside condos.

ANTI WOBBLING OVER

Defend the cat's wellbeing



Image: Illustration demonstrating the anti-tip mechanism, showing how to secure the cat tree to a wall using an anchor and strap to prevent wobbling or tipping.

5. OPERATION AND USE

The SHA CERLIN cat tree is designed for various feline activities:

- **Climbing and Exploring:** Cats can utilize the multiple levels and platforms for climbing, jumping, and exploring their environment from different heights.
- **Scratching:** The sisal-wrapped posts and scratching ramp provide designated areas for cats to sharpen their claws, helping to protect your furniture.
- **Resting and Napping:** The cozy condos, soft hammocks, and plush perches offer comfortable spots for cats to rest, nap, and observe their surroundings.
- **Play:** Dangling toys (if included) encourage playful interaction and exercise.

SCRATCHING SUPPORT

Made of sisal and keep them away from your furniture.



Image: A cat actively using the sisal scratching post and ramp, demonstrating the scratching support features of the cat tree.



WIDEN

top perch



LARGER CATS PREFERRED

More roomy space to relax and enjoy the view.

BROADEN

cat condo




Image: Close-up view highlighting the widened top perch and broadened cat condo, designed to accommodate larger cats comfortably.

EXTRA SPACIOUS HAMMOCK



Image: A detailed view of the extra spacious and soft hammock, providing a comfortable resting spot for cats.

6. MAINTENANCE

Regular maintenance will extend the life of your cat tree and ensure a hygienic environment for your pets.

- **Cleaning:**
 - **Spot Cleaning:** For small stains, use a damp cloth with mild soap. Blot the area gently and allow it to air dry completely.
 - **Vacuuming:** Regularly vacuum the plush surfaces to remove loose fur and dust.
 - **Deep Cleaning:** For deeper cleaning, specialized pet upholstery cleaners can be used, following the product instructions. Avoid saturating the material.
- **Sisal Posts:** The sisal rope is designed for scratching. Over time, it may fray. This is normal wear and tear. If the rope becomes excessively damaged, consider replacing the post if possible, or monitor for sharp edges.
- **Hardware Check:** Every few weeks, inspect all screws and bolts. Re-tighten any that have become loose due to cat activity.
- **Damage Inspection:** Check for any tears in the fabric, broken platforms, or unstable components. Address any issues promptly to prevent injury to your pets.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Cat tree feels wobbly or unstable.	Loose screws; uneven floor; anti-tip kit not installed or improperly installed.	Re-tighten all screws. Ensure the cat tree is on a flat surface. Install or properly secure the anti-tip kit to a wall stud.
Cats are not using the scratching posts.	Preference for other surfaces; unfamiliarity with sisal.	Encourage use by sprinkling catnip on the sisal posts. Gently guide your cat's paws to the posts. Ensure other scratching options are less appealing.
Dangling toys are broken or detached.	Normal wear and tear from play; aggressive play.	Remove broken toys immediately to prevent choking hazards. Replace with new cat-safe toys if desired.
Difficulty during assembly.	Incorrect part identification; steps out of order.	Refer to the detailed assembly instructions and diagrams provided in the package. Ensure all parts are correctly identified before attaching. Do not force parts together.

8. SPECIFICATIONS

Brand	SHA CERLIN
Model Name	AKKT006
Product Dimensions (L x W x H)	116.1L x 62W x 206H centimetres (approx. 45.7L x 24.4W x 81.1H inches)
Item Weight	28.58 kg (approx. 63 lbs)
Material	CARB-certified P2-grade particle board, Plush fabric, Sisal rope
Color	Dark Grey
Weight Capacity (Platforms)	Up to 33 lbs
Weight Capacity (Hammock)	Up to 22 lbs
Special Features	Anti-Scratch, Anti-Slip, Tip Resistant (with included kit)
Recommended Use	Indoor, for all breed sizes of cats
UPC	749655424082

9. WARRANTY AND SUPPORT

SHA CERLIN products are manufactured with quality and durability in mind. For specific warranty information, please refer to the documentation included with your purchase or contact SHA CERLIN customer support directly.

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact SHA CERLIN customer service. Please have your model number (AKKT006) and purchase details ready when contacting support.

