

Babelio BEBAM63

Babelio R30 Flex Pro Removable & No Bottom Bar Baby Gate Instruction Manual

Model: BEBAM63

[Introduction](#)
[Instructions](#)

[Safety Information](#)
[Maintenance](#)

[Parts List](#)
[Troubleshooting](#)

[Setup & Installation](#)
[Specifications](#)

[Operating](#)
[Support](#)

1. INTRODUCTION

The Babelio R30 Flex Pro Removable & No Bottom Bar Baby Gate is designed to provide a secure barrier for children and pets in stairs and doorways. This hardware-mounted gate offers a wide walk-through area and features an auto-close function for convenience and safety. Its modular design allows for easy removal when not needed, minimizing tripping hazards.



Image: The Babelio R30 Flex Pro Baby Gate, black, installed in a doorway, showcasing its wide walk-through design.

2. IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always install and use gate as directed.
- This gate is designed for children from 6 to 24 months.
- Never use with a child able to climb over or dislodge the gate.
- This product will not necessarily prevent all accidents. Never leave child unattended.
- Regularly check all parts for proper installation and adjustment.
- Do not use if any components are damaged or missing.
- Ensure the gate is securely mounted to a solid surface (wood stud, concrete, brick). Do not rely on drywall anchors alone for critical installations like stairs.
- The "no bottom bar" design eliminates a tripping hazard, but ensure the gate is installed flush with the floor or step where appropriate.
- This gate is certified by CPSIA for safety.



Image: A child and a golden retriever dog are safely contained behind the installed Babelio baby gate, demonstrating its use as a barrier.

3. PARTS LIST

Before beginning installation, please ensure all parts are present and undamaged. Refer to the diagram below for identification.

Item	Description	Quantity
Main Gate	Pre-assembled gate frame with opening mechanism	1
Long Gate Accessory	Vertical bar for wider openings (wall-mounted)	1
Short Gate Accessory	Vertical bar for narrower openings (wall-mounted)	1
Short Screws	For securing gate accessories to wooden surfaces	8
Long Screws	For securing gate accessories to wooden surfaces (longer)	8
Allen Key	For adjusting hexagonal nuts	1
Pipe Cover	Plastic covers for pipe ends	4
Wall Anchors	For securing to drywall/concrete (use with long screws)	8



Image: A visual representation of all included components and accessories for the Babelio baby gate, laid out for easy identification.

4. SETUP & INSTALLATION

This gate is hardware-mounted and requires drilling. Ensure you have the necessary tools (electric drill, measuring tape, pencil) and follow these steps carefully.

4.1 Preparation

- **Measure the opening:** The gate is adjustable to fit openings 35.5-55 inches wide. Measure your desired installation area accurately.
- **Identify wall material:** Determine if your wall is wood, drywall, concrete, or brick to select appropriate screws and anchors.
- **Disassemble Long Gate Accessory:** If the Long Gate Accessory is pre-assembled with the Main Gate, disassemble it first as per the manual diagram.



Image: The Babelio baby gate installed in a wide doorway, with text indicating its adaptable size to fit 35.5-55 inch openings and a height of 30 inches.

4.2 Installing Wall Brackets

1. **Position the vertical bars:** Place the Long Gate Accessory and Short Gate Accessory (or two Long Gate Accessories for wider openings) against the wall in your desired location. Ensure they are plumb and at the correct height.

2. **Mark drilling points:** Use a pencil to mark the drilling points through the pre-drilled holes on the plastic brackets of the vertical bars.
3. **Drill pilot holes:**
 - For **wooden walls/studs:** Drill 5/64" (2mm) pilot holes. Use short screws.
 - For **drywall/concrete/brick:** Drill 5/16" (8mm) pilot holes. Insert wall anchors, then use long screws.
4. **Secure brackets:** Screw the vertical bars securely to the wall using the appropriate screws. Ensure they are firmly attached and do not wobble.

How to Quickly Install It?



Image: A detailed diagram illustrating the six steps for quick installation of the Babelio baby gate, including marking, drilling, and securing components.

Your browser does not support the video tag.

Video: A demonstration of the Babelio Easy to Remove Baby Gate for Stairs, showing the installation process and its functionality. This video is provided by Babelio (Seller).

4.3 Attaching the Main Gate

1. **Connect the Main Gate:** Align the Main Gate with the installed vertical bars. Slide the gate's hinges into the corresponding slots on the wall-mounted brackets.
2. **Adjust width:** Loosen the hexagonal nuts on the four plastic latches of the Main Gate using the provided Allen key. Extend the gate to the desired width to fit snugly between the vertical bars.
3. **Tighten nuts:** Once the gate is properly positioned and extended, tighten all four hexagonal nuts firmly to secure the gate's width.
4. **Install pipe covers:** Place the pipe covers over any exposed pipe ends for a finished look and added safety.



Image: The Babelio baby gate installed at the top of a staircase, highlighting its adjustable fit feature to accommodate various stair widths.

5. OPERATING INSTRUCTIONS

5.1 Opening the Gate

To open the gate, use a one-hand operation:

1. Press the button on the top of the handle.
2. Simultaneously pull back the handle.
3. Lift the gate slightly to disengage the bottom latch.
4. Swing the gate open in either direction.

One-Hand Opening



Image: A visual guide demonstrating the simple one-hand operation to open the Babelio baby gate, involving pressing, pulling, and lifting the handle.

5.2 Auto-Close and Stay-Open Features

- **Auto-Close:** If the gate is opened less than 90 degrees, it will automatically swing shut and latch securely.
- **Stay-Open:** If the gate is opened past 90 degrees, it will remain in the open position, allowing for free passage.

Gently push it back towards the closed position for the auto-close feature to engage.

Adjustable Fit for Stairs



Image: The Babelio baby gate demonstrating its auto-lock function, showing the gate automatically closing when opened less than 90 degrees.

Your browser does not support the video tag.

Video: A demonstration of the Babelio easy to remove & no bottom bar baby gate, highlighting its auto-close and stay-open features. This video is provided by Babelio (Seller).

5.3 Removable Design

The gate frame can be quickly removed from the wall-mounted vertical bars for easy storage or when not in use. This feature is ideal for intermittent use or when you need a clear opening without the gate.



Effortless Removal for Flexible Use

Image: The Babelio baby gate partially removed from its wall mounts, illustrating its effortless removal for flexible use and storage.

6. MAINTENANCE

- **Cleaning:** Wipe the gate regularly with a damp cloth and mild soap. Do not use abrasive cleaners or harsh chemicals.
- **Inspection:** Periodically check all screws, latches, and mounting points to ensure they are secure. Tighten any loose components.
- **Lubrication:** If the hinges become stiff, apply a small amount of silicone-based lubricant to ensure smooth operation.
- **Storage:** When not in use, store the gate in a dry place away from direct sunlight or extreme temperatures.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Gate does not latch securely.	Gate is not properly aligned or adjusted.	Loosen hexagonal nuts, adjust gate width for proper alignment, then re-tighten. Ensure vertical bars are plumb.
Gate feels wobbly after installation.	Screws are loose or not properly anchored.	Check all mounting screws and brackets. Re-tighten if loose. Ensure proper wall anchors were used for drywall/concrete.
Gate is difficult to open.	Mechanism is stiff or misaligned.	Apply silicone lubricant to hinges. Check for any obstructions. Ensure the lift mechanism is not binding.
Gate does not auto-close.	Gate is opened past 90 degrees (stay-open feature engaged) or hinges are stiff.	Ensure gate is not opened too wide. Check for obstructions. Lubricate hinges if necessary.

8. SPECIFICATIONS

- **Brand:** Babelio
- **Model Number:** BEBAM63
- **Material Type:** Alloy Steel
- **Color:** Black
- **Mounting Type:** Wall Mount (Hardware Mounted)
- **Item Dimensions (W x H):** 35.5-55" W x 30" H
- **Item Weight:** 7.7 Pounds
- **Age Range Description:** Baby (6-24 months)
- **Certifications:** CPSIA tested

9. CUSTOMER SUPPORT

For any questions, concerns, or assistance with your Babelio R30 Flex Pro Baby Gate, please contact our customer service team:

- **Email:** support@babeliobaby.com
- **Online Store:** Visit the [Babelio Store on Amazon](#) for more products and information.

Please retain your purchase receipt for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question