

[Manuals.plus](#) /

› [Casaottima](#) /

› Casaottima Gaming Desk User Manual

Casaottima B02021701003

Casaottima Gaming Desk User Manual

Model: B02021701003

IMPORTANT SAFETY INFORMATION

For your safety and to prevent damage to the product, please read and follow all instructions carefully. Keep this manual for future reference.

- Always assemble the desk according to the instructions.
- Ensure the desk is properly anchored to the wall or floor to prevent tipping, especially when using the L-shaped configuration.
- Be cautious when using the built-in power outlets and USB ports to prevent electrical hazards.
- Keep the desk and its components away from water and heat sources.
- Always unplug the desk from the power source before making any adjustments or cleaning.

PRODUCT OVERVIEW

The Casaottima Gaming Desk is a versatile L-shaped computer desk designed for home office, gaming, or studio setups. It features built-in power outlets, LED lighting, and various storage solutions.



Image: Overview of the Casaottima L-Shaped Gaming Desk, showcasing its L-shape, integrated shelving, LED lighting, and power outlets. A gaming setup with multiple monitors is displayed on the desk surface.

This desk offers a flexible L-shaped design with a reversible hutch, allowing it to adapt to various room layouts. It includes a built-in charging station with 3 AC outlets and 2 USB ports, and customizable RGB lighting for ambiance. Smart storage solutions such as shelves, a CPU stand, a headphone hook, and a storage bag are integrated for organization.

PACKAGE CONTENTS

Please ensure all parts are present and in good condition before beginning assembly. Refer to the included parts list for identification.

- Desk Frame Components (various labeled parts A, B, C, D, E, F, G, H, I, J, K)
- Desktop Panels (M, N)
- Desktop Shelf Components (O, P, Q)
- CPU Stand (T, L)
- Fabric Storage Bag (U)
- Iron Hook (11)
- Power Outlet Unit (12)
- LED Light Strip (13)

- Cable Management Straps (14)
- Hardware (screws, nuts, adjustable foot pads, Allen wrench, open-end wrench)

ASSEMBLY INSTRUCTIONS

For ease and safety, it is recommended that two people assemble this desk. The entire assembly process typically takes about 45 minutes to 1 hour. Please note the warm tips that appear during the installation process in the video.

Your browser does not support the video tag.

Video: Official installation guide for the Casaottima L-Shaped Gaming Desk. This video provides step-by-step visual instructions for assembling the desk, including details on connecting frame components, installing the desktop, and integrating the electrical features and accessories.

Step 1: Installation of Desk Frames (Part 1)

Install the adjustable foot pads (1) onto parts A, B, and C. Use screw (5) to connect A and H, B and H, and C and I. Ensure that holes marked on B and C face the same direction. For a right-corner desk, install B on the right side of C; for a left-corner desk, install B on the left side of C.



Image: Diagram illustrating the first step of assembly, showing how to attach adjustable foot pads to the bottom of vertical frame pieces (A, B, C) and then connect them with horizontal support bars (H, I) using screws.

Step 2: Installation of Desk Frames (Part 2)

Connect B and C with G and F, using screws (5). Pay attention to the positions and orientations of the screw holes indicated on B, C, and F. Especially, the side of F with two screw holes needs to face G. Ensure that holes marked on B and C face the same direction. For a right-corner desk, install B on the right side of C; for a left-corner desk, install B on

the left side of C.




Image: Diagram showing the connection of frame components B and C with horizontal bars G and F. Red arrows indicate screw locations and the importance of aligning holes correctly for the L-shaped configuration.

Step 3: Installation of Desk Frames (Part 3)

Use screw (5) and screw (4) to connect A and B by E and D. Pay attention to the positions and orientations of the screw holes indicated on A, B, D and E.

Gaming Desk with Colorful LED Lights




Image: Diagram illustrating the connection of frame components A and B using bars E and D, with specific attention to screw placement and hole alignment for structural integrity.

Step 4: Stabilizing the Frame

Use screw (5) and nut (7) to install S. Use screw (4) to install R. These components provide additional stability to the desk frame.




Image: Diagram showing the installation of diagonal support bars (S and R) into the desk frame, secured with screws and nuts to enhance overall stability.

Step 5: Installing the CPU Stand

Use screw (2) to install T. Use screw (5) to install L on T. Do not install foot pad on part L.

Open Removable Shelf



Image: Diagram detailing the assembly and attachment of the CPU stand (parts T and L) to the main desk frame using screws. It specifies not to attach foot pads to part L.

Step 6: Attaching Desktop Panels

Use screw (5) to install M and N. Ensure proper alignment of the desktop panels with the frame.



Image: Diagram showing the process of securing the main desktop panels (M and N) to the underlying metal frame using screws, forming the complete L-shaped desk surface.

Step 7: Installing Fabric Bag and Iron Hook

Use screw (5) to install U. Use screw (5) to install (11). Screw through the cloth bag or hook and directly into the steel frame; Having screw holes on either the front or back is considered normal, as the desk is designed for reversible installation.



Image: Diagram illustrating the attachment of the fabric storage bag (U) and the iron hook (11) to the desk frame using screws. It notes that screw holes on either side are normal due to the reversible design.

Step 8: Installing Desktop Shelf (Part 1)

Use screw (6) and nut (7) to install J.



Image: Diagram showing the initial installation of the vertical supports (J) for the desktop shelf, secured with screws and nuts.

Step 9: Installing Desktop Shelf (Part 2)

Use screw (5) to install K.



Image: Diagram illustrating the attachment of the horizontal bar (K) to the previously installed vertical shelf supports using screws.

Step 10: Assembling Shelf Panels

Use screw (2) to install P on O.



Image: Diagram showing how to connect shelf panel P onto shelf panel O using screws, forming a complete shelf unit.

Step 11: Installing Assembled Shelf

Use screw (2) to install P&O. When installing P&O, if the steel frame is rather tight, loosen the installation screws on part K for adjustment. O and P can be mounted at different heights to meet different using needs.




Image: Diagram illustrating the attachment of the assembled shelf (P&O) to the vertical supports of the desk. It highlights that the shelf can be adjusted to different heights and advises loosening screws on part K if the fit is tight.

Step 12: Installing Top Shelf

Use screw (5) to install Q.




Image: Diagram showing the final step of installing the top shelf panel (Q) onto the upper section of the desk's vertical supports using screws.

Step 13: Installing Power Outlet Unit

Use screw (3) to install (12).

Open Removable Shelf

You can adjust the height of the shelf to use it as a bookshelves or monitor stand.



Image: Diagram illustrating the installation of the power outlet unit (part 12) onto the desk structure using screws (part 3).

Step 14: Installing LED Light Strip

Install the light strip (13) on the shelf. The light strip can be attached to any position according to personal preference, and the strap (14) is used to fix the wires of the light strip.

Convenient Iron Hook

Organize your headphones or bag



Image: Diagram showing the installation of the LED light strip (part 13) along the underside of a shelf, with cable management straps (part 14) used to secure the wiring.

OPERATING INSTRUCTIONS

Power Outlets and USB Ports

The desk is equipped with 3 AC outlets (125V/12A) and 2 USB ports (5V/2A) for convenient power access. Connect the desk's 6.6ft power cord to a wall outlet. You can then plug in your devices directly to the integrated outlets and USB ports.

Open Removable Shelf

You can adjust the height of the shelf to use it as a bookshelves or monitor stand.



Image: A close-up view of the integrated power outlet unit, showing three AC outlets and two USB ports, with devices plugged in.

LED Lighting

The LED strip features 10 static colors, 8 brightness grades, and 10 dynamic modes. It also includes a memory function that recalls your last setting. Use the inline controller to adjust colors, brightness, and modes to suit your preference.

Sturdy Metal Frame

X-shaped steel frame makes the desk more sturdy




Image: Visual representation of the desk's LED lighting capabilities, displaying various static colors and dynamic modes for different ambiance settings.

MAINTENANCE

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Electrical Components:** Ensure the power outlets and LED strip are kept dry. Do not attempt to disassemble or repair the electrical components yourself.
- **Structural Integrity:** Periodically check all screws and connections to ensure they remain tight. Tighten any loose hardware to maintain stability.
- **Heat and Moisture:** Keep the desk away from direct heat sources and excessive moisture to prevent warping or damage to the materials.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk wobbles after assembly.	Loose screws; uneven floor; adjustable foot pads not properly set.	Tighten all screws. Adjust the foot pads on the bottom of the legs to level the desk on uneven surfaces.
LED lights not working.	Power not connected; loose connection; faulty LED strip.	Ensure the power outlet unit is plugged in and the LED strip is securely connected. Check the inline controller for damage. If issues persist, contact customer support.
Power outlets/USB ports not working.	Desk not plugged in; circuit breaker tripped; loose wiring.	Verify the desk's power cord is securely plugged into a working wall outlet. Check your home's circuit breaker. Ensure the power outlet unit is properly installed and connected.
Missing parts during unboxing.	Packaging error.	Contact Casaottima customer support immediately with your purchase details and the specific missing parts.

SPECIFICATIONS

- **Brand:** Casaottima
- **Model Number:** B02021701003
- **Product Dimensions:** 53.15"D x 39.37"W x 58.27"H
- **Color:** Vintage
- **Style:** Modern
- **Base Material:** Metal
- **Top Material Type:** Engineered Wood
- **Item Weight:** 46 Pounds
- **Special Feature:** L-shaped, Built-in Outlet, LED Lights, Shelves, Storage Bag
- **Power Outlets:** 3 AC Outlets (125V/12A), 2 USB Ports (5V/2A)
- **Power Cord Length:** 6.6 ft
- **LED Lights:** 10 static colors, 8 brightness grades, 10 dynamic modes, memory function
- **Storage Options:** 2 shelves, 1 CPU stand, 1 storage bag
- **Assembly Required:** Yes

WARRANTY AND SUPPORT

Casaottima is committed to providing high-quality products and customer satisfaction. If your desk arrives damaged, has missing parts, or if you encounter any issues during assembly or use, please do not hesitate to contact our professional after-sales team. We aim to provide solutions within 24 hours.

For support, please refer to the contact information provided with your purchase or visit the official Casaottima store on Amazon: [Casaottima Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question