

[Manuals.plus](#) /

› [JTLB](#) /

› JTLB 3500W Portable Induction Cooktop User Manual (Model JTLBmg148ust5a-11)

JTLB JTLBmg148ust5a-11

JTLB 3500W Portable Induction Cooktop User Manual

Model: JTLBmg148ust5a-11

INTRODUCTION

Thank you for purchasing the JTLB 3500W Portable Induction Cooktop. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions thoroughly before use and retain them for future reference.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, injury to persons, or damage to the appliance, observe the following safety precautions:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. The ceramic plate remains hot after cooking. Use handles or knobs where provided.
- To protect against electrical shock, do not immerse the cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use the appliance for other than intended use.
- Ensure proper ventilation around the cooktop during operation.
- Only use cookware suitable for induction cooking (ferromagnetic materials).
- Keep magnetic objects away from the cooktop during operation.

PRODUCT OVERVIEW

The JTLB Portable Induction Cooktop features a sleek design with a durable ceramic cooking surface and an intuitive sensor touch control panel.



Image 1: Top-down view of the JTLB 3500W Portable Induction Cooktop, showing the ceramic cooking surface with the "IH" indicator and the control panel below.



Image 2: Angled view of the cooktop, highlighting the sensor touch control panel with various function buttons and the digital display.

Control Panel Features:

- **ON/OFF Button:** Powers the unit on or off.
- **Power Button:** Activates or adjusts the power level.
- **Temperature Button:** Activates or adjusts the temperature setting.
- **'+' / '-' Buttons:** Adjusts power, temperature, or timer settings.
- **Digital Display:** Shows power level, temperature, or time.
- **Time / Reservation Button:** Sets cooking time or schedules a delayed start.
- **Cooking Mode Indicators:** Lights for specific functions like Warm up, Soup/Congee (with 30kg/20kg/10kg options), Steam, Herbal Tea/Milk, Hand Movement, and Automatic.

SETUP

1. **Unpacking:** Carefully remove the cooktop from its packaging. Retain packaging for storage or transport.
2. **Placement:** Place the induction cooktop on a dry, stable, and level surface. Ensure there is adequate ventilation around the unit (at least 4 inches of clear space on all sides) to prevent overheating. Do not place it on a metal surface.
3. **Power Connection:** Plug the US standard 110V power cord into a grounded electrical outlet. Ensure the outlet matches the voltage requirements of the appliance.
4. **Cookware Selection:** Use only induction-compatible cookware. This includes pots and pans made of cast iron, enameled iron, or stainless steel with a magnetic bottom. A simple test is to see if a magnet sticks to the bottom of your cookware.

OPERATING INSTRUCTIONS

1. **Powering On:** Place induction-compatible cookware with contents on the center of the ceramic cooking surface. Press the **ON/OFF** button to turn on the cooktop. The digital display will illuminate.
2. **Selecting a Cooking Mode:**
 - **Manual Power/Temperature:** Press the **Power** or **Temperature** button, then use the '+' and '-' buttons to adjust the

desired power level or temperature.

- **Pre-set Functions:** Press the corresponding button for functions like **Warm up, Soup/Congee** (select 30kg, 20kg, or 10kg options based on volume), **Steam, Herbal Tea/Milk**, or **Automatic**. The cooktop will automatically adjust settings for these modes. The "Hand Movement" button likely cycles through additional modes or settings; refer to specific product documentation if available for its exact function.
3. **Setting the Timer:** Press the **Time** button, then use the '+' and '-' buttons to set the desired cooking duration. The cooktop will automatically turn off once the timer expires.
 4. **Using the Reservation Function:** Press the **Reservation** button (often shared with the Time button), then use '+' and '-' to set a delayed start time. The cooktop will begin cooking automatically after the set delay.
 5. **Powering Off:** After cooking, press the **ON/OFF** button to turn off the cooktop. The display may show "H" indicating the ceramic surface is still hot. Allow the unit to cool completely before cleaning or moving.

CLEANING AND MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your induction cooktop.

1. **Before Cleaning:** Always unplug the cooktop from the power outlet and allow it to cool completely. The ceramic plate can remain hot for some time after use.
2. **Ceramic Surface:** Wipe the ceramic glass surface with a damp cloth and a mild detergent. For stubborn stains, use a non-abrasive ceramic cooktop cleaner. Do not use abrasive pads, scouring powders, or harsh chemicals, as these can scratch or damage the surface.
3. **Cooktop Body:** Wipe the stainless steel body with a soft, damp cloth. Dry thoroughly.
4. **Ventilation Openings:** Ensure the ventilation openings on the sides and bottom of the unit are free from dust and debris. Use a soft brush or vacuum cleaner if necessary.
5. **Storage:** Store the cooktop in a dry, cool place when not in use.

TROUBLESHOOTING

If you encounter issues with your induction cooktop, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cooktop does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure the power cord is securely plugged into a working 110V outlet. Check circuit breaker.
Cooktop beeps or displays an error code (e.g., "E0").	No cookware or incompatible cookware detected; overheating; internal fault.	Place induction-compatible cookware on the cooktop. Ensure the cookware is centered. Allow the unit to cool if it's overheated. If the problem persists, unplug and plug back in.
Cooking is slow or inconsistent.	Incorrect power/temperature setting; unsuitable cookware; insufficient ventilation.	Adjust power/temperature settings. Use flat-bottomed, induction-compatible cookware that covers a significant portion of the cooking zone. Ensure proper ventilation.
Fan continues to run after turning off.	Normal cooling process.	This is normal. The fan will continue to run until the internal components have cooled down sufficiently.

If the issue is not resolved by the above steps, please contact the retailer or manufacturer for further assistance.

SPECIFICATIONS

- **Model:** JTLBmg148ust5a-11

- **Power:** 3500W (Wattage may vary based on specific model and region)
- **Voltage:** 110V (US Plug)
- **Product Dimensions:** 18.5 x 16.14 x 6.69 inches
- **ASIN:** B0DT4G6P6Z
- **Date First Available:** November 6, 2025



Image 3: Diagram showing the dimensions of the cooktop: 18.5 inches (length), 16.14 inches (width), and 6.69 inches (height).

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact the retailer from whom you purchased the JTLB 3500W Portable Induction Cooktop. For technical support or service inquiries, please reach out to the manufacturer or authorized service center using the contact details provided at the point of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DT4G6P6Z>

More documents and user manuals: <https://manuals.plus/>