



[Manuals.plus](#) /

> [CungSu](#) /

> [CungSu TF228WNM/U Digital Thermostat User Manual](#)

## CungSu TF228WNM/U

# CungSu TF228WNM/U Digital Thermostat User Manual

Model: TF228WNM/U

## 1. INTRODUCTION

---

This manual provides detailed instructions for the installation, operation, and maintenance of your CungSu TF228WNM/U Digital Thermostat. Please read this manual thoroughly before attempting to install or operate the device to ensure proper function and safety. Keep this manual for future reference.

## 2. SETUP AND INSTALLATION

---

### 2.1 Unpacking the Device

Carefully remove the CungSu TF228WNM/U Digital Thermostat from its packaging. Verify that all components are present and that the device is in new, factory-sealed condition. Inspect the device for any visible damage that may have occurred during transit.



This image displays the CungSu TF228WNM/U Digital Thermostat unit, a white rectangular device with a display screen and four control buttons, positioned on top of its brown cardboard retail box. The box features a label detailing the model number TF228WNM/U, identifying it as a Digital Thermostat, and listing electrical specifications (220/230VAC 50/60Hz 4(3)A IP20), quantity (QTY: 1), CE marking, date code (1815), and 'MADE IN CHINA'.

## 2.2 Mounting and Wiring

Installation should be performed by a qualified technician in accordance with local electrical codes. Ensure the main power supply is disconnected before beginning any wiring procedures. The thermostat is designed for 220/230VAC 50/60Hz systems. Refer to the wiring diagram provided with the product for specific connection details. Securely mount the thermostat to a wall in an appropriate location, away from direct sunlight, drafts, or heat sources that could affect temperature readings.

## 2.3 Initial Power-On

After successful installation and wiring, restore power to the system. The thermostat display should illuminate, indicating it is powered on. Follow any on-screen prompts for initial setup, such as time and date settings, if applicable.

## 3. OPERATING INSTRUCTIONS

### 3.1 Basic Controls

The TF228WNM/U thermostat features a digital display and multiple control buttons for easy operation. Typically, these buttons allow you to adjust temperature, select operating modes, and access settings.

- **Temperature Adjustment:** Use the 'Up' and 'Down' arrow buttons (or similar) to increase or decrease the desired temperature setting.

- **Mode Selection:** A 'Mode' button (or similar) allows you to cycle through operating modes such as Heat, Cool, Auto, or Off.
- **Power/Standby:** A dedicated button may exist to turn the unit on or off, or place it in standby mode.

### 3.2 Setting the Temperature

To set your desired temperature, ensure the thermostat is in the correct operating mode (e.g., Heat or Cool). Press the temperature adjustment buttons until the desired temperature is displayed. The thermostat will then work to maintain this setpoint.

### 3.3 Understanding the Display

The digital display provides real-time information, including the current room temperature, the set temperature, the active operating mode, and potentially other indicators like fan status or battery level (if applicable).

## 4. MAINTENANCE

---

### 4.1 Cleaning the Thermostat

To maintain optimal performance and appearance, periodically clean the exterior of the thermostat. Use a soft, damp cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the device's finish or internal components.

### 4.2 General Care

Ensure the thermostat's vents (if any) are not obstructed by dust or debris. Avoid exposing the device to extreme temperatures, high humidity, or direct water contact. Do not attempt to open the thermostat casing, as this may void the warranty and expose you to electrical hazards.

## 5. TROUBLESHOOTING

---

If you encounter issues with your CungSu TF228WNM/U Digital Thermostat, refer to the following common troubleshooting steps:

- **No Power/Blank Display:** Check the circuit breaker for the heating/cooling system. Ensure all wiring connections to the thermostat are secure.
- **Incorrect Temperature Reading:** Verify that the thermostat is not exposed to direct sunlight, drafts, or heat sources. Ensure the vents are clear.
- **System Not Responding:** Confirm the thermostat is set to the correct operating mode (Heat/Cool) and the desired temperature is above/below the current room temperature as appropriate.
- **Intermittent Operation:** Check for loose wiring connections. If the issue persists, professional inspection may be required.

If these steps do not resolve the issue, please contact customer support.

## 6. SPECIFICATIONS

---

Feature	Specification
Model Number	TF228WNM/U

Feature	Specification
Manufacturer	CungSu
Operating Voltage	220/230VAC
Frequency	50/60Hz
Current Rating	4(3)A
Ingress Protection (IP) Rating	IP20
ASIN	B0DT4MPN3K
Date First Available	January 15, 2025
UPC	6924732570034

## 7. WARRANTY AND SUPPORT

---

### 7.1 Product Warranty

The CungSu TF228WNM/U Digital Thermostat is supplied new with a factory seal. For specific warranty terms and conditions, please refer to the documentation provided with your purchase or contact the manufacturer directly. Any unauthorized tampering or modification of the device may void the warranty.

### 7.2 Customer Support

For technical assistance, troubleshooting, or inquiries regarding your CungSu TF228WNM/U Digital Thermostat, please contact the seller, Realing US, or the manufacturer, CungSu. They are dedicated to providing excellent customer service and support for their products.

Contact information can typically be found on the product packaging, the seller's storefront, or the manufacturer's official website.