

[Manuals.plus](#) /

› [KIDS PREFERRED](#) /

› KIDS PREFERRED Miffy Plush Toy (Model 54113-A) Instruction Manual

KIDS PREFERRED 54113-A

KIDS PREFERRED Miffy Plush Toy (Model 54113-A) Instruction Manual

1. INTRODUCTION

This manual provides essential information for the care and use of your KIDS PREFERRED Miffy Plush Toy, Model 54113-A. Miffy is an iconic character designed by Dick Bruna, known for her simple and endearing design. This plush toy is crafted to provide comfort and companionship for children.

The Miffy plush toy is suitable for all ages, from 0 months and up, and features soft boa material with embroidered details for durability and safety.





Image 1.1: The 14-inch white Miffy plush toy, featuring its characteristic embroidered eyes and crisscross mouth.

2. PRODUCT FEATURES

- **Size:** Approximately 14 inches tall, making it easy for small hands to hold.
- **Material:** Constructed from super soft boa material for a gentle touch.
- **Details:** Features charming embroidered eyes and the famous crisscross mouth, designed to withstand regular play and washing.
- **Stability:** Contains beans in the base to help Miffy sit upright.
- **Safety:** Designed to meet high quality and safety standards for children aged 0 months and up.




Image 2.1: Visual representation of Miffy's key features, including embroidered facial details, soft boa material, and weighted base for sitting.

3. SETUP AND FIRST USE

The Miffy plush toy comes ready for immediate use. No assembly is required.

1. **Unpacking:** Carefully remove the plush toy from its packaging.
2. **Inspection:** Before first use, inspect the plush toy for any loose threads or damage. If any issues are found, contact customer support.
3. **Initial Cleaning:** It is recommended to gently clean the plush toy before its first interaction with a child, especially for infants. Refer to the "Maintenance and Cleaning" section for detailed instructions.

4. OPERATING AND INTERACTION

The Miffy plush toy is designed for imaginative play and comfort. It can be used in various settings:

- **Cuddling:** Its soft texture makes it ideal for cuddling during naps or bedtime.
- **Playtime:** Encourage imaginative scenarios, such as Miffy joining adventures or tea parties.
- **Decoration:** The plush can also serve as a decorative item in a child's room.

MIFFY

perfect for hugs and cuddles



© Mercis bv



Image 4.1: A baby interacting with the Miffy plush, demonstrating its suitability for hugs and cuddles.

PERFECT SIZE
engage baby in
play time!

0+



© Mercis bv

Image 4.2: A child engaging with the Miffy plush, highlighting its appropriate size for early developmental play.

5. MAINTENANCE AND CLEANING

Proper care will ensure the longevity and hygiene of your Miffy plush toy.

5.1 General Cleaning

- **Spot Cleaning:** For minor spills or dirt, use a damp cloth with mild soap to gently clean the affected area. Blot dry with a clean towel.
- **Machine Washing:** The plush toy is machine washable. Place the toy in a mesh laundry bag to protect it. Use cold water on a gentle cycle with mild detergent.
- **Drying:** Air dry thoroughly. Do not use high heat in a dryer, as this may damage the material or embroidered details. Lay flat or hang to dry.

5.2 Storage

Store the plush toy in a clean, dry environment away from direct sunlight to prevent fading and material degradation.

6. TROUBLESHOOTING

This section addresses common concerns regarding plush toys.

Issue	Possible Cause	Solution
Plush appears flattened or misshapen.	Prolonged compression or improper storage.	Gently fluff the plush by hand. If machine washed, ensure it was air-dried properly.
Stains are difficult to remove.	Type of stain or delayed cleaning.	Attempt spot cleaning with a specialized fabric cleaner suitable for children's toys. Always test on an inconspicuous area first.
Loose threads.	Normal wear and tear.	Carefully trim loose threads with scissors. Do not pull them.

7. SPECIFICATIONS

- **Product Dimensions:** 9 x 6.5 x 14 inches (Length x Width x Height)
- **Item Weight:** 10.2 ounces
- **Model Number:** 54113-A
- **Manufacturer Recommended Age:** 0 months and up
- **Manufacturer:** Kids Preferred
- **ASIN:** B0DT4SSFSGS

8. WARRANTY AND SUPPORT

KIDS PREFERRED is committed to providing high-quality products. While specific warranty details are not provided in this manual, for any concerns regarding manufacturing defects or product quality, please contact Kids Preferred customer support.

For further assistance or inquiries, please visit the official Kids Preferred website or contact their customer service department. Keep your purchase receipt for reference.

